

[manuals.plus](#) /

› [Vgate](#) /

› [Vgate VR800 OBD2 Scanner - Professional EOBD OBDII CAN Diagnostic Code Reader for Check Engine Light](#)

Vgate VR800

Vgate VR800 OBD2 Scanner User Manual

Professional EOBD OBDII CAN Diagnostic Code Reader

1. INTRODUCTION

The Vgate VR800 OBD2 Scanner is a powerful and user-friendly diagnostic tool designed for automotive enthusiasts and professional mechanics alike. It provides comprehensive diagnostic functions for OBD-II/EOBD compliant vehicles, enabling users to quickly identify and resolve issues related to the Check Engine Light (CEL). This manual provides detailed instructions on how to set up, operate, and maintain your VR800 scanner to ensure optimal performance and accurate vehicle diagnostics.

2. PRODUCT OVERVIEW

The Vgate VR800 is a handheld diagnostic device featuring a color LCD display, intuitive button layout, and a durable OBD-II connector cable. Its compact design allows for easy portability and use in various automotive environments.

2.1 Key Components

- **LCD Color Display:** Provides clear and detailed diagnostic information.
- **Navigation Buttons:** Up, Down, Left, Right arrows for menu navigation.
- **OK Button:** Confirms selections.
- **I/M Button:** Shortcut for I/M Readiness status.
- **Question Mark (?) Button:** Provides help and DTC lookup information.
- **Return Button:** Navigates back to the previous screen.
- **OBD-II Connector:** Connects the scanner to the vehicle's diagnostic port.
- **USB Port:** For software updates and data printing.



The Vgate VR800 OBD2 Scanner, a compact diagnostic tool with a color display and an integrated OBD-II connector cable.

3. FEATURES

The Vgate VR800 OBD2 Scanner offers a comprehensive set of features for vehicle diagnostics:

- **All OBD2 Protocols Support:** Compatible with ISO9141, KWP2000, J1850 PWM, J1850 VPW, and CAN protocols. Compliance with SAEJ1979 has been upgraded to the latest standards (February 2017).
- **Broad Vehicle Compatibility:** Works with most American vehicles manufactured after 1996, European vehicles after 2000, and Asian vehicles after 2005. Applicable to OBD-II/CAN/EOBD-compliant vehicles, including light-duty trucks (6.5T or less), SUVs, and minivans.

- **Smog Check Helper (I/M Readiness):** Features Red-Yellow-Green LEDs and a built-in speaker to indicate readiness status for emissions testing. Dedicated I/M and '?' shortcut keys provide quick access to readiness checks.
- **Full OBD Service Modes:** Quickly reads and checks Diagnostic Trouble Codes (DTCs), views freeze frame data, reads live PCM data stream, performs On-Board Monitor tests, and displays live O2 sensor test data.
- **Built-in DTC Lookup Library:** Allows accurate determination of the causes of the Check Engine Light.
- **Accurate Battery Status Check:** Reads real-time battery and voltage information.
- **Multi-language Support:** Available in English, French, German, Italian, Spanish, Russian, Polish, and Portuguese.
- **Data Logging and Printing:** Supports data logging and connection to a PC for printing diagnostic data files.

Display monitor and I/M readiness status



Help you know whether the vehicle can pass the emissions test in advance.

- O2 Sensor test
- I/M Hot Key
- Fuel System
- Misfire
- Etc..



The Vgate VR800 display showing the Smog Check readiness status, indicating whether the vehicle is ready for emissions testing, with checks for O2 Sensor, I/M Hot Key, Fuel System, Misfire, and other parameters.

What's wrong with the car ?



Engine shut off solenoid?



Injector circuit open?



Intake air temperature too high?



DTC Guide

- Fuel pump circuit fuse blown.
- Open Fuel Pump Monitor Circuit.
- Faulty Fuel Pump Relay.
- Faulty Engine Control Module(ECM)



DTC Guide

Accurately identify car problems,
avoiding blind maintenance.

The Vgate VR800 screen showing I/M Readiness parameters, highlighting its ability to perform a rapid diagnosis in approximately 4 seconds, checking various engine systems.

Accurate Vehicle Battery Status

A great upgrade from the basic OBD2 scanner,
better to know battery condition.



An illustration showing the Vgate VR800's DTC Guide feature, which provides explanations for diagnostic trouble codes, helping users understand and address common car problems like fuel pump issues or faulty engine control modules.

VR800 WORKS ON MOST



1996

US-based Cars



2000

EU-based Cars



2005

Asia-based Cars

**Compatible with
All OBD2 Protocols**

KWP2000

ISO9141

J1850 VPW

J1850 PWM

SAEJ1979
(upgraded to Feb. 2017)

CAN
(Controller Area Network)

Language



The Vgate VR800 screen showing real-time battery voltage and charge percentage, indicating its capability to accurately assess vehicle battery health.



A visual representation of the Vgate VR800's broad compatibility, working with US-based cars after 1996, EU-based cars after 2000, and Asia-based cars after 2005, and supporting all major OBD2 protocols.

4. SETUP

Follow these steps to set up your Vgate VR800 OBD2 Scanner:

- 1. Locate the OBD-II Port:** The OBD-II port is typically located under the dashboard on the driver's side of the vehicle. Refer to your vehicle's owner's manual if you cannot find it.
- 2. Connect the Scanner:** Plug the VR800's OBD-II connector cable firmly into the vehicle's OBD-II port.
- 3. Power On:** The scanner will automatically power on once connected to the vehicle's OBD-II port. No external power source or batteries are required as it draws power directly from the vehicle.
- 4. Initial Setup (if prompted):** If this is your first time using the scanner or after a factory reset, you may be prompted to select a language. Use the navigation buttons to select your preferred language and press **OK**.

4 SECONDS RAPID DIAGNOSE

One-Click I/M Readiness Key detects misfire, fuel system, emissions readiness status and DTC information

I/M Readiness

MIL		IGN	Spark
DTC	0	Pd DTC	0
MIS	✓	EVAP	✗
FUE	✓	AIR	✗
CCM	✓	02S	✓
CAT	✓	HRT	✓
HCAT	✗	EGR	✓

- Straight Forward Interface
- Quite Responsive Buttons
- One-Click I/M Readiness Key
- Menu Hot Key



A user holding the Vgate VR800 OBD2 Scanner in a vehicle, demonstrating its ergonomic design and ease of use within the car's interior.

5. OPERATING INSTRUCTIONS

Once the scanner is connected and powered on, you can begin diagnosing your vehicle.

5.1 Navigating the Menu

Use the **UP** and **DOWN** arrow buttons to scroll through menu options. Press the **OK** button to select an option. Press the **Return** button to go back to the previous screen.

5.2 Reading Diagnostic Trouble Codes (DTCs)

1. From the main menu, select **Read DTCs**.
2. The scanner will display any active or pending DTCs. Each code will have a brief description.

5.3 Clearing DTCs

Warning: Clearing DTCs will erase all diagnostic trouble codes from the vehicle's computer and may reset readiness monitors. Ensure you have addressed the underlying issue before clearing codes.

1. From the main menu, select **Clear DTCs**.
2. Confirm your selection when prompted. The scanner will attempt to clear the codes.

5.4 I/M Readiness Function

The I/M Readiness function checks if the various emissions-related systems on the vehicle are operating correctly and if they have completed their self-tests.

1. Press the dedicated **I/M** button on the scanner.
2. The display will show the status of various monitors (e.g., O2 Sensor, EVAP, Catalyst). A green light indicates ready, yellow indicates pending, and red indicates not ready or a fault.

5.5 Viewing Live Data

Live Data allows you to view real-time sensor data from the vehicle's engine control unit (ECU).

1. From the main menu, select **Live Data**.
2. Choose the specific data parameters you wish to view (e.g., engine RPM, vehicle speed, O2 sensor voltage).

5.6 DTC Lookup

If you have a DTC and need more information, use the built-in DTC lookup library.

1. From the main menu, select **DTC Lookup** or press the **?** button when a DTC is displayed.
2. Enter the DTC code (if not already displayed) to get a detailed description and possible causes.

5.7 Battery Status Check

To check your vehicle's battery voltage and status:

1. From the main menu, select **Battery**.
2. The scanner will display the current battery voltage and an estimated charge percentage.

6. MAINTENANCE

Proper maintenance ensures the longevity and accuracy of your Vgate VR800 scanner.

- **Cleaning:** Use a soft, dry cloth to clean the scanner's exterior. Do not use abrasive cleaners or solvents.
- **Storage:** Store the scanner in a clean, dry environment away from extreme temperatures and direct sunlight.
- **Software Updates:** Regularly check for software updates to ensure compatibility with the latest vehicle models and diagnostic protocols. Updates can typically be performed by connecting the scanner to a PC via the USB port and using the provided update software.

7. TROUBLESHOOTING

If you encounter issues while using your Vgate VR800 scanner, refer to the following common problems and solutions:

- **Scanner Does Not Power On:**
 - Ensure the OBD-II connector is securely plugged into the vehicle's port.

- Verify the vehicle's ignition is in the ON position (engine can be off).
- Check the vehicle's fuse for the OBD-II port (consult your vehicle's manual).

• Related Documents - VR800

	<p>Vgate iCar Pro BLE 4.0 Quick Start Guide for iOS & Android</p> <p>Get started quickly with your Vgate iCar Pro BLE 4.0 OBD-II scanner. This guide covers vehicle compliance, app installation, Bluetooth pairing for iOS and Android, supported OBD parameters, and troubleshooting for your automotive diagnostic tool.</p>
	<p>Vgate vLinker BM+ Bluetooth OBD2 Scanner Quick Start Guide</p> <p>Step-by-step guide to connect the Vgate vLinker BM+ Bluetooth OBD2 scanner to your vehicle for diagnostics and app integration. Supports Android and iOS devices.</p>
	<p>Vgate iCar Pro BT3.0 Quick Start Guide for Android</p> <p>Get started quickly with your Vgate iCar Pro BT3.0 OBD-II scanner for Android. This guide covers vehicle compliance, supported protocols, app setup, pairing, troubleshooting, and understanding diagnostic codes.</p>
	<p>Vgate iCar OBD II Adapter User Manual - Diagnostic Tool Guide</p> <p>Comprehensive user manual for the Vgate iCar OBD II Adapter, detailing its features, specifications, supported protocols, setup guide, and warnings for car diagnostics.</p>
	<p>Vgate iCar2 BT3.0 Quick Start Guide and OBDII Information</p> <p>A comprehensive guide to the Vgate iCar2 BT3.0 Bluetooth OBDII scanner, covering vehicle compatibility, app support, connection steps, troubleshooting, and OBDII code explanations.</p>
	<p>Vgate vLinker FD OBD Scanner Bluetooth Quick Start Guide</p> <p>Concise guide to setting up and using the Vgate vLinker FD OBD scanner tool with Bluetooth connectivity for Android and Windows devices. Learn how to download the app, connect, and pair the device.</p>