

Preethi MG-261

Preethi Zodiac Black Mixer Grinder MG-261 User Manual

Model: MG-261 | Brand: Preethi

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, maintenance, and troubleshooting of your Preethi Zodiac Black Mixer Grinder MG-261. Please read this manual thoroughly before first use and retain it for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of injury or damage, always follow basic safety precautions, including:

- Read all instructions before operating the appliance.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Do not immerse the motor unit, cord, or plug in water or other liquids.
- Keep hands and utensils away from moving blades during operation to prevent injury.
- Always unplug the appliance from the power outlet before assembling, disassembling, or cleaning.
- Never operate the appliance with a damaged cord or plug.
- This appliance is for household use only. Do not use outdoors.
- Do not allow children to use or play with the appliance.
- In case of an overload, the indicator light will change from blue to red. This indicates the motor has tripped. Reset the overload protector located at the bottom of the product.
- A slight burning smell may occur during the first few uses due to motor varnish heating. This is normal and should dissipate with subsequent use. If it persists, contact customer service.

3. PRODUCT OVERVIEW

The Preethi Zodiac Black Mixer Grinder MG-261 is a versatile kitchen appliance designed for various food preparation tasks. It features a powerful 750W Vega W5 motor and comes with multiple jars for different applications.



Figure 1: Preethi Zodiac Black Mixer Grinder with its five accompanying jars.

Components:

- Main Motor Unit (750W Vega W5 Motor)
- 0.5L Chutney Jar
- 1.5L Wet Grind Jar
- 1L Dry Grind Jar
- 1.5L Juicer Jar
- 2.1L Master Chef+ Jar (Food Processor)
- Lids and Blades for each jar



Figure 2: The appliance functions as a mixer, juicer, and food processor.

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for storage or future transport.
2. **Clean Jars:** Wash all jars, lids, and blades with mild soap and water before first use. Rinse thoroughly and dry. The jars are dishwasher safe.
3. **Placement:** Place the main motor unit on a stable, flat, and dry surface, away from heat sources and water.
4. **Assemble Jar:** Attach the appropriate blade to the chosen jar. Place ingredients into the jar and secure the lid firmly.
5. **Mount Jar:** Place the assembled jar onto the motor unit, ensuring it locks securely into place. The locking system prevents operation if the jar is not correctly seated.
6. **Connect Power:** Plug the power cord into a suitable 230V AC ~ 50 Hz power outlet.

5. OPERATING INSTRUCTIONS

The mixer grinder features a 3-speed knob control for varying processing needs.

General Operation:

1. Ensure the jar is correctly mounted and locked onto the motor unit.
2. Turn the speed control knob to the desired speed setting (1, 2, or 3).
3. For short bursts of power, use the 'Pulse' setting.
4. After processing, turn the knob to 'OFF' and unplug the appliance before removing the jar.

Specific Jar Functions:



Figure 3: Overview of jar capacities and their primary applications.

- **0.5L Chutney Jar:** Ideal for preparing small quantities of chutneys and pastes. Can yield approximately 4 servings of chutney.
- **1.5L Wet Grind Jar:** Suitable for wet grinding tasks such as preparing batter for dosas, capable of processing enough for about 10 dosas.

- **1L Dry Grind Jar:** Designed for dry grinding spices and grains. Can grind up to 150 grams of dry masala.
- **1.5L Juicer Jar:** For extracting juice from fruits and vegetables. Yields approximately 2-2.5 cups of juice.
- **2.1L Master Chef+ Jar (Food Processor):** This multi-functional jar offers advanced food processing capabilities.

BEST IN CLASS MASTER CHEF+ JAR

2.1L FOOD PROCESSOR



ATTA KNEADING
FOR 12 ROTIS



SLICING
FOR 500 GM VEGGIES



CHOPPING
FOR 300 GM VEGGIES



CITRUS PRESS
FOR 1 DZ ORANGES



Figure 4: Functions of the Master Chef+ Jar.

Master Chef+ Jar Specifics:

- **Atta Kneading:** Kneads dough for up to 12 rotis in approximately 1 minute.
- **Chopping:** Chops up to 300 grams of vegetables in just 2 pulses.
- **Grating and Slicing:** Grates and slices up to 500 grams of vegetables in seconds.
- **Meat Mincing:** Mince meat efficiently.
- **Citrus Press:** Extracts juice from citrus fruits, such as a dozen oranges.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygiene of your appliance.

1. **Unplug:** Always unplug the mixer grinder from the power outlet before cleaning.
2. **Clean Motor Unit:** Wipe the main motor unit with a damp cloth. Do not immerse it in water.
3. **Clean Jars and Lids:** Wash jars, lids, and blades with warm soapy water immediately after use. Rinse thoroughly.
4. **Dishwasher Safe:** All jars are dishwasher safe for convenient cleaning.
5. **Dry Thoroughly:** Ensure all parts are completely dry before reassembling or storing.
6. **Storage:** Store the appliance and its accessories in a clean, dry place.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not start	Not plugged in; Jar not locked correctly; Overload protector tripped.	Check power connection; Ensure jar is securely locked; Reset overload protector at the bottom of the unit.
Burning smell during operation	First-time use (motor varnish); Overloading.	Normal for initial uses, should subside. If persistent or accompanied by smoke, switch off and contact service. Reduce load if overloading.
Motor stops during operation	Overload protector tripped.	Switch off, unplug, reduce contents in jar, wait a few minutes, then reset the overload protector and restart.
Poor grinding performance	Insufficient liquid; Overfilling; Dull blades.	Add more liquid if needed; Do not overfill jars; Check blades for sharpness (contact service if dull).

8. SPECIFICATIONS

- **Brand:** Preethi
- **Model:** MG-261 (Zodiac Black)
- **Power:** 750 Watts
- **Voltage:** 230V AC ~ 50 Hz
- **Body Material:** ABS Plastic
- **Jar Material:** Stainless Steel (except Master Chef+ Jar)
- **Product Dimensions:** 42D x 31W x 30H Centimeters
- **Item Weight:** 8 kg
- **Jars Included:** 0.5L Chutney, 1.5L Wet Grind, 1L Dry Grind, 1.5L Juicer, 2.1L Master Chef+ (Food Processor)
- **Controls Type:** Knob (3 Speed + Pulse)
- **Special Features:** Anti-Skid Base, Auto Shut Off, Dishwasher Safe Jars, Locking System, Overload Protection
- **Flex Cord:** PVC insulated 3 Core, Flexicord with Plugtop & earthing

9. WARRANTY AND SUPPORT

Preethi is committed to providing reliable products and customer support.

INDIA'S LARGEST SELLING MIXER GRINDER BRAND

LIFE LONG FREE SERVICE



Figure 5: Overview of warranty and service benefits.

- **Product Guarantee:** 2 Years from the date of purchase.
- **Motor Warranty:** 5 Years from the date of purchase.
- **Service:** Life-long free service (no labor charge).

For warranty claims, service requests, or any product-related queries, please refer to the contact information provided with your purchase documentation or visit the official Preethi website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question