Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gracemind 1089A

Gracemind 1089A Bluetooth Wireless Keyboard User Manual

Model: 1089A | Brand: Gracemind

Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Gracemind 1089A Bluetooth Wireless Keyboard. This keyboard is designed to enhance your productivity with Microsoft Surface Pro tablets, offering a comfortable typing experience and a responsive touchpad.
The keyboard features Bluetooth 5.3 connectivity, a magnetic attachment for stability, and a built-in rechargeable battery. It is compatible with Microsoft Surface Pro 3, Pro 4, Pro 5, Pro 6, Pro 7, and Pro 7 Plus tablets.



Image: The Gracemind Bluetooth keyboard magnetically attached to a Microsoft Surface Pro tablet, highlighting its compatibility across various Surface Pro models.

Setup

1. Charging the Keyboard

Before initial use, ensure the keyboard is fully charged. Connect the provided USB Type-C charging cable to the keyboard's charging port and to a power source (e.g., computer USB port, USB wall adapter). The charging indicator light will illuminate during charging and change color or turn off when fully charged.



Image: A close-up view of the Type-C charging port located on the side of the keyboard.



Image: An illustration indicating the keyboard's 350mAh rechargeable battery, providing extended usage time.

2. Bluetooth Pairing

Follow these steps to pair your keyboard with your Microsoft Surface Pro:

1. Turn on the keyboard by sliding the power switch to the 'ON' position. The power indicator light will turn on.
2. Press and hold the **Fn** key and the **Z** key simultaneously for 3-5 seconds. The Bluetooth indicator light will start blinking, indicating the keyboard is in pairing mode.
3. On your Microsoft Surface Pro, go to **Settings** > **Devices** > **Bluetooth & other devices**.
4. Ensure Bluetooth is turned **On**.
5. Click on **Add Bluetooth or other device** and select **Bluetooth**.
6. Select "Bluetooth Keyboard" from the list of available devices.
7. Once connected, the Bluetooth indicator light on the keyboard will stop blinking and remain solid.



Image: A visual representation of the Bluetooth 5.0 connection feature on the keyboard.

Video: This official video demonstrates the magnetic attachment of the keyboard to a Surface Pro tablet, followed by the Bluetooth pairing process and basic typing functionality. It shows the keyboard being connected, the pairing sequence, and the use of the touchpad.

Operating Instructions

1. Attaching and Detaching

The keyboard features a powerful magnetic strip that allows for secure attachment to your Surface Pro tablet. Simply align the keyboard with the bottom edge of your tablet until the magnets engage. The keyboard can be used in a flat position or slightly angled for ergonomic typing. It can also be detached for wireless use.



Image: The Gracemind keyboard shown magnetically attached to a Microsoft Surface Pro, ready for use.



Image: Another perspective of the keyboard attached to the Surface Pro, demonstrating its integrated design.

2. Touchpad Functionality

The integrated touchpad provides precise navigation and control, similar to a mouse. It supports multi-touch gestures for enhanced usability within the Windows operating system.

- **Single-finger tap:** Left-click
- **Two-finger tap:** Right-click
- **Two-finger scroll:** Scroll vertically or horizontally
- **Pinch-to-zoom:** Zoom in or out



Image: A detailed view of the keyboard's responsive touchpad, indicating its functionality.

3. Keyboard Features

The keyboard features a standard QWERTY layout with 78 keys, including dedicated function keys for media control and other shortcuts. The keys utilize a scissor-switch mechanism for quiet and comfortable typing.



Image: A diagram showcasing the internal scissor-switch structure of the keyboard keys, designed for tactile feedback and quiet operation.

Maintenance

To ensure the longevity and optimal performance of your keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, damp cloth to wipe the surface of the keyboard. Avoid using harsh chemicals or abrasive materials.
- **Battery Care:** To preserve battery life, fully charge the keyboard regularly. If not in use for an extended period, store it with a partial charge (around 50%). The keyboard features a sleep mode to conserve energy when idle.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures. The slim design allows for easy transport in a backpack or messenger bag.



Image: The keyboard being stored in a protective bag, emphasizing its portable and slim design.

Troubleshooting

If you encounter issues with your Gracemind keyboard, refer to the following common problems and solutions:

- **Keyboard not connecting via Bluetooth:**
  - Ensure the keyboard is fully charged.
  - Verify the keyboard's power switch is in the 'ON' position.
  - Make sure Bluetooth is enabled on your Surface Pro.
  - Repeat the pairing process (press Fn+Z until the Bluetooth indicator blinks, then search on your Surface Pro).
  - If previously paired, try removing the keyboard from your Surface Pro's Bluetooth device list and re-pairing.
- **Touchpad is unresponsive or erratic:**
  - Ensure the keyboard is properly connected via Bluetooth.
  - Clean the touchpad surface to remove any dirt or debris.
  - Restart both the keyboard and your Surface Pro.
- **Keys are not responding:**
  - Check the keyboard's battery level and charge if necessary.
  - Ensure the keyboard is within the effective Bluetooth range (up to 33ft/10m).
  - Re-establish the Bluetooth connection.

Specifications

Feature	Detail
Brand	Gracemind
Model Number	1089A
Connectivity Technology	Bluetooth 5.3
Compatible Devices	Microsoft Surface Pro 3, Pro 4, Pro 5, Pro 6, Pro 7, Pro 7 Plus
Keyboard Layout	QWERTY
Number of Keys	78

Feature	Detail
Special Feature	Lightweight, Touchpad, Magnetic Attachment
Product Dimensions	11.65"L x 8.66"W x 0.25"H
Material	Acrylonitrile Butadiene Styrene (ABS)
Power Source	Battery Powered
Battery Capacity	350mAh (approximate)
Effective Usage Time	100 hours (approximate)
Charging Port	Type-C
Color	Black



Image: The physical dimensions of the keyboard are displayed, showing its length, width, and slim profile.

Warranty and Support

For warranty information and customer support, please contact Gracemind directly through their official channels or the retailer where the product was purchased. Standard return policies typically allow for returns within 30 days of purchase, subject to the retailer's terms and conditions.
For further assistance, visit the Gracemind Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08N6FQLMV

More documents and user manuals: **https://manuals.plus/**