

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [B.K.Licht](#) /

› [B.K.Licht LED Ceiling Light BKL1337 Instruction Manual](#)

B.K.Licht BKL1337

B.K.Licht LED Ceiling Light BKL1337 Instruction Manual

Model: BKL1337 | Brand: B.K.Licht

1. PRODUCT OVERVIEW

The B.K.Licht LED Ceiling Light BKL1337 is a modern lighting fixture featuring four individually adjustable swivel spotlights. It is designed for indoor use, providing warm white illumination suitable for various living spaces such as bedrooms, living rooms, dining rooms, and kitchens. The light comes equipped with energy-efficient GU10 LED bulbs.



Image 1.1: The B.K.Licht LED Ceiling Light featuring four adjustable spotlights in a matt nickel finish.

2. SAFETY INSTRUCTIONS

Please read these safety instructions carefully before installing or operating this product. Retain this instruction manual for future reference.

- Installation must be performed by authorized, qualified personnel in accordance with applicable electrical installation regulations.
- The manufacturer assumes no responsibility for injuries or damages resulting from improper use of the

light.

- The light fixture is not designed for cleaning with water or other liquids. Use a dry, lint-free cloth for cleaning.
- **Caution: Risk of electric shock!** Before assembly, disassembly, or any maintenance, always disconnect the main power supply. Turn off the circuit breaker or fuse. Ensure the power is 'OFF'. Never use the light if any damage is detected.
- Before drilling mounting holes, ensure no gas, water, or power lines are present or damaged in the wall/ceiling.
- Ensure that the mounting material is suitable for the substrate and can support the weight of the fixture. The manufacturer is not liable for improper connection of the item to the respective substrate.
- This product does not contain batteries or accumulators that need to be removed for disposal.
- This light must be connected to the protective conductor (green-yellow wire) at the protective conductor terminal.
- Cover caps and end caps for the power connection must be mounted correctly.
- Do not mount the light on damp or conductive surfaces.
- Ensure cables are not damaged during installation.
- **Caution:** Light components can reach temperatures above 60°C during operation and should not be touched while hot.
- The insertion and alignment of the bulb must be done in a cooled state.
- This product is intended for normal operation and exclusively for ceiling mounting.
- Do not look directly into the light source (LED light).



Image 2.1: Original safety instructions provided with the product (German).



3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation.

- 1 x B.K.Licht LED Ceiling Light fixture
- 4 x GU10 LED Bulbs (3W, 250lm, 3000K Warm White)
- 2 x Mounting Screws
- 2 x Wall Plugs (Dowels)
- 2 x Insulating Sleeves
- 1 x Instruction Manual

BKL1337

inkl. 4 x LED GU10,
2,9 Watt, 260 Lumen, 3.000 Kelvin,
Strahler dreh- und schwenkbar,
Farbe: matt-nickel



230V / 50Hz



B.K. Licht GmbH & Co. KG, Herzog-Johann-Straße 4a,
81245 München



Image 3.1: Visual representation of key features: GU10 socket, adjustable spotlights, and included bulbs.

4. SETUP AND INSTALLATION

Follow these steps for safe and proper installation of your ceiling light.

- 1. Preparation:** Before starting, ensure the main power supply to the installation area is turned off at the circuit breaker.
- 2. Marking:** Position the light fixture on the ceiling at the desired location. Mark the two screw holes for mounting. The fixing bar screws are spaced approximately 13 cm apart.
- 3. Drilling:** Drill two holes at the marked positions. Ensure no hidden electrical wires, water pipes, or gas lines are present before drilling.
- 4. Mounting:** Insert the wall plugs (dowels) into the drilled holes. Secure the mounting bracket of the light fixture to the ceiling using the provided screws.
- 5. Wiring:** Connect the electrical wires from the ceiling to the terminals on the light fixture. Ensure correct polarity (Live, Neutral, Earth) and secure connections. Use the insulating sleeves if necessary.
- 6. Attaching Fixture:** Carefully attach the light fixture body to the mounting bracket, ensuring all wires are tucked safely inside and not pinched. Secure it firmly.
- 7. Bulb Installation:** Insert the GU10 LED bulbs into each of the four spotlight sockets. Twist gently to secure them.
- 8. Final Check:** Once installation is complete, restore power at the circuit breaker. Test the light fixture.



Image 4.1: Product dimensions: 180mm diameter and 109mm height.



Image 4.2: Example of the ceiling light installed in a hallway.

5. OPERATING INSTRUCTIONS

The B.K.Licht LED Ceiling Light is operated via a standard wall switch connected to your household electrical circuit.

- **Turning On/Off:** Use the wall switch to turn the light fixture on or off.
- **Adjusting Spotlights:** Each of the four spotlights can be individually swiveled and tilted to direct light precisely where needed. Gently adjust the spotlight heads to achieve your desired lighting angle.



Image 5.1: Illustration of the 360-degree adjustable feature of the spotlights.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your B.K.Licht LED Ceiling Light.

- **Cleaning:** Always disconnect power before cleaning. Use a soft, dry, lint-free cloth to wipe the surface of the fixture. Do not use abrasive cleaners, solvents, or liquids, as these can damage the finish or electrical components.
- **Bulb Replacement:** Ensure the fixture is cool and power is disconnected before attempting to replace bulbs. Twist the GU10 bulb counter-clockwise to remove and clockwise to insert a new one. Use only GU10 LED bulbs with compatible specifications.

7. TROUBLESHOOTING

If you encounter issues with your B.K.Licht LED Ceiling Light, refer to the following common troubleshooting steps:

- **Light does not turn on:**

- Check if the wall switch is in the 'ON' position.
- Verify that the circuit breaker for the light fixture is not tripped.
- Ensure bulbs are correctly seated in their sockets.
- Test with a known working GU10 bulb to rule out a faulty bulb.

- **Light flickers:**

- Ensure bulbs are securely tightened.
- Check for loose wiring connections (consult a qualified electrician if unsure).

- **Insufficient light output:**

- Verify that the spotlights are adjusted to the desired direction.
- Ensure the bulbs are of the correct wattage and lumen output as specified.

If problems persist after following these steps, please contact B.K.Licht customer service.

8. SPECIFICATIONS

Detailed technical specifications for the B.K.Licht LED Ceiling Light BKL1337.

Brand	B.K.Licht
Model Number	BKL1337
Product Dimensions	7.09"L x 7.09"W x 4.29"H (Ø180mm x 109mm)
Material	Metal
Finish Type	Matt Nickel
Light Source Type	LED
Number of Light Sources	4
Bulb Base	GU10
Bulb Wattage (each)	3 Watts
Total Wattage	12 Watts
Brightness (each bulb)	250 Lumen
Color Temperature	3000 Kelvin (Warm White)
Voltage	230 Volts
Power Source	Electrical Cable
Area Lighting Classification	IP20
Average Life	20,000 Hours
Assembly Required	Yes

Image 8.1: EU Energy Label for the B.K.Licht LED Ceiling Light. For more details, visit the [EPREL database](#).

9. WARRANTY AND SUPPORT

B.K.Licht products are designed for quality and reliability. For any questions, technical assistance, or warranty claims, please contact B.K.Licht customer service.

Customer satisfaction is a priority for B.K.Licht. Please refer to your purchase documentation for specific warranty terms and contact information.



Image 9.1: Product diagram with model number BKL1337, barcode (4057722005772), and QR code for additional information. Scan the QR code for more details: [QR Code Link](#).