

[Manuals.plus](#) /

> [SoundPEATS](#) /

> Soundpeats Sonic Écouteurs Bluetooth 5.2 sans Fil Intra-Auriculaires 35 Heures d'Autonomie avec Micro aptX-Adaptive, Étanche IPX5 pour Sport, Mode Jeu, Gris

## SoundPEATS

# Soundpeats Sonic Wireless Earbuds Instruction Manual

Model: Sonic

## 1. PRODUCT OVERVIEW

The Soundpeats Sonic wireless earbuds are designed to provide a superior audio experience with advanced features such as Bluetooth 5.2, Qualcomm QCC3040 chipset, aptX-Adaptive audio decoding, and IPX5 water resistance. They offer extended battery life and a comfortable fit for various activities including music listening, calls, and gaming.



Image: Soundpeats Sonic earbuds shown with their charging case. The earbuds are gray with rose gold accents, and the case is a matching gray.

## 2. PACKAGE CONTENTS

Ensure all items are present in the package:

- 1 Pair of Soundpeats Sonic Wireless Earbuds
- 1 Charging Case
- 3 Pairs of Eartips (Small, Medium, Large - Medium pre-fitted)
- 1 USB-C Charging Cable
- 1 User Manual



Image: All components of the Soundpeats Sonic package laid out: the charging case, two earbuds, three pairs of silicone eartips, a USB-C charging cable, and the user manual.

## 3. SETUP GUIDE

### 3.1 Initial Charge

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case, ensuring the charging contacts align. The "S" logo on the earbuds will glow red while charging.
2. Connect the USB-C charging cable to the charging port on the case and the other end to a USB power source (e.g., wall adapter, computer USB port).
3. The indicator light inside the case will show the charging status of the case. A full charge for the case takes approximately 1.5 hours.



***35 HOURS  
LONG-LAST ENJOYMENT***

15Hrs Per charge / 2 Times Charge / Type-C Quick Charge

Image: The Soundpeats Sonic charging case with a USB-C cable plugged into its charging port, indicating the charging method.



## **TrueWireless™**

# **MIRRORING TECHNOLOGY**

Enjoy music and calls freely in places with severe interference

Image: An illustration showing the Soundpeats Sonic earbuds inside the charging case, with indicators for battery levels: green for 100%-50%, orange for 49%-10%, and red for 0-10%.

### **3.2 Pairing with a Device**

The earbuds will automatically enter pairing mode when taken out of the case for the first time.

1. Open the charging case and remove both earbuds. They will automatically power on and attempt to pair with each other.
2. Enable Bluetooth on your device (smartphone, tablet, computer).
3. Search for "SOUNDPEATS Sonic" in the Bluetooth device list and select it to connect.
4. Once connected, you will hear a voice prompt confirming the successful pairing.

*Note: The advanced TrueWireless Mirroring technology ensures stable connection and reduced audio interruption.*

### **3.3 Comfortable Fit**

For optimal sound quality and comfort, choose the correct size eartips and ensure a proper fit.

- Try the different eartip sizes (Small, Medium, Large) to find the best seal for your ear canal.
- Insert the earbuds into your ears and gently twist them forward until the "S" logo is upright and they feel secure.



## **UNIQUE DESIGN & COMFORTABLE FIT**

Ergonomic design and 3 sizes of eartips provide comfortable fit

Image: A person wearing the Soundpeats Sonic earbuds, demonstrating their ergonomic design and comfortable fit in the ear.

### **4. OPERATING INSTRUCTIONS**

#### **4.1 Power On/Off**

- **Power On:** The earbuds automatically power on when removed from the charging case.
- **Power Off:** The earbuds automatically power off when placed back into the charging case.

#### **4.2 Button Controls**

The Soundpeats Sonic earbuds feature sensitive button controls for precise operation.

<b>Function</b>	<b>Action</b>
Play/Pause	Press the Multi-Function Button (MFB) once.
Volume +	Double press the Right MFB.

Function	Action
Volume -	Double press the Left MFB.
Next Track	Press and hold the Right MFB for 1.5 seconds.
Previous Track	Press and hold the Left MFB for 1.5 seconds.
Answer/End Call	Press the MFB once.
Reject Call	Press and hold the MFB for 1.5 seconds.
Activate Voice Assistant (Siri, Google Assistant)	Triple press the Right MFB.
Game Mode On/Off	Triple press the Left MFB.



Qualcomm® aptX™  
Adaptive



## ***SUPERIOR CLEAR SOUND WITH POWERFUL BASS***

Adopt aptx-adaptive audio decoding to ensure you clear sound with premium deep bass

Image: A visual representation of the Soundpeats Sonic earbuds and charging case, detailing the button controls for various functions like power, play/pause, volume, track control, call management, voice assistant, and game mode.

## **5. MAINTENANCE AND CARE**

### **5.1 Cleaning**

- Regularly clean the earbuds, especially the eartips and charging contacts, with a soft, dry, lint-free cloth.
- Remove eartips and clean them with mild soap and water if necessary, ensuring they are completely dry before reattaching.
- Do not use harsh chemicals or abrasive materials for cleaning.

## 5.2 Storage

- Always store the earbuds in their charging case when not in use to protect them and keep them charged.
- Store the case and earbuds in a cool, dry place, away from extreme temperatures and direct sunlight.

## 5.3 Battery Care

- To prolong battery life, avoid fully discharging the earbuds and charging case frequently.
- Charge the device regularly, even if not used for extended periods.

## 6. TROUBLESHOOTING

If you encounter issues with your Soundpeats Sonic earbuds, refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing with device.	<ul style="list-style-type: none"> <li>◦ Ensure earbuds are fully charged.</li> <li>◦ Turn off Bluetooth on your device and turn it back on.</li> <li>◦ Forget "SOUNDPEATS Sonic" from your device's Bluetooth list and re-pair.</li> <li>◦ Place earbuds back in the case, close it, wait a few seconds, then remove them to re-enter pairing mode.</li> </ul>
Only one earbud is working.	<ul style="list-style-type: none"> <li>◦ Ensure both earbuds are charged.</li> <li>◦ Place both earbuds back into the charging case, close the lid, and then open it again. This often resets the connection between them.</li> <li>◦ Perform a factory reset (refer to the full user manual for specific steps if needed, as this is not detailed in the provided data).</li> </ul>
Low volume or poor sound quality.	<ul style="list-style-type: none"> <li>◦ Adjust the volume on both the earbuds and your connected device.</li> <li>◦ Ensure the eartips provide a good seal in your ear canal. Try different sizes.</li> <li>◦ Clean any debris from the earbud nozzles and eartips.</li> </ul>
Charging case not charging.	<ul style="list-style-type: none"> <li>◦ Try a different USB-C cable and power adapter.</li> <li>◦ Ensure the charging cable is securely connected to both the case and the power source.</li> </ul>

## 7. SPECIFICATIONS

Key technical specifications for the Soundpeats Sonic Wireless Earbuds:

- **Model Number:** Sonic

- **Brand:** SoundPEATS
- **Connectivity Technology:** Wireless (Bluetooth)
- **Bluetooth Version:** 5.2
- **Chipset:** Qualcomm QCC3040
- **Audio Codec:** aptX-Adaptive
- **Battery Life (Earbuds):** Up to 15 hours per single charge
- **Total Playtime (with Charging Case):** Up to 35 hours
- **Charging Port:** USB Type-C
- **Water Resistance:** IPX5 (Sweat and splash resistant)
- **Control Type:** Button Control
- **Special Features:** cVc 8.0 Noise Reduction (for calls), Game Mode (low latency)
- **Weight:** Approximately 102 Grams (total item weight)
- **Compatible Devices:** iOS, Android, Microsoft, and other Bluetooth-enabled systems (e.g., iPhone, Samsung Galaxy, Huawei, iPad, MacBook)



## ***HIGH-TECH QCC3040 CHIPSET***

Advanced QCC3040 chipset brings seamless connection and lower power consumption



## **TrueWireless™ MIRRORING TECHNOLOGY**

Enjoy music and calls freely in places with severe interference

Image: A graphic illustrating the 35-hour long-lasting enjoyment provided by the Soundpeats Sonic earbuds, indicating 15 hours per charge and 2 additional charges from the Type-C quick charge case.

### **8. WARRANTY AND SUPPORT**

SoundPEATS products are designed and manufactured to the highest quality standards. For warranty information and technical support, please refer to the official SoundPEATS website or contact their customer service directly.

- **Official Website:** Visit the SoundPEATS official website for the most up-to-date warranty policy and support resources.
- **Customer Service:** For any issues or inquiries, contact SoundPEATS customer support through the contact information provided on their website or product packaging.

*Please retain your proof of purchase for warranty claims.*