
[Manuals.plus](#) /

› [Prominence Home](#) /

› Prominence Home Espy Modern 52 Inch Ceiling Fan User Manual (Model 51464-01)

Prominence Home 51464-01

Prominence Home Espy Modern 52 Inch Ceiling Fan User Manual

Model: 51464-01

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Prominence Home Espy Modern 52 Inch Ceiling Fan. This contemporary, low-profile ceiling fan features a sleek design, integrated dimmable LED lighting, and three reversible blades, offering both matte black and honey birch finish options. It is designed to provide adjustable, energy-efficient airflow for indoor spaces.



Image: The Espy 52-inch ceiling fan with matte black blades installed in a modern living room setting.

SAFETY INFORMATION

Please read and understand all instructions before beginning installation. Improper installation can lead to electric shock, fire, or personal injury. Always consult a qualified electrician if you are unsure about any part of the installation process.

- Ensure the power is disconnected at the circuit breaker before installation or servicing.
- All wiring must be in accordance with national and local electrical codes.
- The mounting structure must be capable of supporting the fan's weight (approximately 14.07 lbs).
- Do not bend the blade holders during installation or cleaning.
- Keep hands clear of the fan blades when the fan is operating.



Image: The product is certified to meet safety and compliance standards, including ETL US, DOE, and California regulations.

SETUP AND INSTALLATION

The Espy ceiling fan is designed for flush mount installation, making it suitable for rooms with lower ceilings. It is intended for indoor use only.

Included Components:

- Blade Irons
- Blades (3)
- Hardware Pack
- Light Kit (Integrated LED)
- Owner's Manual
- Remote Control (with batteries and wall mount)

Room Size Guidelines:

This 52-inch ceiling fan is ideal for medium to large rooms up to 400 sq. ft., such as bedrooms, living rooms, dining rooms, and home offices.

Know Your Room Size

Use the guide below for best location of your ceiling fan



Small Room

Less than 8 ft x 10 ft

Fan Size Up to 32-in



Medium Room

Up to 12 ft x 14 ft

Fan Size 32-in to 48-in

THIS FAN



Large Room

Up to 12 ft x 18 ft

Fan Size 48-in to 58-in

Image: Guide for selecting the appropriate fan size based on room dimensions. The 52-inch Espy fan is suitable for large rooms.

Product Dimensions:

Product Dimensions

Find the fan that is the best fit for your space




Image: Visual representation of the fan's dimensions, including a 52-inch blade span and a 10.7-inch height from ceiling to the bottom of the light kit.

OPERATING INSTRUCTIONS

Your Espy ceiling fan is controlled by the included remote control, which allows for convenient adjustment of fan speed, light, and direction.

Remote Control Functions:

- **Fan Speed:** Select from 3 quiet fan speeds (High, Medium, Low) for customizable comfort.
- **Power Fan Off:** Turns the fan off.
- **Light Control:** Tap to turn the integrated LED light on or off. Press and hold to dim or brighten the light (dimnable from 20-100%).
- **Light Delay Mode:** Tap to turn the light off after 1 minute.
- **Reversible Motor Switch:** A physical switch on the remote allows you to change the motor direction for summer or winter mode.

3 Speed Remote Control

Wall Dock Included

High Speed

Medium Speed

Low Speed

Power Fan Off

Light Delay Mode

Tap to turn light off after 1 min

Light Control

Turn light off / on
Press and hold to dim or brighten lights

Reversible Motor Switch

Summer and Winter Mode

Change Motor Direction



Image: Detailed view of the remote control, highlighting buttons for fan speed, light control, light delay, and the reversible motor switch.

Reversible Airflow:

The reversible motor allows for year-round use. In **summer mode**, the fan blades rotate counter-clockwise to create a downward airflow, producing a cooling effect. In **winter mode**, the blades rotate clockwise to create an upward airflow, circulating warm air trapped near the ceiling and helping to reduce heating costs.

Reversible Motor

Warm in winter, cool in summer



Image: Visual explanation of the reversible motor, showing how it circulates air differently for cooling in summer and distributing warmth in winter.

Blade Finish Options:

The fan blades are reversible, offering two distinct finishes: Matte Black and Honey Birch. You can choose the side that best complements your room's decor.

Reversible Blades

Choose between two different blade finishes to pick the style that best complements your home



Matte Black

SIDE A



Honey Birch

SIDE B

Image: The fan blades can be reversed to display either a matte black or honey birch finish, allowing for customization.

Integrated LED Light:

The fan features a frosted integrated globe light kit with a 4-inch LED board, providing 1400 lumens at 3000K color temperature. The light is dimmable from 20% to 100% via the remote control.



Image: Detail of the fan's integrated LED light, showing its frosted globe and dimming capabilities.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish or electrical components.
- **Blade Care:** Periodically check the blade screws for tightness. Loose blades can cause wobbling and noise.
- **Light Kit:** The LED light board is integrated and designed for long life. It does not require bulb replacement.
- **Remote Control:** Replace the 12V battery in the remote control as needed. Ensure correct polarity when inserting new batteries.

TROUBLESHOOTING

If you experience issues with your ceiling fan, refer to the following common solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Remote control battery is dead; Incorrect wiring.	Check circuit breaker. Replace remote control battery (12V). Verify wiring connections are secure.
Light does not work	No power to the light; Remote control battery is dead; Light kit connection issue.	Check circuit breaker. Replace remote control battery. Ensure light kit connections are secure.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws. Ensure blades are balanced (a balancing kit may be required). Verify mounting bracket is securely fastened to the ceiling junction box.
Remote control not responding	Dead battery; Remote not paired with fan; Obstruction between remote and fan receiver.	Replace the 12V battery. Refer to the full owner's manual for remote pairing instructions. Ensure clear line of sight. Note: This fan relies solely on the remote control for operation; there is no manual override switch for the fan or light.
Fan is noisy	Loose screws; Motor hum; Blades hitting an obstruction.	Check and tighten all screws. Ensure no wires are rubbing against the motor housing. Verify blades are not hitting anything.

For more detailed troubleshooting steps, please refer to the complete owner's manual provided with your product or contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Prominence Home
Model Name	Espy
Part Number	51464-01
Color	Matte Black
Product Dimensions	52"D x 52"W x 10.74"H
Blade Length / Span	52 Inches
Number of Blades	3
Blade Finish Options	Matte Black, Honey Birch (Reversible)
Installation Type	Flush Mount
Indoor/Outdoor Usage	Indoor
Power Source	Corded Electric
Voltage	120 Volts (AC)
Wattage	50.13 watts

Feature	Detail
Air Flow Capacity	4117.2 Cubic Feet Per Minute
Speed	3 levels (164 RPM max)
Control Method	Remote Control
Special Feature	Reversible Airflow
Type of Bulb	Integrated LED
Luminous Flux	1400 Lumen
Color Temperature	3000K
Dimmable	Yes (20-100%)
Item Weight	14.07 Pounds
Batteries	1 x 12V (included, Alkaline)
Certifications	cETLus, DOE Compliant

WARRANTY INFORMATION

The Prominence Home Espy Modern 52 Inch Ceiling Fan comes with a**Limited Lifetime Warranty**. Please refer to the full warranty statement included with your product for specific terms, conditions, and limitations.

CUSTOMER SUPPORT

For technical assistance, replacement parts, or any questions not covered in this manual, please contact Prominence Home customer service. Contact information can typically be found in the full owner's manual or on the official Prominence Home website.

You can also visit the [Prominence Home Store on Amazon](#) for additional product information and support resources.

© 2026 Prominence Home. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question