

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Skywin](#) /

› [Skywin TidyFriend Liquid Laundry Detergent Holder Stand \(Model SW-LSS-WHITE\) Instruction Manual](#)

Skywin SW-LSS-WHITE

Skywin TidyFriend Liquid Laundry Detergent Holder Stand Instruction Manual

Model: SW-LSS-WHITE

1. INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your Skywin TidyFriend Liquid Laundry Detergent Holder Stand. This product is designed to simplify the dispensing of liquid laundry detergents and fabric softeners, preventing spills and organizing your laundry area.



Image 1.1: The TidyFriend Liquid Laundry Detergent Holder Stand with various detergent bottles.

2. PRODUCT OVERVIEW

The TidyFriend Laundry Detergent Holder Stand is a practical solution for managing large liquid detergent and fabric softener bottles. Its key features include:

- **Universal Fit:** Designed to accommodate most detergent and softener bottles.
- **Angled Platform:** Facilitates easy, gravity-assisted pouring, eliminating the need to lift heavy containers.
- **Integrated Drip Tray:** Catches any drips or spills, keeping your surfaces clean.
- **Adjustable Strap:** Secures the detergent bottle in place, preventing movement.
- **Non-Slip Rubber Feet:** Ensures stability and prevents the stand from sliding.



Image 2.1: Non-slip rubber feet for enhanced stability.

3. SETUP INSTRUCTIONS

Follow these steps to set up your TidyFriend Laundry Detergent Holder Stand:

- 1. Assemble the Stand:** The stand typically arrives in a few pieces that easily slot together. Ensure all connections are secure.
- 2. Attach the Strap:** Feed the adjustable strap through the designated slots on the stand.
- 3. Place the Detergent Container:** Position your liquid laundry detergent or fabric softener container onto the angled platform of the stand, ensuring the dispenser spout aligns with the drip tray.
- 4. Secure the Container:** Fasten the adjustable strap around the detergent container. Pull the strap firmly to ensure the container is held securely and will not roll or shift during use.

Comes with a strap

to fasten the detergent bottle to the platform



Image 3.1: Detergent bottle secured with the adjustable strap.

So easy to use,
even your kids can pour the soap!



Image 3.2: Step-by-step visual guide for easy setup.

Setup Video

Video 3.1: This video demonstrates the setup and operation of the Skywin Liquid Laundry Detergent Holder Organizer.

4. OPERATING INSTRUCTIONS

Using your TidyFriend stand is designed for simplicity and convenience:

- 1. Position Your Measuring Cup:** Place your laundry measuring cup directly under the detergent spout on the integrated drip tray.
- 2. Dispense Detergent:** Press the dispenser button or lever on your detergent bottle. The angled platform will ensure a smooth flow of liquid into your cup.
- 3. Prevent Spills:** The drip tray is designed to catch any residual drips, keeping your laundry area clean.



Image 4.1: Demonstrates easy, hands-free pouring of detergent.



Image 4.2: The angled platform ensures detergent pours out easily.

5. MAINTENANCE

To keep your TidyFriend Laundry Detergent Holder Stand in optimal condition:

- **Clean the Drip Tray:** Regularly wipe down the drip tray with a damp cloth to remove any accumulated detergent residue. The smooth plastic surface makes it easy to clean.
- **Inspect the Strap:** Periodically check the adjustable strap for wear and tear. Ensure it remains securely fastened around the detergent container.



Image 5.1: The drip tray is easy to wash off in a sink.

6. TROUBLESHOOTING

If you encounter any issues with your detergent holder, consider the following:

- **Slow Detergent Flow:** Ensure the cap on your detergent jug is slightly loosened to prevent a vacuum from forming, which can slow down dispensing.
- **Container Instability:** Verify that the adjustable strap is tightly secured around the detergent bottle and that the non-slip rubber feet are properly positioned on a flat surface.
- **Spills on Counter:** Confirm that the measuring cup is correctly placed within the drip tray and that the dispenser spout is fully extended over the cup.

7. SPECIFICATIONS

Feature	Detail
Model Number	SW-LSS-WHITE
Product Dimensions	7.9 x 12.2 x 5.5 inches (L x W x H)
Item Weight	1.37 pounds (0.62 Kilograms)
Material	Plastic
Color	White
Special Features	Adjustable Straps Lock, Angled Dispensing Design, Easy Organization, Hands Free Drip Catching Capability, Spill Proof Drip Tray System
Assembly Required	No

8. WARRANTY INFORMATION

This product comes with a standard manufacturer's warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the packaging or contact Skywin customer support directly. Keep your proof of purchase for any warranty claims.

9. CUSTOMER SUPPORT

For further assistance, questions, or to report any issues with your TidyFriend Liquid Laundry Detergent Holder Stand, please contact Skywin customer support through their official website or the contact information provided on the product packaging.