

Vicco Roman (Model 695)

Vicco Roman Corner Bench Instruction Manual

Model: 695 | Brand: Vicco

[Safety Information](#) [Setup & Assembly](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- **Adult Assembly Required:** This product requires adult assembly. Keep small parts and assembly hardware away from children.
- **Stable Placement:** Ensure the corner bench is placed on a flat, stable surface to prevent tipping.
- **Weight Limit:** Do not exceed the recommended weight capacity for seating or storage compartments.
- **Avoid Climbing:** Do not allow children to climb on the bench or corner unit.
- **Proper Use:** Use the bench only for its intended purpose as seating and storage.
- **Regular Checks:** Periodically check all fasteners to ensure they are tight. Retighten as necessary.

2. SETUP AND ASSEMBLY

The Vicco Roman Corner Bench requires assembly. All necessary hardware and detailed instructions are included in the package. Please follow the steps below carefully.

2.1 Unpacking

- Open the packaging carefully and remove all components.
- Verify that all parts listed in the parts list are present and undamaged.
- Lay out all parts on a clean, soft surface (e.g., a blanket or cardboard) to prevent scratches.

2.2 Assembly Steps

1. Identify all wooden panels and hardware according to the provided assembly diagram.
2. Begin by assembling the main bench sections. Attach side panels to the base and backrest using the

designated screws and dowels.

3. Assemble the corner unit, ensuring all shelves are securely fastened.
4. Connect the assembled bench sections to the corner unit.
5. Install the upholstered seating pads onto the bench frames.
6. For models with storage, attach the hinges and lids to the storage compartments.
7. Once fully assembled, gently move the bench to its desired location.
8. Tighten all screws and fasteners once the bench is in its final position. Do not overtighten.



Image 1: The Vicco Roman Corner Bench fully assembled, shown with a dining table and stool (sold separately).



Image 2: Detailed dimensions of the individual bench and corner shelf components for planning your space.

3. OPERATING INSTRUCTIONS

The Vicco Roman Corner Bench is designed for comfortable seating and efficient space utilization in dining areas or kitchens.

3.1 Seating

- The upholstered seats provide comfort for dining or casual use.
- The corner design allows for optimal use of space, fitting snugly into room corners.

3.2 Storage (if applicable)

Some configurations of the Roman Corner Bench include integrated storage compartments under the seats.

- To access storage, lift the seat cushion. The hinges are designed for smooth operation.
- Store items evenly to maintain balance and prevent damage to the bench structure.
- Do not overload the storage compartments.



Image 3: The corner bench with seats lifted, revealing the integrated storage compartments.

4. MAINTENANCE

To ensure the longevity and appearance of your Vicco Roman Corner Bench, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the particle board surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the melamine coating.
- **Upholstery Care:** For upholstered parts, spot clean with a mild fabric cleaner as needed. Test on an inconspicuous area first.
- **Avoid Moisture:** Protect the bench from excessive moisture and direct sunlight to prevent warping or fading.
- **Tighten Fasteners:** Periodically check and tighten all screws and fittings to maintain structural integrity.

5. TROUBLESHOOTING

If you encounter any issues with your Vicco Roman Corner Bench, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

| Problem | Possible Cause | Solution |
|---------------------------------------|--|--|
| Bench feels wobbly or unstable. | Loose fasteners or uneven floor. | Tighten all screws and bolts. Ensure the bench is on a level surface. Use furniture pads if necessary. |
| Storage lid does not close properly. | Hinges misaligned or obstruction in compartment. | Check hinge alignment and adjust if needed. Remove any items obstructing the lid. |
| Scratches or minor damage to surface. | Accidental impact or abrasive cleaning. | Use a furniture repair kit or touch-up pen for minor scratches. Avoid abrasive materials for cleaning. |

If the problem persists or if you encounter an issue not listed here, please contact Vicco customer support.

6. SPECIFICATIONS

| Feature | Detail |
|-------------------------------|--|
| Model Name | Roman |
| Model Number | 695 |
| Brand | Vicco |
| Color | Golden Oak |
| Material | 16mm Particle Board with Melamine Resin Coating |
| Overall Dimensions (Approx.) | 120 x 120 cm (Length x Width for corner configuration) |
| Bench Dimensions (Individual) | 76.6 cm (Width) x 41.5 cm (Depth) x 80 cm (Height) |
| Item Weight | Approximately 43.14 kg |
| Assembly Required | Yes |
| Care Instructions | Wipe with a damp cloth |

7. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your purchase or contact Vicco customer service directly. Vicco is committed to providing quality products and support.

7.1 Customer Support

If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please contact Vicco customer support through their official website or the retailer where the product was purchased.

Please have your model number (695) and purchase details ready when contacting support.

