

LEGO 76176

LEGO Marvel Shang-Chi Escape from The Ten Rings 76176 Building Kit Instruction Manual

Model: 76176

1. INTRODUCTION

This instruction manual provides detailed guidance for assembling and understanding the LEGO Marvel Shang-Chi Escape from The Ten Rings 76176 Building Kit. This set allows you to recreate action scenes with iconic characters, vehicles, and accessories from the Marvel Studios film. Please read all instructions carefully before beginning assembly.

Safety Warning: This set contains small parts and is not suitable for children under 3 years of age due to choking hazards. Adult supervision is recommended for younger builders (recommended age 7+).

2. WHAT'S INCLUDED

The LEGO Marvel Shang-Chi Escape from The Ten Rings 76176 Building Kit includes 321 LEGO building elements. Upon opening the box, you will find several numbered bags containing the bricks, along with a printed instruction booklet.

Key Components:

- **Minifigures:** Shang-Chi, Katy, Wenwu, and Razor Fist.
- **Creature Figure:** Morris.
- **Vehicles:** One yellow SUV and two motorcycles.
- **Structures:** Two shooter turrets.
- **Accessories:** Two rings, a crossbow, two daggers, a sword, and a spear.



Image 2.1: Overview of all included LEGO elements for the 76176 set.



Image 2.2: The four minifigures and the Morris creature figure.

3. ASSEMBLY (SETUP)

Follow the step-by-step instructions provided in the physical instruction booklet included with your LEGO set. Each bag of bricks is numbered to correspond with specific sections of the build, ensuring a smooth assembly process.

General Assembly Tips:

1. **Organize:** Open one numbered bag at a time. Spread the pieces on a clean, flat surface to easily locate them.

2. **Follow Steps:** Carefully observe the images in the instruction booklet. Each step shows which new pieces to add and where.
3. **Press Firmly:** Ensure all bricks are pressed together firmly to create stable connections.
4. **Double-Check:** If you encounter difficulty, re-examine the previous steps to ensure no pieces were missed or incorrectly placed.



Image 3.1: Example of the building process with various LEGO elements.

4. OPERATING FEATURES

Once assembled, the LEGO Shang-Chi set offers interactive play features designed for dynamic action scenarios.

Shooter Turrets:

The two shooter turrets are equipped with spring-loaded shooters. To operate:

1. Load the projectile (blue 'arrow' or disc) into the front of the shooter mechanism.
2. Press the small lever or button located at the back of the shooter to launch the projectile.




Image 4.1: Operation of the shooter turret.

Vehicles:

The yellow SUV and two motorcycles are designed for imaginative play, allowing minifigures to be placed inside or on them for chase sequences.

- The SUV features opening doors and a removable roof for easy minifigure placement.
- The motorcycles are sized to fit one minifigure each.



Image 4.2: The yellow SUV and two motorcycles.

Morris Figure:

The Morris creature figure is a static accessory designed to enhance the play experience and character interactions.



Image 4.3: The Morris creature figure.

5. MAINTENANCE

Proper care and storage will help preserve your LEGO set for years of enjoyment.

Cleaning:

- Use a soft cloth or brush to gently remove dust from the bricks.
- For deeper cleaning, wash LEGO bricks by hand using lukewarm water (not exceeding 40°C / 104°F) and a mild detergent. Rinse thoroughly with clear water.
- Do not use hot water, harsh chemicals, or abrasive cleaners, as these can damage the plastic.
- Allow bricks to air dry completely before reassembling or storing.

Storage:

- Store your LEGO set in a cool, dry place away from direct sunlight to prevent discoloration and warping.
- Keep small pieces in a container to prevent loss.

6. TROUBLESHOOTING

If you encounter any issues during assembly or play, consider the following common solutions:

- **Missing Pieces:** Carefully check all packaging and the building area. If a piece is genuinely missing, contact LEGO Customer Service for replacement parts.
- **Assembly Difficulty:** Review the instruction steps. Sometimes a small piece is overlooked or placed incorrectly, affecting subsequent steps. Disassemble the problematic section and rebuild carefully.
- **Loose Connections:** Ensure bricks are fully pressed together. Some connections may require more force than others.

7. SPECIFICATIONS

Product Name	LEGO Marvel Shang-Chi Escape from The Ten Rings
Model Number	76176
Item Model Number (Internal)	6332616
Number of Pieces	321
Recommended Age	7 years and up
Product Dimensions	13.94 x 7.52 x 2.32 inches (35.4 x 19.1 x 5.9 cm)
Item Weight	10.6 ounces (300.5 grams)
Release Date	April 26, 2021

8. WARRANTY AND SUPPORT

LEGO products are manufactured to high-quality standards. If you experience any issues with your set, such as missing or defective parts, please contact LEGO Customer Service directly.

Contact Information:

- **Online Support:** Visit the official LEGO website and navigate to the 'Customer Service' or 'Support' section for FAQs, replacement parts, and contact options.
- **Phone Support:** Refer to the contact details provided on the LEGO website for your specific region.

Please have your set's model number (76176) and details of the issue ready when contacting support.