

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [LEGO](#) /
- › [LEGO Classic Creative White Bricks 11012 Building Kit Instruction Manual](#)

## LEGO 11012

# LEGO Classic Creative White Bricks 11012 Building Kit Instruction Manual

Model: 11012

## 1. PRODUCT OVERVIEW

The LEGO Classic Creative White Bricks (11012) building kit is designed to inspire creative potential in children aged 4 and up. This set includes 60 pieces, offering components to construct three initial models: a snowman with a broom, a sheep with a flower field, and a seagull with a fish. The bricks can also be combined to create unique designs, fostering open-ended play and developing fine motor skills.



Image: The complete LEGO Classic Creative White Bricks 11012 set, showing the product box and the three primary models (snowman, sheep, seagull) assembled.

### Key Features:

- Includes 60 LEGO bricks for creative construction.
- Features 3 easy-to-build model ideas: a snowman, a sheep, and a seagull.
- Designed for children aged 4 and up.
- Encourages open-ended creative play and skill development.
- Compatible with other LEGO sets for expanded building possibilities.

## 2. WHAT'S INCLUDED (SETUP)

Upon opening the package, verify that all components are present. The LEGO Classic Creative White Bricks 11012 set contains 60 individual LEGO elements, including various white bricks, specialized pieces for eyes and accessories, and baseplates for the models. A simple building guide is also included to assist with the initial





Image: Back view of the LEGO Classic Creative White Bricks 11012 packaging, showing previews of the included building ideas and information about the Instructions PLUS app.

### 3. BUILDING INSTRUCTIONS (OPERATING)

This set provides a simple printed building guide for the three main models. For an enhanced interactive building experience, download the free LEGO Building Instructions app on your smartphone or tablet. This app offers digital Instructions PLUS, featuring zoom and rotate viewing tools to guide builders through each step.



Image: The three suggested models from the LEGO Classic Creative White Bricks 11012 set: a snowman with a broom, a sheep in a flower field, and a seagull with a fish.




Image: A child engaged in building with the LEGO Classic Creative White Bricks set, demonstrating the hands-on play experience.

### [Interactive Building Guide:](#)

The LEGO Building Instructions app is available for free download on most app stores. Search for "LEGO Building Instructions" and follow the on-screen prompts to install. Once installed, locate the instructions for model 11012 to access interactive 3D building guides.

Your browser does not support the video tag.

Video: A 360-degree view of the assembled LEGO Classic Creative White Bricks models, showcasing their design from all angles.

## 4. CREATIVE PLAY

Beyond the suggested models, the LEGO Classic Creative White Bricks set encourages builders to use their imagination. Mix and match the bricks to create new animals, objects, or scenes. The white bricks provide a versatile foundation for any creative project, allowing for endless possibilities.



Image: A child smiling and interacting with the assembled LEGO models, highlighting the joy of creative play.



Image: A clear display of the snowman, seagull, and sheep models, demonstrating the variety of creations possible with the set.

## 5. CARE AND MAINTENANCE

To ensure the longevity and cleanliness of your LEGO bricks, follow these guidelines:

- **Cleaning:** Wash LEGO bricks by hand using water no warmer than 104°F (40°C) and a mild detergent. Rinse thoroughly with clear water and allow them to air dry at room temperature. Do not use hot water, washing machines, or dryers, as high temperatures can damage the bricks.
- **Storage:** Store LEGO bricks in a clean, dry place away from direct sunlight and extreme temperatures. This helps prevent discoloration and warping.
- **Handling:** Avoid stepping on or applying excessive force to the bricks, as this can cause breakage or deformation.

## 6. TROUBLESHOOTING

If you encounter any issues with your LEGO Classic Creative White Bricks set, consider the following:

- **Missing Pieces:** In rare cases, a piece might be missing. Please visit the official LEGO Customer Service website to request replacement parts.
- **Difficulty Assembling:** Refer to the included building guide or the interactive Instructions PLUS app for detailed step-by-step visuals. Ensure you are using the correct pieces for each step.
- **Damaged Bricks:** If any bricks are damaged upon arrival, contact LEGO Customer Service for assistance.

## 7. SPECIFICATIONS

Attribute	Detail
Brand	LEGO
Model Name	Classic Creative White Bricks
Model Number	11012 (Product ID: 6327636)
Number of Pieces	60
Recommended Age	4 years and up
Product Dimensions	4.8 x 3.58 x 1.85 inches
Item Weight	2.82 ounces

## 8. WARRANTY AND SUPPORT

LEGO products are manufactured to high-quality standards. For information regarding product warranty, missing parts, or any other support needs, please visit the official LEGO Customer Service website:

[LEGO Customer Service](#)

You can also find additional building ideas and community support on the official LEGO website.

