

[Manuals.plus](#) /

› [BELLA](#) /

› BELLA 1.7 Liter Glass Electric Kettle User Manual

BELLA 17267

BELLA 1.7 Liter Glass Electric Kettle User Manual

Brand: BELLA

Model: 17267

INTRODUCTION

The BELLA 1.7L Glass Electric Kettle is a versatile and safe appliance designed for quickly boiling water. It combines modern style with practical functionality, making it an essential tool for any kitchen. This kettle features a powerful 1500-watt heating element, a fully detachable 360-degree power base with cord storage, and built-in safety features like automatic shut-off and boil-dry protection.

IMPORTANT SAFETY PRECAUTIONS

When using electrical appliances, basic safety precautions should always be followed, including:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical hazards, do not immerse the power base, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The kettle must be used only with the provided power base.
- Do not operate the kettle without water. Boil-dry protection will automatically shut off the kettle if it is empty.
- Ensure the lid is securely closed before operating.

- This kettle features automatic shut-off once water reaches a rolling boil, enhancing safety.

PARTS AND FEATURES



Overall View: The BELLA 1.7 Liter Glass Electric Kettle features a clear glass body, black handle, and a black power base. It has visible water level markings and a power switch.

Fast and Easy Breakfast Every Day



8 inch

5 inch

BELLA 1.7L ELECTRIC KETTLE & WATER BOILER

Compact Design: The kettle measures approximately 8 inches in height and 5 inches in width at the base, making it suitable for various countertop spaces. It can boil up to 7 cups of water in 6-7 minutes.



Soft Blue LED Lights

Soft Blue LED Lights: The kettle illuminates with soft blue LED lights while boiling, providing a visual indication of operation. It features a simple one-touch operation for ease of use.

Fully Detachable Base

Portable swivel base kettle with cord storage



Fully Detachable Swivel Base: The kettle can be lifted off its 360-degree rotating power base for cordless pouring. The base also includes convenient cord storage to keep your countertop tidy.

Built-in Safety Features

Auto shut-off & boil dry protection



Built-in Safety Features: Equipped with automatic shut-off and boil-dry protection, the kettle ensures safe operation. The concealed heating element further enhances safety and simplifies cleaning.

Enjoy Timeless Design

Elegant borosilicate glass
perfect for any countertop

Easy to read
water level indicator



Timeless Design & Water Level Indicator: The elegant borosilicate glass body is durable and allows for easy monitoring of the water level through clear markings. The transparent design is perfect for any kitchen aesthetic.

Product Video Overview

Your browser does not support the video tag.

Video Description: This official product video from BELLA showcases the electric glass kettle's features, including its rapid boiling capability, soft blue LED illumination, detachable power base, and automatic shut-off function. It demonstrates the kettle in use for various hot beverages and instant meals.

SETUP

Before First Use:

1. Unpack the kettle and all its components. Remove any packaging materials.

2. Place the power base on a dry, flat, stable, and heat-resistant surface.
3. To clean the kettle before first use, fill it with water to the MAX line.
4. Boil the water as described in the "Operating Instructions" section.
5. Discard the boiled water and rinse the kettle thoroughly with fresh water.
6. Repeat this process 2-3 times to ensure the kettle is clean and free of any manufacturing residues.

OPERATING INSTRUCTIONS

Boiling Water:

1. Ensure the kettle is unplugged from the power outlet.
2. Open the lid by pinching the release mechanism on top of the handle and lifting.
3. Fill the kettle with the desired amount of fresh, cold water. Do not fill below the MIN (0.5L / 2 CUPS) mark or above the MAX (1.7L / 7 CUPS) mark. Overfilling may cause boiling water to overflow.
4. Close the lid securely until it clicks into place.
5. Place the kettle firmly onto the power base.
6. Plug the power cord into a standard electrical outlet.
7. Flip the power switch located at the base of the handle downwards to the "ON" position. The soft blue LED lights will illuminate, indicating that the kettle is heating.
8. The water will begin to boil. The kettle will automatically shut off once the water reaches a rolling boil, and the LED lights will turn off.
9. Carefully lift the kettle from the power base and pour the hot water. The cordless design allows for easy serving.
10. Always unplug the kettle from the power outlet when not in use.

MAINTENANCE

Cleaning:

- Always unplug the kettle and allow it to cool completely before cleaning.
- The exterior of the kettle can be wiped with a damp cloth. Do not use abrasive cleaners or scouring pads.
- The interior of the kettle should be hand washed. Do not immerse the power base in water.
- The lid is not fully removable, but can be opened wide for access to the interior for cleaning.

Descaling (Removing Mineral Deposits):

Mineral deposits (limescale) can build up inside the kettle, especially in areas with hard water. This can affect performance and appearance. Descale regularly:

1. Fill the kettle with 1 part white vinegar and 2 parts water.

2. Bring the mixture to a boil and let it stand for 30 minutes.
3. Discard the mixture and rinse the kettle thoroughly with fresh water.
4. For stubborn deposits, repeat the process or use a commercial descaling solution following its instructions.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Kettle does not turn on.	Not plugged in; power switch not engaged; kettle not properly seated on base.	Ensure kettle is plugged in, flip the power switch to ON, and ensure kettle is correctly placed on the power base.
Kettle turns off before boiling.	Insufficient water (boil-dry protection activated); mineral deposits.	Ensure water level is above MIN mark. Descale the kettle if mineral deposits are present.
Water tastes strange or has particles.	Mineral deposits (limescale).	Descale the kettle as per maintenance instructions.
Lid does not close properly.	Obstruction or misalignment.	Check for any obstructions. Ensure the lid is aligned correctly and press firmly until it clicks.

SPECIFICATIONS

- **Brand:** BELLA
- **Model Name:** Glass Electric Kettle
- **Model Number:** 17267
- **Capacity:** 1.7 Liters (7 Cups)
- **Power:** 1500 Watts
- **Material:** Borosilicate Glass, Plastic (BPA-Free)
- **Color:** Black
- **Special Feature:** Programmable (refers to auto shut-off), Cordless, LED Illumination
- **Product Dimensions:** 8.66"L x 6.92"W x 9.84"H
- **Item Weight:** 2.2 Pounds
- **Care Instructions:** Hand Wash
- **UPC:** 829486172670

WARRANTY AND SUPPORT

The BELLA 1.7 Liter Glass Electric Kettle comes with a 2-year warranty, ensuring peace of mind regarding its quality and performance.

For detailed information, troubleshooting, or warranty claims, please refer to the official user manual:

[Download User Manual \(PDF\)](#)