

[Manuals.plus](#) /

› [Magicshine](#) /

› Magicshine Allty Bike Light Mount Base Instruction Manual

Magicshine Allty mount base

Magicshine Allty Bike Light Mount Base

Model: Allty Mount Base

1. INTRODUCTION

The Magicshine Allty Bike Light Mount Base is a replacement or spare mounting component designed for specific Magicshine bike lights. This hard plastic base provides a secure attachment point for your light, ensuring stability during rides.

Compatibility: This mount base is compatible with Magicshine Allty series bike lights, including Allty 400, Allty 600, Allty 800, and RN 1200 models.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- 1 x Magicshine Allty Bike Light Mount Base
- 2 x Hex Screws
- 1 x Hex Allen Tool



Image: Magicshine Allty Bike Light Mount Base, including two hex screws and a hex allen tool, sealed in its clear retail packaging.

3. SAFETY INFORMATION

Always ensure the mount base and your bike light are securely attached before riding. Regularly check for any signs of wear or damage. A loose mount can lead to the light detaching, potentially causing a safety hazard or damage to the light.

4. INSTALLATION INSTRUCTIONS

Follow these steps to install the Magicshine Allty Bike Light Mount Base:

1. **Prepare the Light:** Ensure your Magicshine Allty series bike light is clean and free of debris where the mount base will attach.
2. **Position the Mount Base:** Align the new mount base with the designated screw holes on the underside of your bike light. The Garmin-style interface should face outwards.
3. **Secure with Screws:** Insert the two provided hex screws into the holes and gently tighten them using the hex allen tool. Do not overtighten, as this may damage the plastic base or the light housing. Tighten until snug and

secure.

4. **Verify Attachment:** Once tightened, gently attempt to twist or pull the mount base to ensure it is firmly attached to the light and does not wobble.



Image: A detailed view of the Magicshine Allty Bike Light Mount Base, highlighting its hard plastic construction and the standard Garmin-style quarter-turn interface for attaching compatible bike lights. Two screw holes are visible for secure attachment.



Image: This illustration shows the Magicshine Allty Bike Light Mount Base securely attached to the underside of a Magicshine bike light, demonstrating how the light connects to the mount.

5. OPERATING INSTRUCTIONS (ATTACHING LIGHT TO BIKE MOUNT)

Once the Allty Mount Base is secured to your bike light, you can attach the light to a compatible bike handlebar or helmet mount (sold separately) that features a Garmin-style quarter-turn interface.

1. **Align:** Align the tabs on the Allty Mount Base with the grooves on your bike's mount.
2. **Insert and Twist:** Gently push the light into the mount and twist it clockwise until it clicks into place.
3. **Verify Security:** Ensure the light is firmly locked into the bike mount before riding.

6. MAINTENANCE

To ensure the longevity and proper function of your mount base:

- **Cleaning:** Wipe the mount base with a damp cloth to remove dirt and grime. Avoid harsh chemicals.
- **Inspection:** Periodically inspect the mount base for cracks, wear, or damage, especially after impacts or falls.
- **Screw Tightness:** Check the tightness of the hex screws regularly to prevent loosening due to vibrations during rides.

7. TROUBLESHOOTING

Issue	Possible Cause	Solution
Mount base feels loose on the light.	Screws are not tightened sufficiently.	Use the hex allen tool to gently tighten the two hex screws until snug. Do not overtighten.
Light does not securely attach to the bike mount.	Incorrect alignment or incompatible bike mount.	Ensure the light's mount base is correctly aligned with the bike mount's grooves. Verify your bike mount uses a Garmin-style quarter-turn interface.
Mount base is cracked or damaged.	Physical impact or material fatigue.	Replace the mount base immediately to prevent loss of the bike light.

8. SPECIFICATIONS

Feature	Detail
Product Type	Bike Light Mount Base
Material	Hard Plastic
Compatibility	Magicshine Allty 400, 600, 800, and RN 1200 models
Mounting Style	Garmin-style Quarter-Turn Interface
Included Tools	Hex Allen Tool
Item Package Dimensions	4.8 x 2.48 x 0.16 inches
Package Weight	0.01 Kilograms

9. WARRANTY AND SUPPORT

Magicshine products are designed for durability and performance. For warranty information or technical support, please contact Magicshine customer service.

Contact Information:

Email: amazon@magicshine.com

For additional support and product information, visit the official Magicshine store on Amazon [Magicshine Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question