

ACTIVISION A350 Pro

ACTIVISION Blizzard A350 Pro Webcam

User Instruction Manual

1. INTRODUCTION

Thank you for choosing the ACTIVISION Blizzard A350 Pro Webcam. This high-quality webcam is designed to provide clear 2560x1440 (QHD) resolution video for your communication and content creation needs. This manual provides essential information for setting up, operating, and maintaining your device.

Please read this manual thoroughly before using the product and retain it for future reference.

2. SAFETY INFORMATION

- Do not expose the webcam to water or excessive moisture. This product is not waterproof.
- Avoid dropping or subjecting the webcam to strong impacts.
- Do not attempt to disassemble or modify the webcam. This may void your warranty and cause damage.
- Keep the webcam away from extreme temperatures and direct sunlight.
- Clean the lens with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x ACTIVISION Blizzard A350 Pro Webcam with integrated clip support

4. SETUP

4.1 Physical Installation

1. **Unfold the Clip:** Gently unfold the integrated clip support at the base of the webcam.
2. **Position the Webcam:** Place the webcam on top of your computer monitor, laptop screen, or a flat surface. The clip is designed to securely grip the edge of your display.
3. **Adjust the Angle:** Tilt the webcam up or down to achieve your desired viewing angle.



Image 1: Blizzard A350 Pro Webcam with its integrated clip support, positioned on a laptop screen. The webcam features a black finish and a compact design, ready for use.

4.2 Connecting to Your Computer

1. **Connect USB Cable:** Plug the USB cable from the webcam into an available USB port on your computer, laptop, or tablet.
2. **Automatic Driver Installation:** The webcam is plug-and-play. Your operating system (Windows, macOS, Linux) should automatically detect and install the necessary drivers. This process may take a few moments.
3. **Verification:** Once installed, the webcam will be ready for use with compatible applications. You can verify its installation in your device manager or system settings.

5. OPERATING THE WEBCAM

5.1 Basic Usage

After successful installation, you can use your Blizzard A350 Pro Webcam with various video conferencing, streaming, and recording applications.

- **Select Webcam:** In your chosen application (e.g., Zoom, Skype, OBS Studio), navigate to the video settings and select "Blizzard A350 Pro Webcam" as your video input device.
- **Adjust Settings:** Most applications allow you to adjust resolution, brightness, contrast, and other video settings. The A350 Pro supports up to 2560x1440 (QHD) resolution.

5.2 Manual Focus

The Blizzard A350 Pro Webcam features manual focus. To adjust the focus:

- Gently rotate the lens ring on the front of the webcam until your image appears sharp and clear.

5.3 Low Light Feature

The webcam is equipped with a low light feature to enhance video quality in dimly lit environments. This feature is typically automatically managed by the webcam's internal processing, but some applications may offer manual adjustments for low light compensation.

6. MAINTENANCE

- **Cleaning the Lens:** Use a soft, lint-free cloth (e.g., a microfiber cloth) to gently wipe the webcam lens. Do not use liquid cleaners or abrasive materials.
- **Cleaning the Body:** Wipe the body of the webcam with a slightly damp cloth if necessary, then dry immediately with a soft cloth.
- **Storage:** When not in use, store the webcam in a clean, dry place, away from dust and extreme temperatures.

7. TROUBLESHOOTING

Problem	Possible Solution
Webcam not detected	• Ensure the USB cable is securely plugged into both the webcam and the computer. • Try a different USB port on your computer. • Restart your computer. • Check your operating system's device manager to see if the webcam is listed.
No image or black screen	• Ensure the webcam is selected as the video input in your application settings. • Check if any privacy settings on your operating system are blocking webcam access. • Close other applications that might be using the webcam.
Poor image quality / Blurry image	• Adjust the manual focus ring on the webcam lens. • Ensure there is adequate lighting in your environment. • Clean the webcam lens with a soft, dry cloth. • Check the resolution settings in your application; ensure it's set to 1440p or QHD for best quality.

8. SPECIFICATIONS

Feature	Detail
Model Name	A350 Pro Webcam
Brand	ACTIVISION
Maximum Display Resolution	2560x1440 (QHD)
Video Recording Resolution	1440p
Connectivity Technology	USB
Focus Type	Manual Focus
Special Feature	Low Light Enhancement
Compatible Devices	Computer, Laptop, Tablet

Feature	Detail
Aspect Ratio	16:9
Supported Image Format	JPEG
Dimensions (L x W x H)	3 x 15 x 5.5 cm
Weight	220 grams
Color	Black

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official ACTIVISION support website. Keep your proof of purchase for warranty claims.

© 2026 ACTIVISION. All rights reserved. Blizzard A350 Pro Webcam.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question