

Young AKB74915324

Young AKB74915324 Replacement Remote Control User Manual

For LG Smart LED LCD TVs

1. INTRODUCTION

This manual provides instructions for the Young AKB74915324 Replacement Remote Control, designed for use with various LG Smart LED LCD TV models. This remote control offers a direct replacement solution, requiring no complex programming or pairing. Simply insert batteries to begin operation.

Compatible LG TV Models include:

- 32LH604V, 43LH590V, 49LH590V, 65UH625V
- 43UH610V, 50UH635V, 40UH630V, 43LH604V, 49LH604V, 55UH605V
- 32LH590, 32LH6047, 32LH604, 40UH630, 43LH590, 43LH6047, 43LH604, 43LH615, 43LH630, 43UH603, 43UH6107, 43UH6109, 43UH610, 43UH6207, 43UH65, 43UH6509, 43UH650, 43UH661
- 49LH590, 49LH6047, 49LH604, 49LH615, 49LH630, 49UH603, 49UH603V, 49UH6107, 49UH6109, 49UH610, 49UH6207, 49UH620, 49UH6507, 49UH6509, 49UH650, 49UH661
- 50UH635, 55LH6047, 55LH604, 55LH615, 55LH630, 55UH605, 55UH6157, 55UH6159, 55UH615, 55UH6257, 55UH625, 55UH6507, 55UH6509, 55UH650, 55UH661, 55UH635, 58UH635
- 60UH605, 60UH6157, 60UH615, 60UH6257, 60UH625, 60UH6507, 60UH650, 60UH6157, 65UH6159, 65UH615, 65UH6257, 65UH625, 65UH6507, 65UH6509, 65UH650, 65UH661

2. SAFETY INFORMATION

- **Battery Safety:** Always use new, high-quality AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote will not be used for an extended period to prevent leakage. Dispose of used batteries responsibly according to local regulations.
- **Handling:** Avoid dropping the remote control or exposing it to extreme temperatures, humidity, or direct sunlight. Do not attempt to disassemble or modify the remote control.

3. PACKAGE CONTENTS

- 1 x Young AKB74915324 Replacement Remote Control

4. SETUP

4.1 Battery Installation

The remote control requires two (2) AAA alkaline batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Rear view of the remote control with the battery cover removed, revealing the two AAA battery slots. Once batteries are installed, the remote control is ready for immediate use with compatible LG TVs. No programming or pairing is required.

5. OPERATING INSTRUCTIONS

Point the remote control directly at your LG TV's infrared receiver. Ensure there are no obstructions between the remote and the TV.

5.1 Button Layout



Image: Front view of the Young AKB74915324 remote control, displaying its full button layout.

5.2 Key Functions

- **Power Button** (): Turns the TV on or off.
- **Number Buttons (0-9)**: Directly select TV channels.
- **LIST**: Displays the channel list.
- **GUIDE**: Accesses the electronic program guide.
- **INFO**: Displays information about the current program.
- **P PAGE (Page Up/Down)**: Navigates through pages or channel lists.
- **Volume Up/Down (+/-)**: Adjusts the TV volume.
- **Mute ()**: Mutes or unmutes the TV sound.
- **Channel Up/Down (▲/▼)**: Changes TV channels.
- **Navigation Buttons (◀ ▲ ▼ ▶)**: Navigate through menus and options.
- **OK Button**: Confirms selections in menus.
- **BACK**: Returns to the previous screen or menu.
- **EXIT**: Exits the current menu or application.
- **LIVE MENU**: Accesses the Live Menu.
- **TEXT**: Opens Teletext.
- **AD**: Audio Description button.
- **REC/***: Record button.
- **Colored Buttons (Red, Green, Yellow, Blue)**: Functionality varies depending on the TV model and current screen content.

6. MAINTENANCE

6.1 Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's surface or internal components.

6.2 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Follow the battery installation steps outlined in Section 4.1.

7. TROUBLESHOOTING

- **Remote not working:**
 - Ensure new AAA alkaline batteries are correctly installed with proper polarity.
 - Check if the remote control is pointed directly at the TV's infrared receiver.
 - Remove any obstructions between the remote and the TV.
 - Verify that the TV is powered on.
- **Specific buttons not responding:**
 - This remote is a direct replacement and should function identically to the original AKB74915324 remote. If a specific button does not work, ensure your TV model is listed in the compatibility section.
 - Try replacing the batteries, even if other buttons seem to work.


8. SPECIFICATIONS

Feature	Detail
Model Number	AKB74915324 (YY-AKB74915324)
Brand	Young
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Power Source	2 x AAA Alkaline Batteries (not included)
Product Dimensions	6.69 x 1.77 x 0.47 inches (17 x 4.5 x 1.2 cm)
Item Weight	4 ounces (approx. 113 grams)
Special Feature	Ergonomic Design
Compatible Devices	LG Smart LED LCD Televisions (specific models listed in Introduction)

9. SUPPORT

For further assistance or if you encounter issues not covered in this manual, please contact the seller or manufacturer directly. Refer to your purchase documentation for contact information.

Related Documents - AKB74915324

	<p>R.M. Young Model 26800 Meteorological Translator: Instructions and Specifications</p> <p>Comprehensive instruction manual for the R.M. Young Model 26800 Meteorological Translator, detailing its features, operation, programming, and technical specifications for meteorological data acquisition.</p>
	<p>Smart IR Remote with Temperature & Humidity Display (Model S16) - User Guide</p> <p>Comprehensive user manual for the Model S16 Smart IR Remote, featuring temperature and humidity sensing. Learn how to set up, configure, and use its functions like smart scenarios, remote control, scheduling, and voice assistant integration.</p>
	<p>Manuale Utente De'Longhi Pinguino Compact ES72 YOUNG: Guida Completa</p> <p>Manuale utente completo per il condizionatore portatile De'Longhi Pinguino Compact ES72 YOUNG. Trova istruzioni dettagliate su installazione, funzionamento, manutenzione e risoluzione dei problemi per un uso ottimale.</p>
	<p>RECARO Young Sport & Young Sport HERO: Installation and Use Manual</p> <p>Comprehensive guide for RECARO Young Sport and Young Sport HERO child car seats, detailing installation, usage for ECE Groups I-III (9-36 kg), safety features, cleaning, and maintenance. Learn how to ensure optimal protection for your child with RECARO's expertise.</p>
	<p>AROMACONNECT Wake-Up Light Diffuser: Operational Manual</p> <p>This operational manual provides detailed instructions and setup guides for the Young Living AROMACONNECT Wake-Up Light Diffuser, covering features like light, sound, misting, and routine settings.</p>
	<p>Kurzweil Mark-Pro ONEi Dijital Piyanonuzun Kullanım Kılavuzu</p> <p>Kurzweil Mark-Pro ONEi dijital piyanonuzun özelliklerini, kurulumunu ve tüm fonksiyonlarını öğrenin. Bu kullanım kılavuzu, enstrümanınızı en iyi şekilde kullanmanız için rehberlik eder.</p>

no relevant documents