

Manuals.plus /

› HealSmart /

› HealSmart 14-Inch 3-Speed Floor Fan User Manual

HealSmart HIFANXFLOOR14PLATICEXPV2

HealSmart 14-Inch 3-Speed Floor Fan User Manual

Model: HIFANXFLOOR14PLATICEXPV2

Brand: HealSmart

INTRODUCTION

Thank you for choosing the HealSmart 14-Inch 3-Speed Floor Fan. This manual provides important information regarding the safe operation, assembly, maintenance, and troubleshooting of your new fan. Please read this manual thoroughly before use and retain it for future reference.

This high-velocity floor fan is designed to provide powerful and efficient air circulation for various indoor environments, including bedrooms, kitchens, and living rooms. Its compact design and robust features make it a versatile cooling solution.




Figure 1: Front view of the HealSmart 14-Inch 3-Speed Floor Fan. This image displays the fan's black plastic housing, protective grill, and central fan blades.

SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always observe the following safety precautions:

- This fan is designed for **indoor use only**. Do not use outdoors or in wet locations.
- Ensure the voltage used does not exceed the maximum allowable voltage of **120V**.
- Always unplug the fan from the power outlet before cleaning, servicing, or moving it.
- Do not operate any fan with a damaged cord or plug. If the cord or plug is damaged, contact qualified service personnel.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area where it will not be tripped over.

- Do not insert fingers or foreign objects into any ventilation or exhaust opening.
- Do not block air openings or operate near curtains or other materials that may block airflow.
- Close supervision is necessary when any appliance is used by or near children.
- Do not use this fan in areas where gasoline, paint, or flammable liquids are used or stored.

PACKAGE CONTENTS

Upon opening the package, please verify that all components are present and undamaged:

- HealSmart 14-Inch Floor Fan Unit
- Fan Stand/Feet (2 pieces)
- Instruction Manual (this document)

SETUP AND ASSEMBLY

Your HealSmart floor fan is designed for quick and easy assembly. Follow these steps to set up your fan:

1. Carefully remove all components from the packaging.
2. Identify the main fan unit and the two separate stand/feet components.
3. Align each stand/foot with the corresponding slots on the bottom of the fan unit.
4. Gently push and slide the stand/feet into place until they securely click or fit snugly. Ensure both feet are firmly attached to provide a stable base for the fan.
5. Place the assembled fan on a flat, stable surface.



Figure 2: The fan unit shown with its two detachable base components, illustrating the simple assembly process. Assembly should take approximately 5 minutes.

OPERATING INSTRUCTIONS

The HealSmart 14-Inch Floor Fan features a simple control system for ease of use.

Power and Speed Control

1. Plug the fan's power cord into a standard 120V AC electrical outlet.
2. Locate the rotary control knob, typically found on the side or back of the fan unit.
3. Turn the knob clockwise to select your desired speed setting:
 - **0:** Off
 - **1:** Low Speed
 - **2:** Medium Speed

- **3: High Speed**



Figure 3: Detail of the fan's rotary control knob for power and speed selection (0-3) and the integrated carry handle.

Adjusting Airflow Direction (Tilt)

The fan head can be tilted to direct airflow precisely where needed. Simply grasp the fan housing firmly and gently tilt it up or down to the desired angle. The fan will remain in the set position.



Figure 4: Side view of the fan demonstrating its adjustable tilt feature, allowing users to direct airflow upwards or downwards.



Figure 5: Visual representation of the fan's three speed settings (Low, Mid, High) and their corresponding airflow intensity.

MAINTENANCE AND CLEANING

Regular cleaning will help maintain your fan's performance and extend its lifespan. Always unplug the fan before cleaning.

- **Exterior Cleaning:** Use a soft, damp cloth to wipe down the exterior surfaces of the fan. Do not use abrasive cleaners or solvents, as they may damage the plastic.
- **Blade Cleaning:** Dust and debris can accumulate on the fan blades and grill over time. For general cleaning, use a vacuum cleaner with a brush attachment to remove dust from the grill and blades. For more thorough cleaning, the fan grill may be carefully removed (refer to assembly instructions in reverse if necessary, or consult the manufacturer for specific disassembly guidance). The plastic blades can be hand washed with mild soap and water once removed. Ensure all parts are completely dry before reassembling and operating the fan.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

TROUBLESHOOTING

If you encounter issues with your HealSmart floor fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power to the unit.	Ensure the power cord is securely plugged into a working 120V outlet. Check the circuit breaker.
Weak or no airflow.	Fan speed setting is too low; obstructions blocking airflow.	Increase the speed setting using the control knob. Remove any objects blocking the front or rear grills.
Fan makes unusual noise.	Loose parts; fan not on a stable surface; debris in blades.	Ensure all parts are securely assembled. Place the fan on a flat, stable surface. Unplug and check for any debris caught in the blades or grill.
Plastic odor during initial use.	New product odor.	This is normal for new plastic appliances and should dissipate after a few hours of use in a well-ventilated area.

If the problem persists after attempting these solutions, please contact HealSmart customer service for further assistance.

SPECIFICATIONS

Feature	Specification
Brand	HealSmart
Model Name	HIFANXFLOOR14PLATICEXPV2
Electric Fan Design	Floor Fan
Color	Black
Size	14-Inch Diameter
Product Dimensions	6"D x 17"W x 17"H
Item Weight	5.84 pounds
Power Source	Corded Electric
Voltage	120 Volts
Number of Power Levels	3
Control Method	Touch (Rotary Knob)
Blade Material	Plastic
Number of Blades	3
Indoor/Outdoor Usage	Indoor
Assembly Required	Yes
UPC	840166221242

WARRANTY AND SUPPORT

Specific warranty information for the HealSmart 14-Inch 3-Speed Floor Fan was not provided in the available product data. For details regarding warranty coverage, returns, or technical support, please contact HealSmart customer service directly or visit their official website.

Please retain your purchase receipt as proof of purchase for any warranty claims.

© 2024 HealSmart. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question