Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Snailax 498

Snailax Cordless Handheld Percussion Massager with Heat (Model 498) User Manual

Model: 498

Introduction

This manual provides essential information for the safe and effective operation of your Snailax Cordless Handheld Percussion Massager with Heat. Please read all instructions carefully before use and retain this manual for future reference.

Important Safeguards

To reduce the risk of electric shock, burns, fire, or injury, observe the following precautions:

- Always unplug the appliance from the electrical outlet immediately after using and before cleaning.
- Do not use without massage heads when activating the heating function; ensure red heat nodes are exposed.
- Avoid using the massager in wet conditions or near water.
- Ensure proper body positioning and usage techniques as described in this manual.
- Consult a physician before use if you have certain medical conditions, including but not limited to pregnancy, heart disease, diabetes, or if you have a pacemaker.
- Do not use on open wounds, swollen areas, or areas of skin irritation.
- Keep out of reach of children.

Product Components

The Snailax Cordless Handheld Percussion Massager is designed for deep tissue massage with an optional heat function. It features a long handle for easy reach and dual pivoting massage heads.



Image: The Snailax Cordless Handheld Percussion Massager, showing its ergonomic design, dual massage heads with red heat elements, and the various interchangeable massage heads.

Interchangeable Massage Heads

The massager includes three sets of interchangeable massage heads to customize your massage experience for different muscle groups and preferences:

- **Deep Shiatsu Massage Head:** Provides a concentrated, kneading massage.
- **Acupuncture Massage Head:** Offers a stimulating, point-focused massage.
- **Triangular Massage Head:** Designed for broader coverage and gentle stimulation.



Image: Illustration of the three distinct types of interchangeable massage heads included with the Snailax massager, each designed for different massage sensations and applications.

Setup

Charging the Device

The massager is equipped with a built-in rechargeable lithium-ion battery. Before first use, fully charge the device. A full charge provides approximately 80 minutes of operation.

1. Connect the charging adapter to the massager's power inlet.
2. Plug the adapter into a standard electrical outlet.
3. The charging indicator light will illuminate. Once fully charged, the light may change color or turn off depending on the model.



Image: Visual representation of the massager's long-lasting charge capability, highlighting 80 minutes of use per charge and a 15-minute auto shut-off for safety.

Attaching Massage Heads

To change or attach a massage head, align the desired head with the pivoting massage nodes and gently push until it clicks into place. To remove, pull the head off firmly.

Operating Instructions

The massager features an integrated control panel on the handle for easy operation.



Image: Detailed view of the control buttons on the massager's handle, including Power, Heat, Mode, and Intensity buttons for easy adjustment during use.

1. **Power On/Off:** Press the **Power Button** ( ) to turn the massager on or off.
2. **Adjusting Modes:** Press the **Mode Button** (M) to cycle through the 3 available percussion modes.
3. **Adjusting Intensity:** Press the **Intensity Button** (⚡) to select from 3 variable percussion speeds.
4. **Heat Function:** Press the **Heat Button** ( ) to activate or deactivate the soothing heat function.

Using the Heat Function

Important: To use the heat function, DO NOT install any massage heads. Keep the red heat nodes exposed to allow the warmth to be delivered effectively.



Image: A user demonstrating the heat function on their neck, with the massager's red heat nodes visible and no interchangeable heads attached, as required for heat activation.

Auto Timer Function

For user safety and to prevent over-massage, the device is equipped with a 15-minute auto-timer function. The massager will automatically stop after 15 minutes of continuous use. To continue your massage, simply press the power button again.

Targeted Massage Areas

The Snailax massager is suitable for various body parts, including the neck, back, shoulders, waist, calves, and legs. Move the percussion nodes to your body's knots and enjoy full body relaxation.




Image: A visual guide demonstrating how the massager can be effectively used on different areas of the body, such as the neck, back, waist, feet, and thighs.

Maintenance and Care

Proper maintenance ensures the longevity and optimal performance of your massager.

- Always turn off and unplug the massager before cleaning.
- Clean the device with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
- Do not submerge the massager in water or expose it to excessive moisture.
- Store the massager in a cool, dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter issues with your Snailax massager, refer to the following common solutions:

Problem	Possible Cause	Solution
Device fails to work	Adapter not properly connected or plugged in.	Ensure the adapter is securely plugged into both the massager's power inlet and a functional electrical socket.
Heat function not working	Massage heads are installed, or heat nodes are not exposed.	Remove all interchangeable massage heads. The heat function requires the red heat nodes to be exposed.
Massage heads detach during use	Heads not securely attached or worn.	Ensure massage heads are firmly pushed onto the pivoting nodes until they click. If heads continue to detach, they may be worn and require replacement.
Short battery life	Battery not fully charged or aging battery.	Ensure the device is fully charged before each use. If the issue persists, contact customer support.

Product Specifications

- **Model Number:** 498
- **Product Dimensions:** 14.96 x 6.3 x 5.08 inches
- **Item Weight:** 2.8 Pounds
- **Power Source:** Battery Powered (1 Lithium Ion battery included)
- **Battery Life:** Approximately 80 minutes per full charge
- **Material:** Plastic
- **Manufacturer:** Snailax
- **Date First Available:** November 18, 2020



Image: An overview of the Snailax massager package contents, including the device, charging adapter, and all interchangeable massage heads, with key dimensions highlighted.

Warranty and Support

Your Snailax Cordless Handheld Percussion Massager comes with a 2-year guarantee. Additionally, a 30-day free return policy is available for money back. For any product inquiries, technical support, or warranty claims, please contact Snailax customer service.

Please refer to the contact information provided with your product packaging or visit the official Snailax website for support details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08NT2K2CL

More documents and user manuals: **https://manuals.plus/**