Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cirbic B08NWFTVG6

Cirbic Talking Scales: User Manual

Model: B08NWFTVG6

Introduction

Thank you for choosing the Cirbic Talking Scales. This digital body weight scale is designed for ease of use, featuring a clear, loud voice announcement of your weight and a large, backlit display. It is particularly beneficial for individuals with visual impairments or the elderly. Please read this manual thoroughly before use to ensure proper operation and maintenance.

Safety Information

- Always place the scale on a hard, flat, and stable surface for accurate readings. Avoid carpets or uneven floors.
- Do not use the scale on wet or slippery surfaces to prevent falls.
- Do not immerse the scale in water or use harsh chemical cleaners.
- This scale is for personal use only and not intended for commercial or medical diagnostic purposes.
- Keep out of reach of children.
- If the scale malfunctions, do not attempt to repair it yourself. Contact customer support.

Package Contents

- Cirbic Talking Scales (Black)
- User Manual

Note: 2x AAA batteries are required and not included.

Setup

1. Battery Installation

Locate the battery compartment on the underside of the scale. Open the cover and insert two (2) AAA batteries, ensuring correct polarity (+/-). Close the battery compartment cover securely.



Image: The bottom of the scale with four circular feet, a speaker grille, a battery compartment, and a small switch labeled 'KG/LB'.

2. Unit Selection (Pounds/Kilograms)

On the underside of the scale, next to the battery compartment, you will find a small switch labeled 'KG/LB'. Slide this switch to select your preferred unit of measurement (pounds or kilograms).

3. Initial Calibration

Before first use or after moving the scale, it is recommended to calibrate it. Gently tap the center of the scale with your foot to turn it on. Wait for the display to show '0.0' and then turn off automatically. The scale is now calibrated and ready for use.

Operating Instructions

1. Taking a Measurement

1. Place the scale on a hard, flat surface.

2. Step onto the scale with bare feet, standing still and centered.
3. The scale will automatically turn on, display your weight, and announce it clearly in a North American male accent.
4. Step off the scale. The display will remain on for a few seconds before automatically turning off.



Image: The top surface of the black scale showing a digital display with '117.0 lb' illuminated in blue. The Cirbic logo is visible at the bottom.

2. Voice Announcement Feature

The scale is equipped with a loud and clear voice announcement feature, stating your weight in your selected unit. This is ideal for users who may have difficulty reading the display.

3. Backlit Display

The large LCD display features a bright backlight, ensuring your weight is easily visible even in low-light conditions.

Your browser does not support the video tag.

Video: A demonstration of the Cirbic Talking Scales in use, showing a person stepping on the scale and the weight being announced and displayed. This video highlights the clear voice and large numbers for visually impaired users.

Maintenance

Cleaning

Wipe the scale with a slightly damp cloth. Do not use abrasive cleaners or immerse the scale in water. Keep the scale dry.

Storage

Store the scale in a cool, dry place. Avoid extreme temperatures and direct sunlight.

Battery Replacement

If the display shows 'Lo' or the voice announcement becomes unclear, it's time to replace the batteries. Follow the battery installation steps in the 'Setup' section.

Troubleshooting

- **No Display/Voice:** Check battery installation and replace if necessary. Ensure the scale is on a flat surface.
- **Inaccurate Readings:** Ensure the scale is on a hard, flat, and stable surface. Perform initial calibration (step on, wait for '0.0', step off). Avoid moving the scale between measurements.
- **'Lo' on Display:** Batteries are low and need to be replaced.
- **'Err' on Display:** Indicates an overload (weight exceeds 397 lbs / 180 kg) or an error during measurement. Step off the scale and try again.

Specifications

Brand	Cirbic
Model	B08NWFTVG6
Color	Black
Dimensions	11" x 11" (approx.)
Weight Range	6.6 lbs to 397 lbs (3 kg to 180 kg)
Material	Durable 6mm thick tempered glass
Power Source	2x AAA Batteries (not included)
Display Type	Backlit LCD
Special Features	Voice Announcement, Large Numbers, Auto On/Off



Image: A side view of the black scale, highlighting its thin profile and the green tint of the tempered glass edge.

Warranty

This Cirbic Talking Scale comes with a 1-year limited warranty from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or failure to follow the instructions in this manual. Please retain your proof of purchase for warranty claims.

Support

For technical support, warranty claims, or any questions regarding your Cirbic Talking Scales, please contact our customer service team. Refer to the contact information provided with your product packaging or visit the official Cirbic website for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08NWJMY1L

More documents and user manuals: **https://manuals.plus/**