

BoxWave ClearTouch Anti-Glare

BoxWave ClearTouch Anti-Glare Screen Protector User Manual

Model: ClearTouch Anti-Glare (Compatible with Icom M220)

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, use, and maintenance of your BoxWave ClearTouch Anti-Glare Screen Protector. This product is designed to protect the screen of your Icom M220 device from scratches, smudges, and glare, while maintaining optimal screen visibility and touch responsiveness.

The ClearTouch Anti-Glare screen protector is engineered with a matte surface that disperses light, reducing reflections and improving readability in various lighting conditions. It also features an anti-fingerprint coating to keep your screen clean.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- Two (2) BoxWave ClearTouch Anti-Glare Screen Protectors
- One (1) Applicator Card
- One (1) Microfiber Cleaning Cloth
- One (1) Dust Removing Sticker

Anti-Smudge Surface

Protects Against Fingerprints



Other Brands



Image: Contents of the BoxWave ClearTouch Anti-Glare Screen Protector package, showing two screen protectors, an applicator card, a

microfiber cleaning cloth, and a dust removing sticker.

3. SETUP AND INSTALLATION

Proper installation is crucial for optimal performance. Follow these steps carefully:

1. **Prepare Your Workspace:** Choose a clean, dust-free environment. Wash your hands thoroughly to avoid transferring oils or dirt to the screen or protector.
2. **Clean the Device Screen:**
 - Use the provided microfiber cleaning cloth to gently wipe the screen of your Icom M220, removing any smudges or fingerprints.
 - If necessary, use a screen cleaner solution (not included) designed for electronics, applied to the cloth, not directly to the screen.
 - Use the dust removing sticker to lift any remaining dust particles from the screen. Ensure the screen is completely free of dust, dirt, and oils.

***ClearTouch** screen protector included accessories*



***Applicator
Card***



***Microfiber
Cleaning Cloth***



***Dust Removing
Sticker***

Image: Illustration of cleaning the device screen using a microfiber cloth and a dust removal sticker.

3. **Align the Screen Protector:**

- Carefully peel back a small portion of the protective film labeled "Step 1" or similar from one end of the screen protector. Avoid touching the adhesive side.
- Align the exposed edge of the screen protector with the corresponding edge of your Icom M220 screen. Pay close attention to cutouts for speakers, cameras, or buttons to ensure perfect alignment.

4. Apply the Screen Protector:

- Once aligned, slowly and steadily peel back the rest of the "Step 1" protective film while simultaneously pressing the screen protector onto the device screen.
- Use the applicator card to gently smooth out any air bubbles as you go. Start from the center and push bubbles towards the edges.




Image: A hand using an applicator card to smooth out a screen protector during installation, removing air bubbles.

5. **Remove Top Film:** Once the screen protector is fully adhered and free of bubbles, carefully peel off the top protective film labeled "Step 2" or similar.
6. **Final Wipe:** Use the microfiber cloth to give the newly installed screen protector a final gentle wipe.

4. OPERATING WITH THE SCREEN PROTECTOR

The BoxWave ClearTouch Anti-Glare Screen Protector is designed to integrate seamlessly with your Icom M220 device,

preserving its functionality while adding protection.

- **Touch Sensitivity:** The screen protector is engineered to maintain the original touch sensitivity of your device. You should experience no noticeable difference in responsiveness.
- **Anti-Glare Feature:** The matte finish reduces reflections from bright light sources, making your screen easier to view outdoors or under strong indoor lighting.
- **Anti-Fingerprint Surface:** The oleophobic coating helps repel oils and smudges, keeping your screen cleaner for longer.



Reduces glare for improved readability

Prevents smudges and fingerprints

Each package includes 2 ClearTouches

Designed to fit your device perfectly

BoxWave ClearTouch Anti-Glare Screen Protector

Image: A tablet screen with a screen protector, demonstrating reduced glare in a bright environment.



ClearTouch ANTI-GLARE

The specially designed diffusion surface reduces distracting glare to improve your screen's readability, from bright to low-light conditions

Distracting Glare

BoxWave ClearTouch Anti-Glare Screen Protector

Image: A visual comparison showing how the screen protector's surface resists fingerprints compared to an unprotected screen.

5. CARE AND MAINTENANCE

To ensure the longevity and effectiveness of your screen protector, follow these maintenance guidelines:

- **Cleaning:** Use the provided microfiber cloth to wipe the screen protector regularly. For stubborn smudges, slightly dampen the cloth with water or a mild, electronics-safe screen cleaner. Avoid harsh chemicals or abrasive materials.
- **Protection:** While the screen protector offers significant protection against scratches, avoid placing your device with sharp objects (e.g., keys, coins) in the same pocket or bag.
- **Replacement:** If the screen protector becomes heavily scratched, damaged, or loses its adhesive properties, it is

recommended to replace it with a new one. Your package includes two protectors for this purpose.

6. TROUBLESHOOTING

Common issues and their solutions:

Problem	Possible Cause	Solution
Air Bubbles After Installation	Dust particles trapped underneath, or uneven application.	Gently lift the nearest edge of the protector and re-apply, using the applicator card to push out bubbles. Ensure the screen is dust-free before re-application. Small bubbles may disappear over 24-48 hours.
Screen Protector Not Sticking	Oils or dirt on the screen, or adhesive damage.	Ensure the screen is thoroughly cleaned before application. If the adhesive is damaged, use the second screen protector provided.
Reduced Touch Sensitivity	Incorrect installation or a faulty protector.	Re-install the protector carefully, ensuring no air gaps. If the issue persists, contact BoxWave customer support.
Excessive Glare	Not a ClearTouch Anti-Glare protector, or extreme lighting conditions.	Verify the product is indeed the ClearTouch Anti-Glare model. While it significantly reduces glare, it may not eliminate it entirely in direct sunlight.

7. SPECIFICATIONS

Feature	Description
Product Name	ClearTouch Anti-Glare Screen Protector
Brand	BoxWave
Compatibility	Icom M220
Material	Polyethylene Terephthalate (PET)
Surface Finish	Matte, Anti-Glare, Anti-Fingerprint
UV Reduction	Reduces 90% UV rays
Package Quantity	2 Screen Protectors

8. WARRANTY AND SUPPORT

BoxWave products are designed for quality and durability. For information regarding warranty coverage or technical support, please refer to the official BoxWave website or contact their customer service directly.

Contact Information:


- **Website:** www.boxwave.com
- **Email:** Refer to website for support email.

- **Phone:** Refer to website for support phone number.

When contacting support, please have your product model (ClearTouch Anti-Glare Screen Protector for Icom M220) and purchase details ready.


© 2023 BoxWave Corporation. All rights reserved.
Product specifications are subject to change without notice.

Related Documents - ClearTouch Anti-Glare



MEL3T
GAMING

Check Blue HD Screen Protector Film



Product Content

- 1x Nano Blue HD 9H Screen Protector Film
- 1x Dust-Free Installation Kit
- 1x Cleaning Cloth

Features

- Microbial Guard**
 - Prevents your screen from harmful microbes and keeps every inspection safe.
- Blue Light Guard**
 - Protects your eyes from blue light and enhances viewing comfort.
- Crystal HD Display**
 - Ensures great perfect color with ultra-clear and vibrant visuals.
- Anti-Scratch**
 - Scratch-resistant glass resists scratches from keys, drops, and slips.
- Anti-Fingerprint**
 - Oleophobic coating repels smudges for a cleaner, clearer screen.
- Ultra Responsive**
 - Ultra-thin tempered glass for reliable and precise touchscreen sensitivity.

Installation

- Use alcohol pad remove the airbubbles and fingerprints on console.
- Then use dry screen wipe cloth to dry the surface.
- Use dust absorber to remove the dust particles.
- Lay the tray over the device screen in accurate direction.
- Roll out the roll.
- Press the mark place and wait for 3 seconds.
- Remove the tray.
- Use wipe cloth to clean the surface after remove the film completely.
If any small bubbles, use the wipe cloth across the bubble.
- Now your console is ready to use!

[MEL3T GAMING Nano Blue HD Screen Protector Film for Nintendo Switch 2 - Installation Guide](#)

Protect your Nintendo Switch 2 screen with the MEL3T GAMING Nano Blue HD Screen Protector Film. Features microbial guard, blue light filtering, anti-scratch, and anti-fingerprint properties. Includes easy installation instructions.



