Bush Furniture KWD160G2W-03

Bush Furniture Key West 60W L-Shaped Desk User Manual

Model: KWD160G2W-03

Introduction

Thank you for choosing the Bush Furniture Key West 60W L-Shaped Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: The Bush Furniture Key West 60W L-Shaped Desk in Shiplap Gray/Pure White finish, showcasing its L-shape design and X-pattern accents.

Safety Information

Please observe the following safety precautions during assembly and use:

- **Adult Assembly Required:** This product requires assembly by at least two adults.
- **Use Proper Tools:** Ensure you have a hammer and screwdriver for assembly. Do not use power tools unless specifically instructed, as over-tightening can damage components.
- **Weight Capacity:** Do not exceed the maximum weight recommendation of 200 pounds (90.7 kg) on the desk surface.

- **Stable Placement:** Place the desk on a level, stable surface to prevent tipping.
- **Component Check:** Before assembly, verify all parts are present and undamaged. Do not proceed with assembly if any parts are missing or broken.
- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Parts List

Before beginning assembly, ensure all components are accounted for. Refer to the assembly diagram (not provided in this manual, typically included with product packaging) for specific part identification.

- Desk Top Panels (L-shaped sections)
- Leg Supports with X-pattern accents
- Crossbars/Stretchers
- Hardware (screws, dowels, cam locks, etc.)




Image: Diagram highlighting key features of the desk, including the finished-on-all-sides design, attractive edge detailing, unique X-pattern

accents, and sturdy post leg design.

Setup and Assembly

Assembly of the Bush Furniture Key West L-Shaped Desk typically requires two people. Follow the step-by-step instructions provided in the product packaging for detailed guidance. The general steps involve:

1. **Unpack and Organize:** Carefully unpack all components and hardware. Lay them out on a soft, clean surface to prevent scratches.
2. **Attach Leg Supports:** Secure the leg supports to the desk top panels using the provided hardware. Ensure the X-pattern accents are correctly oriented.
3. **Connect Desk Sections:** Join the two L-shaped desk sections together, ensuring a secure and flush fit.
4. **Final Tightening:** Once all components are in place, gently tighten all screws and fasteners. Do not overtighten.
5. **Positioning:** Carefully lift and place the assembled desk in its desired location.



Image: A close-up view of the distinctive X-pattern accent on the side panel of the desk, a key design element.




Image: A detailed view of the sturdy post leg design at the base of the desk, showing its tapered shape.

Operating (Usage)

The Key West 60W L-Shaped Desk is designed for versatile use in a home office environment. Its spacious surface provides ample room for:

- **Computer Work:** Accommodates monitors, keyboards, and other peripherals.
- **Writing and Study:** Provides a comfortable area for paperwork, reading, and studying.
- **Gaming:** Offers sufficient space for gaming setups.

The reversible design allows for flexible placement in various room layouts, making it suitable for corner or open-space configurations.

Care and Maintenance

To ensure the longevity and appearance of your Bush Furniture Key West L-Shaped Desk, follow these care instructions:

- **Cleaning:** Wipe the desk surfaces with a damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.

- **Heat and Moisture:** Protect the surface from direct heat and excessive moisture. Use coasters for drinks and heat pads for hot items.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration over time.
- **Moving:** When moving the desk, always lift it rather than dragging it to prevent damage to the legs and frame.

Troubleshooting

If you encounter any issues with your desk, consider the following common solutions:

- **Wobbling Desk:**
  - Ensure the desk is placed on a level surface.
  - Check that all assembly hardware (screws, cam locks) are securely tightened. Do not overtighten.
- **Damaged Surface:**
  - For minor scratches, furniture repair kits or markers matching the finish may be used.
  - For significant damage, contact customer support for replacement part options.
- **Missing Hardware:**
  - Double-check all packaging materials.
  - Contact Bush Furniture customer support for replacement parts.

Specifications

Key technical specifications for the Bush Furniture Key West 60W L-Shaped Desk:

Feature	Detail
Brand	Bush Furniture
Model Number	KWD160G2W-03
Product Dimensions (D x W x H)	26.77"D x 24.02"W x 42.91"H (Overall)
Item Height	30 inches
Item Weight	90.3 Pounds
Color	Shiplap Gray/Pure White
Style	Farmhouse/Cottage
Base Material	Particle Board/Chipboard, Manufactured Wood
Top Material Type	Engineered Wood

Feature	Detail
Maximum Weight Recommendation	200 Pounds
Required Assembly	Yes
Recommended Number of People for Assembly	2
Product Care Instructions	Wipe with Damp Cloth




Image: Technical diagram showing the dimensions of the L-shaped desk, including overall length, depth, and height in both inches and centimeters.

Warranty Information

The Bush Furniture Key West 60W L-Shaped Desk is backed by the Bush Furniture **1 Year Manufacturer's Limited Warranty**. This warranty covers defects in materials and workmanship under normal use. Please refer to the warranty documentation included with your product for full terms and conditions, or visit the Bush Furniture official website for more details.

Customer Support

For assistance with assembly, missing parts, or any other inquiries regarding your Bush Furniture Key West L-Shaped Desk, please contact Bush Furniture customer support. You can find contact information on the Bush Furniture official website or through the retailer where you purchased the product.

You can also visit the official Bush Furniture store on Amazon for more information and related products: Bush Furniture Amazon Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question