

[Manuals.plus](#) /

› [PowerLocus](#) /

› PowerLocus PLX True Wireless In-Ear Earbuds User Manual

PowerLocus B08NYVYMLX

PowerLocus PLX True Wireless In-Ear Earbuds User Manual

INTRODUCTION

Thank you for choosing PowerLocus PLX True Wireless In-Ear Earbuds. This manual provides essential information on how to set up, operate, and maintain your new earbuds to ensure optimal performance and longevity. Please read this guide thoroughly before using the product.

The PowerLocus PLX earbuds offer freedom of movement with a stable, ergonomic fit, active noise cancellation for immersive audio, and intuitive touch controls. They feature automatic pairing and a built-in microphone for clear communication.

FOCUS ON YOUR SOUND

NOISE CANCELLING WIRELESS EARBUDS



This image illustrates the noise-cancelling feature of the PowerLocus PLX wireless earbuds, designed to help users focus on their audio by reducing ambient distractions.

WHAT'S IN THE BOX

- 2x PowerLocus PLX True Wireless Earbuds
- 1x Charging Case
- 1x USB-C Charging Cable
- 1x PowerLocus Card (Warranty/Information)

SPECIFICATIONS

Bluetooth Version	5.0
Audio Driver	13mm

Charging Interface	USB-C
Battery Playtime (Earbuds)	Up to 4 hours per charge
Total Playtime (with Case)	Up to 44 hours
Water Resistance	Waterproof (Sweat & Rain Resistant)
Wireless Range	Up to 10 meters (33 feet)
Microphone Sensitivity	42dB ±3DB
Bluetooth Profiles	HSP, HFP, A2DP, AVRCP
Impedance	32 Ohm
Sound Control	Active Noise Cancellation
Control Method	Touch
Compatible Devices	iOS, Android, Windows, Mac (iPhone, iPad, Samsung, PC, Smartphones, Macbook)

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging port on the case and plug the other end into a USB power source (e.g., wall adapter, computer USB port).

- The charging case provides up to 40 hours of additional battery life.
- Each earbud offers approximately 4 hours of playtime on a single charge.



This image illustrates the battery life of the PowerLocus PLX earbuds, providing 4 hours of playback on a single charge and an additional 40 hours from the charging case. It also highlights the USB-C fast charging capability.



This image provides a close-up view of the PowerLocus PLX charging case, clearly showing the USB-C charging port and the accompanying USB-C cable, which is used for recharging the case and earbuds.


2. Automatic Pairing

The PowerLocus PLX earbuds are designed for effortless pairing:

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, computer), go to the Bluetooth settings.
3. Select "PowerLocus PLX" from the list of available devices to connect.
4. Once connected, the earbuds are ready for use.

EFFORTLESS PAIRING

Just open the case to automatically power on and pair



This image demonstrates the automatic pairing feature of the PowerLocus PLX earbuds. Simply open the case, and the earbuds will automatically power on and connect to your device, as shown with a smartphone displaying a music app.

OPERATING THE EARBUDS

Wearing Comfort

The earbuds are ergonomically designed to ensure a stable and comfortable fit for extended periods. Insert them gently into your ears and adjust for a snug seal to optimize sound quality and noise cancellation.



TESTED ON THOUSANDS EARS

WEARING COMFORT

Ergonomically designed to ensure
a comfortable fit

This image highlights the ergonomic design of the PowerLocus PLX earbuds, engineered for comfortable wear. An inset diagram shows how the earbud is shaped to fit securely and comfortably in the ear, tested for various ear types.

Touch Controls

The PowerLocus PLX earbuds feature intuitive touch controls on each earbud for easy management of your audio and calls:

- **Play/Pause:** Single tap on either earbud.
- **Skip Tracks:** Double tap on the right earbud for next track, double tap on the left earbud for previous track.
- **Answer/End Call:** Single tap on either earbud during an incoming call or active call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud.

Mono and Stereo Mode

You can use both earbuds together for a stereo audio experience or use a single earbud independently in mono mode. This is useful for calls or when you need to be aware of your surroundings.

USE MONO AND STEREO

🎤 BUILT-IN MICROPHONES FOR CLEAR SPEECH



This image shows the flexibility of the PowerLocus PLX earbuds, allowing use in both mono and stereo modes. A man is depicted using a single earbud while working, emphasizing the built-in microphones for clear speech during calls or work.

MAINTENANCE

Cleaning

Regularly clean your earbuds and charging case to maintain optimal performance and hygiene. Use a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.

Water Resistance

The PowerLocus PLX earbuds are designed to be sweat and rain resistant, making them suitable for workouts and outdoor activities. However, they are not intended for submersion in water. Ensure the charging port is dry before charging.



This image demonstrates the durability of the PowerLocus PLX earbuds, highlighting their sweat and rain resistant design. The earbuds are suitable for outdoor activities and workouts, even in challenging weather conditions.

Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store the case in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

- **Earbuds not pairing:** Ensure both earbuds are charged. Place them back in the case, close it, then open it again to re-initiate pairing mode. Check your device's Bluetooth settings and try reconnecting.
- **No sound from one earbud:** Ensure both earbuds are charged and properly connected. Try placing them back in the case and taking them out again. If the issue persists, try resetting the earbuds (refer to manufacturer's website for specific reset instructions if needed).
- **Charging issues:** Verify the USB-C cable is securely connected to both the case and the power source. Ensure the

charging port is clean and free of debris. Try a different USB-C cable or power adapter.

- **Poor sound quality:** Ensure the earbuds are properly seated in your ears for a good seal. Check that the audio source volume is adequate. Clean any earwax or debris from the earbud nozzles.

WARRANTY AND SUPPORT

PowerLocus stands behind its products. Your PowerLocus PLX True Wireless In-Ear Earbuds come with a **24-month product warranty** from the date of purchase.

For any questions, technical support, or warranty claims, please contact PowerLocus customer support. Refer to the PowerLocus card included in your packaging for specific contact details or visit the official PowerLocus website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question