LIVINGbasics B08P1B2QR6

LIVINGbasics 3-in-1 Baby High Chair Instruction Manual

Model: B08P1B2QR6

Introduction



Figure 1: Overview of the LIVINGbasics 3-in-1 Baby High Chair. This image displays the high chair in its upright, assembled configuration, showcasing its design and features.

This manual provides comprehensive instructions for the safe assembly, operation, maintenance, and troubleshooting of

your LIVINGbasics 3-in-1 Baby High Chair. Please read this manual thoroughly before use and retain it for future reference to ensure proper and safe use of the product.

Important Safety Information

Always ensure your child is securely fastened in the 5-point harness. Never leave your child unattended in the high chair. Ensure the high chair is placed on a flat, stable surface. Do not use if any parts are damaged or missing. This high chair is suitable for babies aged 7-36 months, with a maximum child weight of 15kg (33 lbs).
The high chair has been approved by certification of EN-14988: 2017, ensuring compliance with European safety standards for children's high chairs.



Figure 2: Baby in High Chair. This image shows a baby comfortably seated in the high chair, demonstrating its intended use and the appropriate age range for safe operation (7-36 months).

Setup and Assembly

Assembly of the LIVINGbasics 3-in-1 Baby High Chair is designed to be straightforward, typically taking less than 10 minutes. Follow the steps below for proper setup.

1. Unpack all components and verify against the parts list (refer to product packaging for a complete list).
2. Assemble the main frame by connecting the legs securely. Ensure all locking mechanisms click into place.
3. Attach the seat unit to the frame, ensuring it is firmly seated.
4. Install the food tray onto the designated slots.
5. Confirm all connections are firm and stable before placing a child in the chair.



Figure 3: High Chair Dimensions. This image illustrates the overall dimensions of the high chair, including height, width, and depth, in both assembled and folded states, providing a visual guide for space requirements.



Figure 4: Fast Folding Design. This image demonstrates how to fold the high chair for compact storage and easy transportation. It highlights the buttons on both sides to initiate the folding mechanism and shows the chair in its folded state, suitable for small spaces or car trunks.



Figure 5: Easy Movement Feature. This image highlights the integrated wheels on the rear legs of the high chair, designed to facilitate easy movement and repositioning of the chair without lifting.

Operating Instructions

The LIVINGbasics 3-in-1 Baby High Chair offers multiple adjustment options to ensure comfort and adaptability as your child grows.

Height Adjustment

The high chair features 6 adjustable seat height positions, allowing it to be adapted to various dining table heights. Locate the height adjustment buttons on the side of the chair and press them to raise or lower the seat to the desired position. Ensure both sides are adjusted evenly and securely locked.



Figure 6: 6 Adjustable Heights. This image illustrates the six different height settings for the high chair, showing how the seat can be raised or lowered to match various table heights, ensuring a comfortable fit for your child.

Reclining Position Adjustment

The seat offers 3 reclining positions for your child's comfort, suitable for feeding or resting. Adjust the recline by using the mechanism located on the back of the seat. Ensure the seat is securely locked into the chosen recline position.



Figure 7: Adjustable Design. This image highlights the adjustable features of the high chair, including the recline positions for the seat back and the adjustable footrest, allowing for customized comfort for the child.

Food Tray Adjustment

The food tray has 3 adjustable positions to accommodate your child's size and provide easy access. It also features a split design with a removable top plate for easy cleaning.



Figure 8: Split Dinner Plate. This image showcases the two-part food tray, with a removable top plate made of food-grade PP material, designed for easy cleaning and direct contact with food. It also shows the tray's adjustability.

Footrest Adjustment

The footrest can be adjusted to 3 positions to provide proper support for your child's feet as they grow, promoting comfortable posture during meals.

Safety Harness

Always secure your child using the 5-point harness belt. This harness provides 360° protection and can be adjusted to two positions for longer use as your baby grows. Ensure the harness is snug but comfortable.



Figure 9: 5-Point Harness Belt. This image details the 5-point safety harness system, emphasizing its 360° protection and adjustable nature to accommodate a growing child, ensuring secure seating during meal times.

Storage Basket

A unique storage basket is integrated into the design, useful for holding baby's toys or feeding supplies, keeping them conveniently accessible.



Figure 10: Storage Basket and Fall Prevention. This image shows the integrated mesh storage basket for baby supplies and highlights the non-slip fall guard feature located under the tray, designed to prevent the baby from sliding down.

Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your high chair and ensure hygiene for your child.

- **Tray Cleaning:** The one-hand detachable tray and food-grade PP tray cover are dishwasher safe for thorough cleaning. Alternatively, they can be washed by hand with warm, soapy water.
- **Fabric Cleaning:** The premium fabric seat can be quickly wiped clean with a damp cloth. For stubborn stains, use a mild soap solution and water. Allow to air dry completely before re-use.
- **Frame Cleaning:** The elliptical thickened steel pipe frame is covered with lacquer, making it anti-fouling, rust-proof, and easy to clean. Wipe down with a damp cloth as needed. Avoid abrasive cleaners.
- **General Inspection:** Periodically check all screws, bolts, and connections to ensure they are tight and secure. Inspect the harness for any signs of wear, fraying, or damage. Replace damaged parts immediately.

Troubleshooting

This section addresses common concerns you might encounter with your high chair and provides guidance for resolution.

- **Harness Adjustment Issues:** If the arm straps do not sit correctly on your child's shoulders, ensure they are threaded through the appropriate slots for your child's size and adjusted for a snug fit. The harness offers two adjustable positions for growing babies.
- **Cleaning Difficulties in Crevices:** While the design aims for easy cleaning, some tight spots, particularly under the protective seat, may require a small brush or cotton swab for thorough cleaning. Ensure all food debris is removed to prevent accumulation.
- **Protective Seat Cracking:** The protective seat is designed for durability. If you observe any cracking or significant wear, discontinue use of the affected part and contact customer support for assistance or replacement parts.
- **Chair Instability:** Ensure the high chair is fully unfolded and all locking mechanisms are engaged. Always place the chair on a flat, level, and stable surface. The pyramid-shaped design and non-slip legs are engineered to provide maximum stability.

Specifications

Feature	Detail
Product Dimensions (L x W x H)	40.64 x 50.8 x 106.68 cm (16 x 20 x 42 inches)
Item Weight	7.7 kg (17 lbs)
Maximum Weight Recommendation	15 kg (33 Pounds)
Material Type	Alloy Steel (frame), Food Grade PP (tray), Premium Fabric (seat cushion)
Age Range (Description)	7-36 months
Adjustable Seat Height	6 positions
Adjustable Reclining Position	3 positions
Adjustable Food Tray	3 positions, removable top plate
Adjustable Footrest	3 positions
Safety Harness	5-point harness
Portability	Foldable design, wheels on rear legs
Assembly Required	Yes
Certification	EN-14988: 2017



Figure 11: Sturdy & Stable Design. This image highlights the robust construction of the high chair, featuring a pyramid-shaped design for maximum stability, 38mm x 22mm oval thickened steel tubes, and one-piece non-slip legs, ensuring safety and durability.

Warranty and Support

For information regarding warranty coverage, product support, or to purchase replacement parts, please contact LIVINGbasics customer service. Refer to the product packaging or the official LIVINGbasics website for current contact details.

Manufacturer: LIVINGbasics

Place of Business: Lachine, Quebec H8T 2Y3, CA

© 2025 LIVINGbasics. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question