Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SENSEA 3276000700395

SENSEA Remix Oval Duroplast Toilet Seat User Manual

Model: 3276000700395

1. Introduction

Thank you for choosing the SENSEA Remix Oval Duroplast Toilet Seat. This product is designed for durability, hygiene, and ease of use, featuring a soft-close mechanism and a quick-release system for convenient cleaning. Please read this manual carefully before installation and use to ensure proper function and longevity of your toilet seat.



Image 1.1: The SENSEA Remix Oval Duroplast Toilet Seat in white, with the lid open.

2. Safety Instructions

- Ensure all components are securely fastened before use.
- Do not stand on the toilet seat or lid. This product is designed for sitting only.
- Keep children away from the soft-close mechanism to prevent pinching, although it is designed to close slowly.
- Use only mild cleaning agents. Avoid abrasive cleaners or harsh chemicals that may damage the surface or antibacterial coating.
- Do not overtighten screws during installation, as this may cause damage to the toilet bowl or seat.

3. Package Contents

Please verify that all parts are present before beginning installation:

- 1 x SENSEA Remix Oval Duroplast Toilet Seat (Lid and Seat)
- 2 x Adjustable Plastic Hinges
- 2 x Mounting Screws with Fixings
- 6 x Plastic Pads (pre-attached to the seat)



Image 3.1: All components included with the SENSEA Remix Toilet Seat, showing the seat, lid, and mounting hardware.




Image 3.2: Diagram illustrating key features such as top fixing, easy cleaning, long life (30,000 cycles), and included components.

4. Setup and Installation

The SENSEA Remix toilet seat features a top-fix installation system for easy mounting on all standard toilets.

1. **Prepare the Toilet Bowl:** Ensure the toilet bowl's mounting holes are clean and free of debris.
2. **Insert Fixings:** Place the plastic fixings into the mounting holes on the toilet bowl.
3. **Position Hinges:** Place the adjustable plastic hinges over the fixings. The hinges allow for adjustment to fit various hole distances (4-19 cm center-to-center).
4. **Attach Seat:** Align the toilet seat with the hinges and press down firmly until it clicks into place.
5. **Secure with Screws:** Insert the mounting screws through the hinges and into the fixings. Tighten the screws from the top using a screwdriver until the seat is secure. Do not overtighten.

6. **Test Stability:** Gently try to move the seat to ensure it is firmly attached and does not wobble. Adjust tightness if necessary.

5. Operating Features

5.1 Soft Close Function

The SENSEA Remix toilet seat is equipped with a soft-close mechanism. This feature ensures that both the seat and the lid close slowly and quietly, preventing slamming and reducing wear and tear. Simply push the lid or seat down gently, and it will lower itself automatically.



Image 5.1: A hand gently pushing down the toilet seat, demonstrating the soft-close function.

5.2 Quick Release for Easy Cleaning

For thorough cleaning, the toilet seat can be easily removed from its hinges. Locate the quick-release buttons (usually small silver buttons) near the hinges at the back of the seat. Press these buttons simultaneously and lift the seat straight up to detach it from the toilet bowl.



Image 5.2: A finger pressing the quick-release button on the toilet seat hinge, allowing for easy removal.

6. Maintenance and Cleaning

Regular cleaning will help maintain the hygiene and appearance of your SENSEA Remix toilet seat. The Duroplast material and antibacterial coating ensure better hygiene.

- **Daily Cleaning:** Wipe the seat and lid with a soft cloth dampened with water and a mild, non-abrasive soap.
- **Deep Cleaning:** Utilize the quick-release feature to remove the seat for more thorough cleaning of both the seat and the toilet bowl area.
- **Avoid Harsh Chemicals:** Do not use strong acids, alkalis, abrasive powders, or scouring pads, as these can damage the surface and the antibacterial properties.
- **Hinge Care:** The stainless steel hinges are corrosion-resistant. Keep them clean and dry to ensure smooth operation.
- **Reattachment:** After cleaning, simply align the seat with the hinges and press down until it clicks securely into place.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Seat wobbles or moves	Mounting screws are loose.	Tighten the mounting screws from the top. Ensure the plastic fixings are properly seated.
Soft-close function not working properly	Hinges are dirty or damaged.	Clean the hinges thoroughly. If damaged, contact SENSEA support for replacement parts.
Difficulty removing seat for cleaning	Quick-release buttons not fully pressed or mechanism is stiff.	Ensure both quick-release buttons are pressed simultaneously and firmly. Apply a small amount of silicone spray to the mechanism if stiff.
Seat does not fit toilet bowl correctly	Incorrect hinge adjustment or toilet bowl is non-standard.	Adjust the position of the hinges to match the toilet bowl's mounting holes. Verify toilet dimensions against product specifications.

8. Specifications

Attribute	Value
Brand	SENSEA
Model Number	3276000700395
Color	White
Material	Duroplast
Product Dimensions (Outer)	43.5 cm (Length) x 38 cm (Width)
Inner Length	28.5 cm
Inner Width	22.5 cm
Depth	5.1 cm
Item Weight	1.99 kg
Maximum Supported Weight	150 kg
Distance between Fasteners	13 cm
Center-to-Center Distance (Adjustable)	4-19 cm
Plastic Pads	6




Image 8.1: Detailed diagram showing the dimensions of the SENSEA Remix Toilet Seat, including outer length (435mm), width (380mm), inner length (285mm), inner width (225mm), and adjustable hinge distance (130-180mm).

9. Warranty and Support

The SENSEA Remix Toilet Seat comes with a**5-year guarantee**, reflecting our commitment to quality and durability. This warranty covers manufacturing defects under normal use conditions.

For technical support, warranty claims, or inquiries about replacement parts, please contact SENSEA customer service through the official SENSEA website or your point of purchase. Please have your model number (3276000700395) and proof of purchase ready when contacting support.



Image 9.1: The official SENSEA brand logo.

© 2024 SENSEA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08P26CVRN

More documents and user manuals: **https://manuals.plus/**