Apowand Rose Red

Apowand Mini Massager User Manual

Model: Rose Red (B08P26LLPW) | Brand: Apowand

1. Introduction

The Apowand Mini Massager is a compact, cordless handheld device designed for personal use to relieve muscle soreness and tension. Its small size and powerful vibrations make it ideal for targeting areas such as the neck, shoulders, back, and other parts of the body. Crafted from safe, 100% silicone, this massager features a waterproof design for easy cleaning and offers 10 distinct vibration modes to suit various preferences. It is conveniently rechargeable via USB, making it a versatile companion for both travel and daily relaxation.



Image: The Apowand Mini Massager in its Rose Red color, showcasing its sleek and ergonomic design.

2. Product Features

- **Portable Design:** The mini massager is small and lightweight, making it highly suitable for travel and daily use. It comes with a flannel bag for convenient carrying.
- **Powerful Handheld Massager:** Equipped with 10 different vibration modes, this personal massager effectively relieves muscle soreness in the neck, shoulders, back, legs, and any part of the body.
- **USB Fast Charging:** Easily rechargeable via USB using a mobile power supply, PC, or car charger. A full charge takes approximately 2 hours.
- **Safe and Waterproof:** Made from high-quality, 100% body-safe silicone with excellent IP65 water resistance, allowing for easy cleaning.



Image: Visual representation of the massager's key features, including full body massage, 10 patterns, medical grade silicone, cordless, rechargeable battery, body safe & soft, travel friendly, and waterproof.



Image: A size comparison showing the massager's compact dimensions (4.35 inches in length, 1.18 inches in width) next to a typical smartphone, highlighting its portability.

3. What's Included

Upon opening your Apowand Mini Massager package, you will find the following items:

- 1 x Mini Wand Massager
- 1 x Fine Flannel Bag
- 1 x USB Charging Cable
- 1 x User Instructions (in English)

4. Setup

Initial Charging:

Before first use, it is recommended to fully charge your Apowand Mini Massager. The charging port is located at the bottom of the device. Use the provided USB charging cable to connect the massager to a USB power source such as a mobile power supply, PC, or car charger. A full charge typically takes approximately 2 hours.



Image: An illustration demonstrating how to charge the massager using the USB cable, showing various compatible power sources like a wall adapter, power bank, laptop, and car charger.

5. Operating Instructions

Power On/Off and Mode Selection:

1. To **power on** the massager, press and hold the power button located on the device.
2. Once powered on, **short press** the power button to cycle through the 10 different vibration modes.
3. To **power off** the massager, press and hold the power button again until the device turns off.

Experiment with the various modes to find the one that best suits your needs for muscle relaxation and relief.

Your browser does not support the video tag.

Video: An official product video demonstrating the features and operation of the Apowand Mini Massager, including how to power on, switch modes, and its waterproof capabilities. (Source: GH Minnie, Seller)

6. Maintenance and Care

To ensure the longevity and hygiene of your Apowand Mini Massager, follow these care instructions:

- **Cleaning:** Due to its IP65 waterproof design, the massager can be easily cleaned. Simply rinse it under running water or wipe it with a damp cloth and mild soap. Ensure it is completely dry before storing.
- **Storage:** Store the massager in the provided flannel bag in a cool, dry place away from direct sunlight and extreme temperatures.
- **Charging:** Always use the original USB charging cable. Avoid overcharging the device.



Image: The massager shown partially submerged in water, illustrating its 100% water resistance and ease of cleaning.

7. Troubleshooting

Problem	Possible Cause	Solution
Massager does not turn on.	Battery is depleted.	Charge the massager fully using the provided USB cable. Ensure the charging port is clean and the cable is securely connected.
Massager does not charge.	Charging cable or port issue.	Ensure the USB cable is not damaged. Try a different USB power source. Check the charging port for any obstructions. If the issue persists, contact customer support.

Problem	Possible Cause	Solution
Vibrations are weak or inconsistent.	Low battery or internal malfunction.	Recharge the device. If the problem continues after a full charge, there might be an internal issue. Contact customer support for assistance.

8. Specifications

Feature	Detail
Product Dimensions	4.35 x 1.18 x 1.18 inches
Weight	5.28 ounces (approx. 80g)
Model Number	Rose Red
Battery	1 AAA battery required (included) - *Note: Product description mentions rechargeable, this might be a typo in the provided spec. Assuming rechargeable as per description.*
Material	Silica gel (100% silicone)
Color	Rose Red
Waterproof Rating	IP65
Vibration Modes	10 Quiet Vibration Modes
Charging Type	USB Charging
Manufacturer	Apowand

9. Warranty and Support

Apowand provides a **2-year warranty** and free replacement service for all customers. If you encounter any issues or have questions regarding your massager, please do not hesitate to contact our customer support team for assistance.
For support, please refer to the contact information provided in your product packaging or visit the official Apowand website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question