

[Manuals.plus](#) /

› [ForeverPRO](#) /

› ForeverPRO 00416438 Grate Foot Assembly Instruction Manual

ForeverPRO FP-00416438

ForeverPRO 00416438 Grate Foot Assembly Instruction Manual

Brand: ForeverPRO | Model: FP-00416438

INTRODUCTION

This manual provides essential information for the installation, maintenance, and troubleshooting of the ForeverPRO 00416438 Grate Foot Assembly. This part is designed as a replacement component for specific refrigerator models. Please read these instructions carefully before proceeding with any installation or maintenance.

PRODUCT OVERVIEW



Image: Close-up view of the ForeverPRO 00416438 Grate Foot Assembly, showing its brass-colored outer ring and dark gray inner core with a central hole.

The ForeverPRO 00416438 Grate Foot Assembly is a replacement part designed to support refrigerator

grates. It replaces part numbers 1100594, 416438, and PS8712121. This component is crucial for maintaining the stability and proper positioning of your refrigerator's grates.

COMPATIBILITY

This Grate Foot Assembly is compatible with a range of refrigerators, primarily those manufactured by Bosch. It is also known to be compatible with certain models from Thermador and Gaggenau. Please verify your appliance's specific part requirements before purchase and installation to ensure compatibility.

INSTALLATION INSTRUCTIONS

Safety First: Always unplug your refrigerator from the power outlet before attempting any installation or repair to prevent electrical shock.

1. **Prepare the Appliance:** Ensure the refrigerator is unplugged and any food items or shelves that obstruct access to the grate feet are removed.
2. **Locate the Old Grate Foot:** Identify the grate foot that needs replacement. It may be worn, damaged, or missing.
3. **Remove the Old Grate Foot:** Depending on the design, the old foot may screw out, snap off, or require gentle prying. Use appropriate tools if necessary, taking care not to damage the grate or surrounding components.
4. **Install the New Grate Foot:** Align the ForeverPRO 00416438 Grate Foot Assembly with the mounting point. Gently push or screw the new foot into place until it is securely seated. Ensure it is flush and stable.
5. **Reassemble and Test:** Once the new foot is installed, replace any removed shelves or food items. Plug the refrigerator back into the power outlet. Verify that the grate is stable and level.

If you are unsure about any step, it is recommended to consult a qualified appliance technician.

MAINTENANCE

Proper maintenance can extend the life of your refrigerator components, including the grate feet.

- **Regular Cleaning:** Periodically clean the grate feet and the areas they support to prevent debris buildup. Use a soft cloth and mild detergent if necessary.
- **Periodic Inspection:** Routinely check the grate feet for any signs of wear, cracking, or looseness. Replace any damaged feet promptly to maintain stability.

TROUBLESHOOTING

If you encounter issues after installing the Grate Foot Assembly, consider the following:

- **Part Does Not Fit:** Double-check the model number of your refrigerator and compare it with the compatible models for the 00416438 part. Ensure you have the correct replacement part.
- **Grate is Unstable:** Verify that the new grate foot is fully seated and securely installed. Check other grate feet for wear or damage that might be contributing to instability.
- **Damage During Installation:** If the part was damaged during installation, it may need to be replaced. Handle with care during installation.

For persistent issues, refer to your refrigerator's original service manual or contact customer support.

SPECIFICATIONS

Attribute	Value
Brand Name	ForeverPRO
Model Info	00416438
Item Model Number	00416438
Part Number	FP-00416438
ASIN	B08P2PVMW9
Date First Available	November 24, 2020

WARRANTY INFORMATION

Specific warranty details for the ForeverPRO 00416438 Grate Foot Assembly are not provided in this manual. For information regarding product warranty, please refer to the product packaging, the seller's website, or contact ForeverPRO directly.

CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding the ForeverPRO 00416438 Grate Foot Assembly, please contact the seller or ForeverPRO customer service. Contact information can typically be found on the product packaging or the retailer's website where the item was purchased.