

[Manuals.plus](#) /

› [Hasbro](#) /

› Hasbro FurReal Walkalots Pets E3504EU6 Instruction Manual

Hasbro E3504EU6

Hasbro FurReal Walkalots Pets Instruction Manual

Model: E3504EU6

INTRODUCTION

Thank you for choosing the Hasbro FurReal Walkalots Pet. This interactive toy is designed to provide engaging playtime for children aged 18 months and up. This manual provides essential information for the safe and proper setup, operation, and maintenance of your new pet. Please read these instructions carefully before use and retain them for future reference.

IMPORTANT SAFETY INFORMATION

- **Adult Supervision Required:** Always ensure an adult supervises children during play with this toy.
- **Choking Hazard:** This toy may contain small parts. Keep away from children under 3 years of age.
- **Battery Safety:** If batteries are required (check packaging), always follow battery safety guidelines. Do not mix old and new batteries, or different types of batteries. Insert batteries with correct polarity. Remove exhausted batteries promptly.
- **Intended Use:** This toy is intended for indoor play. Avoid exposure to water or extreme temperatures.

WHAT'S IN THE BOX

Your Hasbro FurReal Walkalots Pet package should contain the following items:

- 1 x FurReal Walkalots Pet (e.g., puppy or kitten)
- 1 x Detachable Leash Handle



Image: FurReal Walkalots cat-like pet in its original packaging, showing the toy and leash handle.

SETUP

1. **Unpack the Pet:** Carefully remove the FurReal Walkalots pet and its leash handle from the packaging.
2. **Attach the Leash:** Locate the attachment point on the pet's collar or back. Align the leash handle with this point and firmly push or click it into place until you hear a secure click. Ensure the leash is securely attached before play.
3. **Battery Installation (if applicable):** If your specific model requires batteries, locate the battery compartment (usually on the underside of the pet). Use a screwdriver to open the compartment, insert the required batteries (e.g., AA or AAA, not specified in product data) observing polarity (+/-), and secure the cover.



Image: FurReal Walkalots cat-like pet with its blue leash handle attached, still in packaging. This illustrates the leash attachment.

OPERATING INSTRUCTIONS

Once the leash is securely attached and batteries are installed (if needed), your FurReal Walkalots pet is ready for a walk!

1. **Hold the Leash:** Grasp the leash handle firmly.
2. **Push or Pull:** Gently push the pet forward or pull it along using the leash. The pet is designed to move its head and tail as it walks, creating an interactive experience.
3. **Explore:** Encourage imaginative play by walking your pet around the house or in designated play areas.



Image: A child happily playing with a brown FurReal Walkalots puppy, holding its blue leash, demonstrating how to operate the toy.

MAINTENANCE

- **Cleaning:** To clean your FurReal Walkalots pet, gently wipe the surface with a damp cloth. Do not immerse the toy in water. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, store the pet and its leash in a clean, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** If the pet's movements become sluggish or stop, it may be time to replace the batteries (if applicable). Refer to the "Setup" section for battery installation instructions.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Pet does not move.	No batteries or exhausted batteries.	Install new batteries, ensuring correct polarity.
Leash detaches easily.	Leash not securely attached.	Ensure the leash handle is firmly clicked into the attachment point.
Pet's movement is sluggish.	Low battery power.	Replace with fresh batteries.

SPECIFICATIONS

Model Number: E3504EU6

Product Dimensions: 8.66 x 9.84 x 7.87 inches (22 x 25 x 20 cm)

Item Weight: 1.15 pounds (0.52 kg)

Recommended Age: 18 months and up

Manufacturer: HASBRO

WARRANTY AND SUPPORT

For information regarding warranty, returns, or customer support, please refer to the documentation included with your purchase or visit the official Hasbro website. Keep your proof of purchase for any warranty claims.

Hasbro Official Website: www.hasbro.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08P2X4YSL>

More documents and user manuals: <https://manuals.plus/>