

Marvel F1110

Marvel Spider-Man Jet Web Cycle Vehicle and Action Figure (Model F1110) Instruction Manual

INTRODUCTION

Welcome to the instruction manual for your Marvel Spider-Man Jet Web Cycle Vehicle and Detachable Action Figure. This toy set allows children aged 4 and up to recreate exciting adventures with Spider-Man and his unique web cycle, featuring detachable glider wings. Please read these instructions carefully before use to ensure proper assembly and operation.

PACKAGE CONTENTS

Verify that all components are present in your package:

- 1 x Spider-Man 6-inch Action Figure (Integrated Suit design)
- 1 x Jet Web Cycle Vehicle
- 1 x Detachable Backpack Accessory with Flip-Out Glider Wings



Image: The product packaging displays the Spider-Man action figure, the Jet Web Cycle, and the detachable glider wings accessory.

SETUP INSTRUCTIONS

1. Attaching the Glider Wings to Spider-Man Figure

1. Locate the Spider-Man action figure and the detachable backpack accessory with glider wings.
2. Align the pegs on the backpack accessory with the corresponding holes on the back of the Spider-Man figure.
3. Gently press the backpack onto the figure until it clicks securely into place.



Image: A child demonstrates holding the Spider-Man figure with the yellow glider wings attached to its back.

2. Preparing the Jet Web Cycle

The Jet Web Cycle comes pre-assembled and ready for use. No additional assembly is required for the vehicle itself.

OPERATING INSTRUCTIONS

1. Placing Spider-Man on the Jet Web Cycle

1. Ensure the glider wings on Spider-Man's back are folded down. The wings will automatically fold when the figure is seated on the cycle.
2. Position the Spider-Man figure onto the seat of the Jet Web Cycle.
3. Align Spider-Man's hands with the handlebars of the cycle and gently push down until the figure is securely seated. The figure's feet should rest on the footrests.



Image: The Spider-Man action figure is shown securely seated on the red and gold Jet Web Cycle, ready for play.



Image: A child is shown carefully placing the Spider-Man figure onto the Jet Web Cycle, demonstrating the seating process.

2. Activating Glider Wings

To activate the glider wings, simply lift the Spider-Man figure off the Jet Web Cycle. The wings will automatically flip out, preparing Spider-Man for aerial adventures.



Image: The Spider-Man figure stands with its yellow glider wings fully deployed, positioned next to the Jet Web Cycle.



Image: A child is shown lifting the Spider-Man figure from the Jet Web Cycle, illustrating how the glider wings automatically deploy.

3. Articulation

The Spider-Man figure features 4 points of articulation: both arms and both legs. This allows for various poses and dynamic play scenarios.

MAINTENANCE

- **Cleaning:** Wipe the figure and vehicle with a soft, dry cloth. Do not use harsh chemicals or abrasive

cleaners.

- **Storage:** Store the toy in a cool, dry place away from direct sunlight to prevent discoloration or damage.
- **Inspection:** Periodically check for any loose parts or damage. Discontinue use if any significant damage is found.

TROUBLESHOOTING

This product is designed for durability and simple operation. Should you encounter any issues, please review the following:

- **Figure not seating properly on cycle:** Ensure the glider wings are fully folded down before attempting to seat the figure.
- **Wings not deploying:** Ensure the figure is fully lifted off the cycle. The mechanism is designed to deploy when the figure is detached.
- **Loose parts:** If any small parts become loose, ensure they are reattached correctly. If a part is broken, discontinue use to prevent choking hazards for younger children.

SPECIFICATIONS

Model Number:	F1110
ASIN:	B08P2YC9T1
Product Dimensions:	2.52 x 12.99 x 9.02 inches
Item Weight:	7.8 ounces
Recommended Age:	4 years and up
Manufacturer:	Hasbro

SAFETY INFORMATION

- **Choking Hazard:** This toy contains small parts and is not suitable for children under 3 years of age.
- **Adult Supervision:** Adult supervision is recommended during play, especially for younger children.
- **Intended Use:** This product is intended for play purposes only. Do not modify or use for purposes other than its intended design.

WARRANTY AND SUPPORT

For information regarding warranty, returns, or customer support, please refer to the retailer's policy where the product was purchased or visit the official [Marvel/Hasbro website](#) for further assistance.

For additional product information, you may visit the [Marvel Store](#).