

[Manuals.plus](#) /

› [Hatteker](#) /

› Hatteker Mens Hair Clipper & Beard Trimmer User Manual

Hatteker 696XJ

Hatteker Mens Hair Clipper & Beard Trimmer Instruction Manual

Model: 696XJ

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using this appliance. Keep this manual for future reference.

- Keep away from eyes and face.
- Use with caution in wet conditions.
- Supervise children when in use.
- Do not immerse the charging adapter in water.
- Ensure the appliance is fully dry before charging.

2. PRODUCT OVERVIEW

The Hatteker Mens Hair Clipper & Beard Trimmer is a versatile grooming tool designed for precision and ease of use. It features a high-carbon steel blade, IPX7 waterproof rating, and a powerful lithium-ion battery for extended cordless operation.



Figure 2.1: Hatteker Hair Clipper and included accessories.

This image displays the main hair clipper unit, along with a variety of colorful guide combs, a charging cable, a cleaning brush, and a barber's cape, highlighting the comprehensive grooming kit.

Key Features:

- **Versatile Grooming:** Ideal for hair clipping, beard trimming, mustaches, sideburns, goatees, stubble, and other facial and body hair. Suitable for children's haircuts due to low noise and safety blades.
- **High Carbon Steel Blade:** Precision-ground blades designed to stay sharp longer, providing high-performance precision for various styles and long-lasting durability. The tightly aligned teeth ensure effective hair removal without snagging or pulling.
- **IPX7 Waterproof:** The trimmer is fully washable, allowing for fast and easy cleaning by simply rinsing the blades under running water.
- **Powerful Battery:** Offers up to 300 minutes of cordless operation after a full 3-hour charge, making it suitable for home or professional barber use.
- **Adjustable Taper Lever & Ten Color Guide Combs:** Features an adjustable taper lever (0.8 mm to 2.0 mm) for

precise closeness and blending. Includes ten colorful guide combs (1.5, 3, 4.5, 6, 10, 13, 16, 19, 22, 25 mm) for a wide range of hairstyles and lengths.

3. COMPONENTS & WHAT'S IN THE BOX

Your Hatteker Hair Clipper kit includes the following items:

- Hatteker Hair Clipper Unit
- 10 Color Guide Combs (1.5, 3, 4.5, 6, 10, 13, 16, 19, 22, 25 mm)
- Hair Comb
- Cleaning Brush
- Charging Cable (USB)
- Hairdressing Cape
- Blade Oil



COMING WITH 10 COLORFUL GUIDE COMBS

Easy to get different shaving lengths for kids and men.



Figure 3.1: Hair Clipper with a full set of colorful guide combs.

This image showcases the hair clipper alongside its complete set of 10 colorful guide combs, each representing a different cutting length, emphasizing the variety of styling options available.



Figure 3.2: USB Quick Charge capability of the clipper.

This image illustrates the clipper being charged via a USB cable connected to a laptop, highlighting its quick charge feature and long battery life (3 hours for full charge, 5 hours working time).

4. SETUP

4.1 Initial Charge

Before first use, fully charge the clipper for approximately 3 hours. The digital LCD display will show the battery percentage and charging status.

DIGITAL LCD DISPLAY EASY TO KNOW BATTERY STATUS



Battery Indicator
Percentage



Oiled Reminder



Charging Reminder

LCD liquid crystal
Display



Figure 4.1: Digital LCD Display for battery status.

This image details the clipper's LCD screen, which provides real-time information on battery percentage, an oiling reminder, and a charging reminder, ensuring optimal performance and maintenance.

4.2 Attaching Guide Combs

Select the desired guide comb for your preferred hair length. Align the comb with the clipper blade and push firmly until it clicks into place.

Video 4.1: Demonstration of attaching guide combs and adjusting the taper lever.

This video demonstrates how to easily attach and detach the colorful guide combs to the hair clipper. It also shows the functionality of the adjustable taper lever, allowing users to customize cutting lengths for precise grooming.

5. OPERATING INSTRUCTIONS

5.1 Adjusting Cutting Length

Use the adjustable taper lever on the side of the clipper to fine-tune the cutting length between 0.8 mm and 2.0 mm. For longer lengths, attach the appropriate guide comb.




Figure 5.1: Adjustable Taper Rod and Guide Combs.

This diagram illustrates the adjustable taper rod on the clipper, which allows for fine-tuning of cutting length, alongside the 10 colored individual guide combs that provide a full range of hair lengths for various styling needs.

5.2 Hair & Beard Trimming

Ensure hair is clean and dry. For best results, comb hair in the direction of growth before trimming. Move the clipper against the direction of hair growth for an even cut.



Figure 5.2: Accurate Cutting for various styles.

This collage demonstrates the clipper's versatility in achieving accurate and comfortable cuts for different grooming needs, including professional hair cutting for adults and children, and precise beard trimming.

6. MAINTENANCE

6.1 Cleaning the Blades

The clipper is IPX7 waterproof, allowing for easy cleaning. After each use, remove the guide comb and rinse the blades under running water. Use the provided cleaning brush to remove any trapped hair.



Figure 6.1: Whole body waterproof for easy cleaning.

This image clearly shows the hair clipper being cleaned under running water, emphasizing its IPX7 waterproof rating and the ease of maintaining hygiene after use.

6.2 Oiling the Blades

Regularly apply a few drops of the included blade oil to the blades to ensure smooth operation and prolong their lifespan. The LCD display may show an oil reminder icon.

		
PROFESSIONAL HAIR CLIPPER It can cut through all hair types for easy at-home haircuts and stay sharp longer. The teeth on the blade are tightly line up with each other to remove hair with no snagging or pulling, offering an effective haircut	CARBON STEEL BLADE The blades are precision ground to stay sharp for longer, provide high-performance precision for any style and prevent skin irritation for a long life	IPX7 WATERPROOF This hair trimmer is fast and easy to clean. Simply rinse the blades under running water for quick, hygienic cleaning

Figure 6.2: Key features including adjustable blade, LED display, and IPX7 waterproof.

This composite image highlights three important aspects of the clipper: the adjustable taper lever for customized cutting lengths, the LED digit display for battery and charging status, and its IPX7 waterproof design for easy cleaning.

7. TROUBLESHOOTING

- **Clipper not turning on:** Ensure the battery is charged. Connect the charging cable and allow it to charge for at least 30 minutes before attempting to turn it on again.
- **Blades pulling hair:** The blades may be dull or require oiling. Clean the blades thoroughly and apply blade oil. If the issue persists, consider replacing the blade head.
- **Reduced power/speed:** This typically indicates a low battery. Recharge the clipper fully.
- **Excessive noise/vibration:** Ensure the blade is properly seated and secured. Apply blade oil. If the noise continues, contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	Hatteker
Model Number	696XJ
Product Dimensions	2.68 x 6.46 x 9.69 inches; 1.54 Pounds
Battery Type	Lithium Metal (included)
Charging Time	3 Hours
Runtime	5 Hours (300 minutes)
Waterproof Rating	IPX7
Country of Origin	China

9. WARRANTY & SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Hatteker customer service directly. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08P328PMP>

More documents and user manuals: **<https://manuals.plus/>**