ANTELA Speed 4S

ANTELA Indoor WiFi Surveillance Camera User Manual

Model: Speed 4S | Brand: ANTELA

Introduction and Overview

The ANTELA Indoor WiFi Surveillance Camera (Model Speed 4S) provides comprehensive home monitoring with its advanced features. Designed for ease of use and reliable performance, this camera allows you to keep an eye on your home, pets, or children from anywhere, at any time.





The ANTELA Indoor WiFi Surveillance Camera, a compact and modern device designed for discreet home monitoring.

Key Features:

- **1080p Full HD Resolution:** Provides clear and smooth live video feed for detailed monitoring.
- **Pan/Tilt/Zoom Functionality:** Offers a 355° horizontal and 110° vertical rotation with a wide-angle lens to cover all areas.
- **Infrared Night Vision:** Ensures clear visibility up to 10 meters (32 feet) in low-light or complete darkness.
- **Smart Motion Detection:** Sends instant notifications to your app upon detecting movement, with alarm video recording.
- **Two-Way Audio:** Built-in microphone and speaker allow for real-time communication.
- **Voice Assistant Compatibility:** Works seamlessly with Amazon Alexa and Google Assistant for hands-free control.
- **Flexible Storage Options:** Supports local storage via Micro SD card (up to 128GB) and secure cloud storage.


Setup Guide

Follow these steps for a quick and easy installation of your ANTELA camera:

1. **Download the Smart Life App:**

   Search for "Smart Life" on the Google Play Store for Android devices or the Apple App Store for iOS devices and

download the application.



Step 1: Download the Smart Life app from your device's app store.

2. **Power On Your Camera:**

   Connect the camera to a power source using the provided power adapter. Ensure the camera is placed within range of your 2.4 GHz Wi-Fi network (5G Wi-Fi is not supported).



Step 2: Plug in your camera to power it on.

3. **Follow In-App Guide for Connection:**

   Open the Smart Life app, register or log in, and follow the on-screen instructions to add your new device. The app will guide you through connecting the camera to your Wi-Fi network.



Step 3: Follow the in-app guide to complete the setup and connect to Wi-Fi.

Operating Instructions

Pan/Tilt/Zoom Control


The camera offers extensive coverage with its 355° horizontal and 110° vertical rotation. You can control the camera's viewing angle directly from the Smart Life app by swiping on the live view or using the directional controls.



Control the camera's pan (355°) and tilt (110°) movements directly from your smartphone app.

Smart Motion Detection

The camera is equipped with intelligent motion detection. When motion is detected, the camera will immediately send a notification to your smartphone via the Smart Life app. You can customize detection sensitivity and set specific detection zones within the app.



The camera detects motion and sends instant alerts to your mobile device, displaying a timeline of detected events.

Two-Way Audio Communication

With the built-in microphone and speaker, you can engage in real-time two-way conversations through the camera. This feature is ideal for communicating with family members, pets, or even deterring intruders.



Engage in real-time conversations with loved ones or pets using the camera's two-way audio function.

Infrared Night Vision


The camera automatically switches to infrared night vision mode in low-light conditions, providing clear black and white video up to 10 meters (32 feet). This ensures 24/7 monitoring capability.



The camera provides clear infrared night vision, allowing for continuous monitoring even in complete darkness.

Remote Control and Monitoring

Access your camera's live feed and control its functions from anywhere using the Smart Life app on your smartphone or tablet, as long as you have an internet connection.



Monitor your home remotely from anywhere using the mobile application.

Voice Assistant Integration

The ANTELA camera is compatible with Amazon Alexa and Google Assistant, allowing for convenient voice control. You can ask your voice assistant to display the camera feed on compatible smart displays.



Use voice commands with Alexa to view your camera feed on compatible devices.

Storage Options

The camera supports two storage methods for recorded video and images:

- **Micro SD Card:** Insert a Micro SD card (up to 128GB, not included) into the camera's designated slot for local storage of recordings.
- **Cloud Storage:** Subscribe to the optional cloud storage service via the Smart Life app for secure, encrypted storage of your video data.

Maintenance

To ensure optimal performance and longevity of your ANTELA camera, follow these simple maintenance guidelines:

- **Cleaning:** Gently wipe the camera lens and body with a soft, dry, lint-free cloth. Avoid using harsh chemicals, cleaning solvents, or abrasive materials, as these can damage the camera's surface or lens.

- **Placement:** Ensure the camera is placed in a stable location, away from direct sunlight, extreme temperatures, and high humidity. Do not block the ventilation holes.
- **Software Updates:** Regularly check the Smart Life app for firmware updates. Keeping your camera's software up-to-date ensures you have the latest features and security enhancements.
- **Power Supply:** Always use the original power adapter provided with the camera to prevent damage.

Troubleshooting

If you encounter issues with your ANTELA camera, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Camera fails to connect to Wi-Fi.	Incorrect Wi-Fi password; 5GHz Wi-Fi network; camera too far from router.	Ensure correct 2.4GHz Wi-Fi password. Move camera closer to router. Restart camera and router.
Poor video quality.	Weak Wi-Fi signal; dirty lens; insufficient lighting.	Improve Wi-Fi signal strength. Clean the camera lens. Ensure adequate lighting or enable night vision.
Motion detection alerts are too frequent or not working.	Sensitivity settings too high/low; incorrect detection zone.	Adjust motion detection sensitivity in the app. Define specific detection zones to avoid false alarms.
Two-way audio not functioning.	Microphone/speaker muted in app; app permissions.	Check audio settings in the Smart Life app. Ensure the app has microphone permissions on your phone.
SD card not recording.	SD card full or corrupted; incorrect formatting; card not inserted properly.	Format the SD card via the app. Replace with a new SD card if corrupted. Ensure proper insertion.

Specifications

Detailed technical specifications for the ANTELA Indoor WiFi Surveillance Camera (Model Speed 4S):

Feature	Detail
Brand	ANTELA
Model Name	Speed 4S
Connectivity Technology	Wireless (Wi-Fi 2.4 GHz)
Video Resolution	1080p Full HD
Pan Angle	355 degrees
Tilt Angle	110 degrees
Special Features	Local Recording, Night Vision, HD Resolution, Motion Detection, Two-Way Audio

Feature	Detail
Indoor/Outdoor Use	Indoor
Power Source	Corded Electric (240 Volts AC, 4.5 Watts)
Material	Plastic
Dimensions (L x W x H)	6.3 x 5.8 x 9.6 cm
Weight	310 grams
Night Vision Range	Up to 10 meters (32 feet)
Storage	Micro SD card (max 128GB), Cloud Storage



Physical dimensions of the ANTELA camera: 6.3 cm width and 9.6 cm height.

Warranty and Support

ANTELA products are designed for reliability and performance. For specific warranty information, please refer to the warranty card included with your product or visit the official ANTELA website. For technical support, troubleshooting assistance, or any inquiries not covered in this manual, please contact ANTELA customer service through their official channels.

You can often find additional support resources, FAQs, and updated manuals on the brand's official website: Visit the ANTELA Store on Amazon

© 2023 ANTELA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question