

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Amazon Basics](#) /

› [Amazon Basics Kids Corner Wooden Kitchen Toy Playset Instruction Manual](#)

Amazon Basics 838428

Amazon Basics Kids Corner Wooden Kitchen Toy Playset Instruction Manual

Model: 838428

INTRODUCTION

This instruction manual provides essential information for the safe assembly, operation, and maintenance of your Amazon Basics Kids Corner Wooden Kitchen Toy Playset. Designed for toddlers and preschoolers aged 3 years and up, this playset offers a realistic and engaging play experience, fostering developmental skills through imaginative play.

The playset features a stove, oven, sink, and refrigerator, along with various accessories, providing a comprehensive play kitchen environment. Please read this manual thoroughly before assembly and use to ensure proper setup and long-lasting enjoyment.



Figure 1: Assembled Amazon Basics Kids Corner Wooden Kitchen Toy Playset.

This image displays the complete Amazon Basics Kids Corner Wooden Kitchen Toy Playset, showcasing its corner design with a refrigerator, oven, stove, and sink unit, all in a white and gray finish.

SAFETY INFORMATION

Warning: Not suitable for children under three years. Contains small parts which may present a choking hazard. Always supervise children during play. Ensure all parts are securely fastened before allowing children to play with the unit. Regularly inspect the playset for any loose parts or damage that could pose a safety risk.

SETUP

The Amazon Basics Kids Corner Wooden Kitchen Toy Playset requires assembly. Detailed step-by-step instructions, including a list of all components and hardware, are provided in the official User Manual PDF. It is highly recommended to follow these instructions carefully to ensure proper and safe assembly.

You can download the full User Manual PDF [here](#).

Components Overview

The playset includes the main kitchen units and several accessories:

- Refrigerator unit with opening door and simulated ice dispenser.
- Oven unit with opening door and control knobs.
- Stove top with two burners and control knobs.
- Overhead vent hood with hooks for utensils.

- Sink unit with faucet and opening dishwasher door.
- Accessories: Toy metal skillet, lid, pot, ladle, and spatula.



Figure 2: Playset with doors open, revealing storage compartments.

This image shows the Amazon Basics Kids Corner Wooden Kitchen Toy Playset with the refrigerator, oven, and dishwasher doors open, highlighting the interior storage shelves and compartments.

OPERATING INSTRUCTIONS

The playset is designed for interactive pretend play. Children can engage with various features to simulate real kitchen activities.

Key Features:

- **Doors:** The refrigerator, oven, and dishwasher doors open and close, allowing for storage of play food and accessories.
- **Knobs:** The stove and oven knobs turn and produce a clicking sound, enhancing the realistic play experience.
- **Stove Top:** Features two simulated burners for pretend cooking.
- **Sink:** A plastic sink basin with a realistic faucet allows for pretend washing of dishes.
- **Accessories:** Use the included metal skillet, lid, pot, ladle, and spatula for various cooking scenarios. The utensils can be hung on the hooks under the vent hood.



Figure 3: Stove and Hood Detail.

This image provides a close-up view of the stove top with its two burners, the control knobs, and the overhead vent hood with hooks from which a toy pot, lid, skillet, ladle, and spatula are hanging.



Figure 4: Microwave and Oven Detail.

This image shows a detailed view of the microwave unit above the refrigerator and the oven unit, both featuring simulated digital displays and control panels.

MAINTENANCE

To ensure the longevity and cleanliness of your playset, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a damp cloth and mild soap as needed. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Inspection:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten if necessary to maintain structural integrity.
- **Storage:** Store the playset in a dry environment away from direct sunlight or extreme temperatures to prevent warping or fading of the wood.

The playset is constructed from high-quality FSC-certified wood and other child-safe materials, designed for durability and to withstand regular play.



Figure 5: FSC-certified Wood Mark.

This image displays the FSC (Forest Stewardship Council) logo, signifying that the wood used in the playset comes from responsibly managed forests.

TROUBLESHOOTING

If you encounter any issues with your playset, consider the following common solutions:

- **Loose Parts:** If any parts feel wobbly or loose, re-tighten the corresponding screws. Refer to the assembly instructions for screw locations.
- **Missing Components:** Before assembly, verify all parts are present against the component list in the User Manual. If parts are missing, contact customer support.
- **Damage:** If the playset sustains damage, discontinue use immediately to prevent injury. Contact customer support for guidance on repair or replacement.

SPECIFICATIONS

Attribute	Value
Product Dimensions	39.37 x 28.35 x 35.04 inches (L x W x H)
Item Weight	45 pounds
ASIN	B08P4HC1B1
Item Model Number	838428
Manufacturer Recommended Age	3 years and up
Manufacturer	Amazon



Figure 6: Product Dimensions Diagram.

This diagram illustrates the overall dimensions of the playset, including its length, width, and height, with measurements provided in both inches and centimeters.

WARRANTY

For detailed information regarding the product warranty, please refer to the official Warranty PDF document.

You can access the Warranty PDF [here](#).

SUPPORT

If you have any questions, require assistance, or need to report an issue with your Amazon Basics Kids Corner Wooden Kitchen Toy Playset, please contact Amazon customer support. You can typically find support contact information on the Amazon website or through your purchase history.

For general information about Amazon Basics products, visit the official Amazon Basics Store: [Amazon Basics Store](#).