

- Manuals.plus /
- › Superer /
- › Superer Charger Cord User Manual

Superer PSD0502000US

Superer Charger Cord User Manual

Model: PSD0502000US

1. INTRODUCTION

This user manual provides essential information for the safe and effective use of your Superer Charger Cord. This product is designed to provide reliable power for compatible Beats earphones and other devices requiring a USB Type-C charging cable.

Please read this manual thoroughly before using the product and retain it for future reference.

2. PRODUCT OVERVIEW



Image: The Superer charger cord and wall adapter. The black wall adapter features a USB-A port, and the black cable has a standard USB-A connector on one end and a USB Type-C connector on the other.

The Superer Charger Cord includes a wall adapter and a 5-foot USB Type-C cable. It is specifically designed for charging various Beats earbud models and other compatible devices.

2.1 Compatibility

This charger is compatible with devices that utilize a USB Type-C charging port. Please verify your device's charging port type before use.

- **Compatible with:** Beats Flex, Beats Studio Buds, Beats Studio Buds+, Beats Fit Pro, Beats Studio Pro Wireless Earbuds Headphone.
- **Not compatible with:** Devices using a Micro-USB port, such as Beats Solo3 Wireless, Beats Studio3 Wireless, Powerbeats Pro, and Beats Pill+.

USB-C Charging Port

Check the shape of your charging port before purchase



USB-C



Micro-usb



Image: A visual comparison showing the distinct shapes of a USB-C charging port (correct, with a checkmark) and a Micro-USB charging port (incorrect, with an 'X'). The charger is shown plugged into a wall outlet.

USB C



Fit for
Beats Flex ✓
Beats Studio Buds ✓
Beats Fit Pro ✓

Micro USB



Not Fit for
Beats Solo3 Wireless
Beats Studio3 Wireless
Powerbeats Pro
Beats Pill+

Image: A chart illustrating compatibility. It shows a USB-C connector with checkmarks next to "Fit for Beats Flex", "Beats Studio Buds", and "Beats Fit Pro". Below, a Micro-USB connector is shown with an 'X' next to "Not Fit for Beats Solo3 Wireless", "Beats Studio3 Wireless", "Powerbeats Pro", and "Beats Pill+".

Fit for type-c cable port



Beats Flex



Beats Studio Buds



Beats Fit Pro

Image: Examples of compatible Beats devices: Beats Flex (light blue earbuds with neckband), Beats Studio Buds (black true wireless earbuds in case), and Beats Fit Pro (black true wireless earbuds in case).

3. SETUP AND INSTALLATION

1. **Unpack:** Carefully remove the AC charger and 5-foot power cable from the packaging.
2. **Connect Cable to Adapter:** Insert the standard USB-A end of the charging cable into the USB-A port on the Superer wall adapter. Ensure it is firmly seated.



Image: A close-up view of the USB-A port on the Superer wall adapter, showing the cable being inserted.

3. **Plug into Power Outlet:** Insert the prongs of the wall adapter into a standard 100-240V AC wall outlet.



Image: A close-up view of the Superer wall adapter's prongs, ready to be plugged into an electrical outlet.

4. **Connect to Device:** Insert the USB Type-C end of the cable into the charging port of your compatible earbud or headphone device.



Image: A close-up view of the USB Type-C connector on the charging cable.

4. OPERATING INSTRUCTIONS

Once connected, your device should begin charging automatically. The charger provides a stable 5V 2A output for efficient charging.



Image: A pair of black earbuds with a neckband connected to the Superer charger, which is plugged into a wall outlet. A laptop is

also visible in the background.

The compact and portable design allows for easy transport and use in various settings.

Your browser does not support the video tag.

Video: This video demonstrates the compact size and portability of the Superer charger, showing it being plugged into an outlet and used to charge various devices like earbuds, tablets, and phones in different environments.

5. MAINTENANCE AND CARE

- Keep the charger and cable dry. Avoid exposure to liquids.
- Do not expose to extreme temperatures.
- Store in a clean, dry place when not in use.
- Avoid sharp bends or excessive pulling on the cable to prevent damage.
- Clean the charger and cable with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.



Image: This image highlights the durability features of the cable, including resistance to water, high insulation tensile strength, and abrasion resistance.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not charging.	Incorrect port type; loose connection; faulty outlet; damaged cable/charger.	Ensure your device has a USB Type-C port. Check that the cable is securely plugged into both the adapter and the device. Try a different wall outlet. Inspect the cable and charger for visible damage.

Problem	Possible Cause	Solution
Slow charging.	Device drawing more power than supplied; background apps on device.	Ensure the device is compatible with 5V 2A charging. Close unnecessary applications on your device.
Charger feels warm.	Normal operation during charging.	A slight warmth is normal. If it becomes excessively hot or emits smoke/odor, immediately unplug it and discontinue use.

The charger is equipped with multiple safety protections:

- Short Circuit Protection
- Overcurrent Protection
- Overheating Protection
- Overvoltage Protection
- Electrostatic Protection
- Overcharge Protection



Image: An illustration showing the Superer charger alongside icons representing its safety features: Short Circuit Protection, Overcurrent Protection, Overheating Protection, and Overvoltage Protection.

7. SPECIFICATIONS

Feature	Detail
Model Number	PSD0502000US
Input	100-240V ~ 50-60Hz 0.5A Max
Output	5V 2A

Feature	Detail
Product Dimensions	1.78 x 1.42 x 0.4 inches (charger only)
Item Weight	3.2 ounces
Cable Length	5 feet
Connectivity Technology	USB
Connector Type	USB Type C
Safety Certification	UL Listed

Item Dimension

The volume is reduced by half and does not take up space



Image: A visual representation of the charger's dimensions, showing it plugged into a power strip next to a larger white adapter, illustrating its compact size.

8. WARRANTY AND SUPPORT

Superer stands behind the quality of its products. This charger cord is backed by the following:

- **30-Day Replacement or Returns:** Eligible for replacement or returns within 30 days of purchase.
- **12-Month Manufacturer Guarantee:** The manufacturer provides an additional 12 Months Guarantee from the date of purchase.

For any inquiries or support needs, please refer to the contact information provided with your product packaging or visit the official Superer website.

Positive Customer Support

Refund Within 30 Days of Purchase
and Replace Service Within 12 Months



12

Replace Service Within 12 Months

Worry-free after sales



Replace Service
Within 12 Months



Refund Within
30 Days of Purchase



Quick feedback
to any problems

Image: An infographic detailing the customer support policy, including "Replace Service Within 12 Months", "Refund Within 30 Days of Purchase", and "Quick feedback to any problems".

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08P4X79HN>

More documents and user manuals: <https://manuals.plus/>