

[Manuals.plus](#) /

› [CHUNGHOP](#) /

› CHUNGHOP Universal Remote for LG Smart TV Magic Remote (Model AN-MR19BA) Instruction Manual

## CHUNGHOP AN-MR19BA

# CHUNGHOP Universal Remote for LG Smart TV Magic Remote

MODEL: AN-MR19BA

## 1. Introduction

---

This instruction manual provides essential information for the setup and operation of your CHUNGHOP Universal Remote. This remote is designed as a replacement for various LG Smart TV Magic Remote models. Please note that this is an infrared (IR) remote control and does not support voice control, gyro, mouse, or pointer functions.

## 2. Compatibility

---

The CHUNGHOP Universal Remote is compatible with the following LG Smart TV Magic Remote Control models:

- AN-MR18BA, AN-MR19BA, AN-MR600G, AN-MR650, AN-MR650G, ANMR650A, ANMR600, AN-MR650B
- AKB75095307, AKB74475401, AKB74475433, AKB73975702, AKB75055701
- AKB73975711, AKB73715608, AKB74475401, AKB75375604, AGF76631064
- AKB74915324, AKB73715601, AKB75095308, AKB72915239

# CHUNGHOP Universal Remote

## Compatible with All LG Smart TV

AN-MR18BA / AN-MR19BA/ AN-MR600G/ AN-MR650  
AN-MR650G/ ANMR650A/ ANMR600/ AN-MR650B  
AN-MR18BA/ AKB75095307/ AKB74475401  
AKB74475433/ AKB73975702/ AKB75055701  
AKB73975711/AKB73715608 etc.



Image: The CHUNGHOP Universal Remote shown alongside a list of compatible LG Smart TV Magic Remote models.

# Replace for All LG Smart TV Remote Control



Image: The CHUNGHOP remote positioned as a replacement for several original LG Smart TV remotes.

### 3. Features

- **Dedicated Hotkeys:** Includes direct access buttons for 3D, Amazon, and Netflix for quick navigation to popular streaming services and features.
- **Infrared (IR) Technology:** Operates using stable infrared signals.
- **Long-Distance Control:** Effective control distance of up to 33 feet (10 meters).
- **Ergonomic Design:** Designed for comfortable handling and ease of use.

# Quickly Access Your Favorite Channel

With 3D, Amazon and Netflix hot keys, it will bring you more convenient!



Image: A close-up of the remote control highlighting the dedicated hotkeys for Netflix, Amazon, and My Apps.

# LONG-DISTANCE CONTROL

Stable infrared signal, control distance is up to **33FT**



Image: A visual representation demonstrating the remote's effective long-distance control up to 33 feet.

## 4. Setup

### 4.1 Battery Installation

This remote control requires 2 x 1.5V AA batteries (not included). No programming or additional setup is required after battery installation.

1. Open the battery compartment cover located on the back of the remote control.
2. Insert two AA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
3. Close the battery compartment cover securely.

# Easy to Use

No programming required

Just install 2 x 1.5V AA Batteries(Not Included) can work well.



Image: The remote's battery compartment is open, showing the correct placement for two AA batteries.

Video: A demonstration of installing batteries into the CHUNGHOP Universal Remote and a general overview of the remote's design and compatibility.

## 5. Operating Instructions

Once batteries are installed, the remote is ready for use with your compatible LG Smart TV. Point the remote directly at your television for optimal performance.

### 5.1 Basic Functions

- **Power Button:** Turns the TV on or off.
- **Number Buttons (0-9):** For direct channel selection.
- **Volume Up/Down (VOL +/-):** Adjusts the television volume.
- **Channel Up/Down (CH +/-):** Changes television channels.
- **Directional Pad (Up/Down/Left/Right) and OK Button:** Navigates menus and confirms selections.

### 5.2 Hotkeys and Special Buttons

- **NETFLIX:** Direct access to the Netflix application.
- **AMAZON:** Direct access to the Amazon application.
- **MY APPS:** Accesses your installed applications.
- **Q.MENU:** Opens the Quick Menu for common settings.
- **BACK/EXIT:** Returns to the previous screen or exits a menu/application.
- **3D:** Activates or deactivates 3D mode (if supported by your TV).

### 5.3 Important Note on Features

This remote control operates via infrared (IR) signals only. It **does not** include the following functions found on some original LG Magic Remotes:

- Voice Control
- Gyroscope (motion sensing)
- Mouse Function
- Pointer Function



Image: The remote control displayed with text overlays explicitly stating the absence of voice, gyro, mouse, and pointer functions.



Image: A detailed view of the remote control from both the front and side, highlighting its ergonomic shape and button arrangement.

## 6. Specifications

Specification	Detail
Brand	CHUNGHOP
Model Name	AN-MR19BA
Connectivity Technology	Infrared (IR)
Battery Type	2 x AA (not included)
Maximum Range	10 Meters (33 Feet)
Controller Type	Button Control

Button Quantity	18
Special Feature	Ergonomic Design

## 7. Troubleshooting

---

- **Remote not responding:**
  - Ensure batteries are correctly installed with proper polarity.
  - Replace old batteries with new AA batteries.
  - Check for any obstructions between the remote control and the TV's IR receiver.
  - Ensure you are within the maximum operating range of 33 feet (10 meters).
- **Voice control, pointer, or mouse functions are not working:**
  - This CHUNGHOP Universal Remote is an infrared (IR) remote control and does not support voice, gyro, mouse, or pointer functions. These features are specific to certain original LG Magic Remote models and are not replicated by this replacement remote.

## 8. Warranty and Support

---

For any questions, technical assistance, or warranty inquiries regarding your CHUNGHOP Universal Remote, please contact the manufacturer directly through their official support channels. Refer to the product packaging or the seller's information for specific contact details.