

Bobolyn e8518e53-f61c-4121-951e-536fe807bbd9

Bobolyn 4-in-1 Electric Wax Melt Warmer Instruction Manual

Model: e8518e53-f61c-4121-951e-536fe807bbd9

Brand: Bobolyn

1. INTRODUCTION

Thank you for choosing the Bobolyn 4-in-1 Electric Wax Melt Warmer. This versatile device is designed to enhance your home or office ambiance by safely melting scented wax, warming essential oils, heating candle jars, or keeping your beverages warm. Please read this manual thoroughly before use to ensure safe and optimal operation.

2. SAFETY INFORMATION

To prevent injury or damage, always follow these safety precautions:

- Keep the wax warmer away from children and pets, as it may become hot during operation.
- Place the warmer on a stable, heat-resistant surface.
- Do not touch the ceramic dish or heating plate until several hours after turning it off, as they retain heat.
- Ensure the power supply is unplugged when not in use or before cleaning.
- Do not immerse the electrical unit in water or any other liquid.
- Avoid using abrasive cleaners or scouring pads, as they may damage the ceramic surface.
- If using essential oils, mix them with some water in the removable dish.

3. PRODUCT FEATURES

- **4-in-1 Multifunctional Design:** Use for wax melts, essential oils, candle jars, or beverage warming.
- **Large Capacity Dish:** 4.5-inch ceramic dish accommodates more wax cubes.
- **Durable Ceramic:** Leak-proof and anti-corrosion ceramic construction.
- **Efficient Heating:** Iron plate with fast heating and stable temperature.
- **Safe Operation:** Elevated bottom support prevents direct contact with surfaces.

- **Simple Control:** Easy on/off side switch with an indicator light.
- **Elegant Design:** High-quality ceramic with a modern aesthetic, suitable for various decor styles.
- **Easy to Clean:** Removable dish for convenient wax residual cleaning.
- **Portable:** Compact and lightweight design for easy travel.

4. PACKAGE CONTENTS

- Bobolyn Electric Wax Melt Warmer Base
- Removable Ceramic Dish (4.5 inches)
- Power Cord with On/Off Switch

5. SETUP INSTRUCTIONS

1. Unpack all components from the box.
2. Place the warmer base on a flat, stable, and heat-resistant surface.
3. Ensure the power cord is easily accessible and not obstructed.

6. OPERATING INSTRUCTIONS

For Wax Melts or Essential Oils:

1. Place the removable ceramic dish onto the warmer base.
2. Add your desired amount of scented wax cubes or essential oil (mixed with water) into the dish.
3. Plug the power cord into a suitable electrical outlet.
4. Flip the side switch to the 'ON' position. The front indicator light will illuminate, signifying that the warmer is active.
5. The wax or oil will begin to melt and release fragrance into your room.
6. To turn off, flip the side switch to the 'OFF' position and unplug the device when not in use.

For Warming Candle Jars or Beverages:

1. Remove the ceramic dish from the warmer base.
2. Place your candle jar (without lighting the wick) or a mug containing your beverage directly onto the heating plate of the warmer base.
3. Plug the power cord into a suitable electrical outlet.
4. Flip the side switch to the 'ON' position. The indicator light will illuminate.
5. The heating plate will warm your candle or beverage.
6. To turn off, flip the side switch to the 'OFF' position and unplug the device when not in use.

4 in 1 Ceramic Wax Melt Warmer



Essential Oils



Wax Cubes



Warm Coffee



Candle Jar

Figure 1: Versatile 4-in-1 usage of the Bobolyn Wax Melt Warmer.

Perfect Size for Any Space

- * Use with candles or wax melts
- * Stylish designs to complement your home decor
- * 4.5 foot cord with an on/off switch



Figure 2: Dimensions of the Bobolyn Wax Melt Warmer and its packaging.

Video 1: Official product overview demonstrating the Bobolyn Wax Melt Warmer's features and ease of use.

7. MAINTENANCE AND CLEANING

- Always unplug the warmer and allow it to cool completely before cleaning.
- To clean the removable ceramic dish: Once the wax has hardened, gently push on one side to pop out the solid wax. Wipe the dish with a soft, damp cloth. For essential oil residue, wash with warm soapy water.
- To clean the warmer base: Wipe the heating plate and exterior with a soft, damp cloth. Do not use abrasive cleaners.
- Ensure all parts are completely dry before reassembling or plugging in the warmer.

Video 2: Demonstration of how to easily clean the wax dish after use.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Warmer does not turn on.	Not plugged in; switch is off; power outage.	Ensure plug is securely in outlet; flip switch to 'ON'; check power supply.
Wax/Oil not melting or warming slowly.	Insufficient time; too much wax/oil.	Allow more time (typically 5-10 minutes); reduce amount of wax/oil.
No fragrance or weak fragrance.	Wax/Oil has lost scent; old wax/oil.	Replace with new wax melts or essential oil; ensure product is fresh.
Warmer gets very hot.	Normal operation; prolonged use.	This is normal. Always handle with care and keep away from children/pets. Unplug if not in use.

9. SPECIFICATIONS

- **Brand:** Bobolyn
- **Model Name:** e8518e53-f61c-4121-951e-536fe807bbd9
- **Color:** A-whitesmoke
- **Material:** Ceramic
- **Product Dimensions:** 4.5"L x 4.5"W x 3.3"H
- **Power Source:** Corded Electric
- **Wattage:** 20 watts
- **Coverage:** Medium to Large Room (approx. 40 Square Feet)
- **Special Feature:** 4-in-1 functionality (candle melts burner, electric fragrance warmer, wax burner, coffee mug warmer)

10. WARRANTY AND SUPPORT

Specific warranty information is not provided in this manual. For warranty details, product support, or further assistance, please refer to the product packaging or contact Bobolyn customer service directly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question