

[Manuals.plus](#) /

> [Lovehoney](#) /

> Lovehoney Glow Up Bullet Vibrator - User Instruction Manual

Lovehoney Glow Up

Lovehoney Glow Up Bullet Vibrator - User Instruction Manual

Model: Glow Up

1. INTRODUCTION

Thank you for choosing the Lovehoney Glow Up Bullet Vibrator. This compact and versatile personal massager is designed for targeted external stimulation. Please read this manual thoroughly before first use to ensure safe and optimal operation.





Image 1: The Lovehoney Glow Up Bullet Vibrator. This image displays the sleek, rose gold beige bullet vibrator, highlighting its compact and discreet design.

2. WHAT'S INCLUDED

- Lovehoney Glow Up Bullet Vibrator
- USB Charging Cable
- User Manual (this document)

3. SETUP AND CHARGING

Initial Charge

Before first use, fully charge your Lovehoney Glow Up Bullet Vibrator. The device is powered by an internal rechargeable Lithium-Ion battery.

1. Locate the charging port at the base of the vibrator. This is typically a small, discreet opening.
2. Insert the small end of the provided USB charging cable into the vibrator's charging port.
3. Connect the larger USB end of the cable to a compatible USB power source (e.g., computer USB port, USB wall adapter).
4. The indicator light on the vibrator will illuminate during charging.
5. Allow approximately **120 minutes** for a full charge. A full charge provides approximately **60 minutes** of playtime.




Image 2: The Lovehoney Glow Up Bullet Vibrator shown with its USB charging cable. This image illustrates how the device connects to the USB cable for recharging.

First Use Preparation

Before using the vibrator for the first time, and after each subsequent use, clean it thoroughly as described in the Maintenance section.

4. OPERATING INSTRUCTIONS

The Lovehoney Glow Up Bullet Vibrator features a simple single-button interface for ease of use.



**Easy-to-Use
Push Button**
for Uninterrupted
Solo or Couple's
Play

Image 3: A hand demonstrating how to press the easy-to-use button on the Lovehoney Glow Up Bullet Vibrator. This highlights the simple control mechanism.

Power On/Off

- To turn the vibrator **ON**, press and hold the power button for approximately **2 seconds**. The vibrator will start on its lowest setting.
- To turn the vibrator **OFF**, press and hold the power button for approximately **2 seconds** again.

Changing Vibration Modes

The vibrator offers **3 speeds** and **7 patterns** for a total of 10 functions.

- Once the vibrator is on, press the power button repeatedly to cycle through the different vibration speeds and patterns.
- Experiment with each setting to find your preferred intensity and rhythm.



Image 4: The Lovehoney Glow Up Bullet Vibrator, emphasizing its 3 vibration speeds and 7 patterns for diverse use.

Usage Tips

- The Glow Up Bullet Vibrator is designed for targeted external stimulation.
- For enhanced comfort and sensation, use with a high-quality water-based lubricant.
- This device is waterproof, allowing for use in the bath or shower.

**Discreet,
Petite and
Rechargeable**
Bullet Vibrator
for Clitoral
Stimulation



Image 5: The Lovehoney Glow Up Bullet Vibrator, highlighting its discreet, petite, and rechargeable features, ideal for clitoral stimulation.

Your browser does not support the video tag.

Video 1: Demonstration of the Lovehoney Glow Up Rechargeable Bullet Vibrator. This video provides a visual guide on how to use and charge the device, showcasing its features and compact size.

Your browser does not support the video tag.

Video 2: Overview of the Lovehoney Glow Up Bullet Vibrator. This video offers a concise demonstration of the vibrator's functionality, including its charging process and waterproof capabilities.

5. MAINTENANCE

Cleaning

Proper cleaning ensures hygiene and extends the lifespan of your vibrator.

- Always clean the vibrator before and after each use.
- Wash the device with warm water and a mild, toy-friendly soap or a specialized toy cleaner.
- Rinse thoroughly to remove all soap residue.
- Pat dry with a lint-free cloth or allow to air dry completely before storing.

Storage

- Store the vibrator in a clean, dry, and dust-free environment.
- Keep it away from extreme temperatures and direct sunlight.
- Avoid storing with other toys made of different materials to prevent potential damage or reactions.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Vibrator does not turn on.	Battery is depleted.	Charge the vibrator fully (refer to Section 3).
Vibrator does not charge.	Charging cable not properly connected or damaged.	Ensure the USB cable is securely plugged into both the vibrator and the power source. Try a different USB port or power adapter.
Vibrations are weak or inconsistent.	Low battery.	Recharge the vibrator.
Vibrator turns off shortly after turning on.	Battery issue or internal malfunction.	Ensure the device is fully charged. If the problem persists, contact customer support.

7. SPECIFICATIONS

- **Model:** Glow Up
- **Brand:** Lovehoney
- **Dimensions:** Approximately 3 inches in length
- **Material:** Plastic
- **Color:** Rose Gold Beige (as per product variant)
- **Power:** Rechargeable Lithium-Ion battery (included)
- **Charging Time:** 120 minutes
- **Playtime:** Up to 60 minutes on a full charge
- **Functions:** 3 speeds, 7 patterns (10 functions total)
- **Waterproof:** Yes



Image 6: A hand holding the Lovehoney Glow Up Bullet Vibrator, illustrating its compact 3-inch size, making it suitable for travel.

8. SAFETY INFORMATION

- This product is intended for adult use only.
- Discontinue use immediately if you experience any discomfort or pain.
- Do not use if the product appears damaged or faulty.
- Consult a healthcare professional if you have any concerns about using this product.
- Keep out of reach of children.

9. WARRANTY AND SUPPORT

Lovehoney products are manufactured to high-quality standards. For warranty information or customer support, please refer to the official Lovehoney website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

Manufacturer: Lovehoney

Date First Available: February 26, 2021

