

USHINING U181

USHINING U181 GSM Mobile Phone User Manual

Model: U181

1. INTRODUCTION

Thank you for choosing the USHINING U181 GSM Mobile Phone. This device is designed for ease of use, featuring large buttons, a clear display, and essential functions like calling, SMS, FM radio, and a flashlight. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your new phone.

2. PACKAGE CONTENTS

Please check the box for the following items:

- 1 x USHINING U181 Mobile Phone
- 1 x Micro USB Charger
- 1 x Battery (800 mAh)
- 1 x SIM Card Adapter
- 1 x User Manual (Español, English, Français, Italiano, Deutsch)



Image: The USHINING U181 mobile phone, charger, battery, SIM adapter, and user manual as included in the package.

3. DEVICE OVERVIEW

Familiarize yourself with the physical components of your USHINING U181 mobile phone.




Image: Front view of the USHINING U181 mobile phone, showing the screen, navigation buttons, and numeric keypad.



Image: Various angles of the USHINING U181 mobile phone, including front, back, and side profiles, highlighting its compact design.

4. SETUP

4.1. Inserting SIM Card(s) and Battery

1. Remove the back cover of the phone by gently prying it open from the notch.
2. If present, remove the battery.
3. Locate the SIM card slot(s). The phone supports dual SIM cards. Insert your SIM card(s) into the designated slot(s) with the gold contacts facing down.
4. Insert the 800 mAh battery into the battery compartment, ensuring the contacts align correctly.
5. Replace the back cover until it clicks into place.

Staying on standby



Durable Battery

Support dual card dual standby



SIM CARD



SIM CARD



Image: Diagram illustrating the insertion of the battery and dual SIM cards into the USHINING U181 mobile phone.

4.2. Charging the Phone

1. Connect the micro USB charger to the charging port located at the bottom of the phone.
2. Plug the charger into a power outlet.
3. The battery indicator on the screen will show the charging status. Allow the phone to charge fully before first use.

4.3. Powering On/Off

- **To Power On:** Press and hold the **Power/End Call** button (red button) until the screen lights up.
- **To Power Off:** Press and hold the **Power/End Call** button until the power-off options appear, then select 'Power off'.

4.4. Language Selection

Upon first power-on or after a factory reset, you may be prompted to select your preferred language. The phone supports Spanish, English, French, Italian, and German. Navigate using the directional keys and confirm with the central selection button.

5. OPERATING INSTRUCTIONS

5.1. Making and Receiving Calls

- **To Make a Call:** Enter the phone number using the keypad and press the **Call** button (green button).
- **To Answer a Call:** Press the **Call** button when the phone rings.
- **To End a Call:** Press the **Power/End Call** button.

5.2. Sending and Receiving SMS

- Navigate to the 'Messages' menu.
- Select 'Write message' to compose a new SMS.
- Enter the recipient's number or select from contacts, then type your message.
- Press 'Send'.

5.3. Using the LED Flashlight

The phone features a built-in LED flashlight for convenience.

- **To Turn On/Off:** Press and hold the central button with the flashlight icon on the keypad.



Image: The USHINING U181 mobile phone with its LED flashlight illuminated, demonstrating its brightness.

5.4. FM Radio

To use the FM radio, navigate to the 'FM Radio' application in the menu. You may need to connect headphones (not included) to act as an antenna for optimal reception.

5.5. MP3 Player

The phone supports MP3 playback. To use this feature, you will need to insert a microSD card (up to 32GB, not included) with MP3 files stored on it. Navigate to the 'MP3 Player' application in the menu.

5.6. Camera

The phone includes a basic camera. Access it through the 'Camera' option in the main menu. Photos are saved to the phone's internal memory or an inserted microSD card.

5.7. Alarm Clock, Calendar, Calculator

These utility functions can be accessed via the main menu. Set alarms, view dates, and perform basic calculations as needed.

5.8. Bluetooth Connectivity

The phone supports Bluetooth for connecting to compatible devices such as headsets. To activate and pair, go to 'Settings' > 'Bluetooth', turn it on, and search for available devices.

6. MAINTENANCE

6.1. Battery Care

- Avoid exposing the battery to extreme temperatures.
- Do not puncture or damage the battery.
- Use only the provided charger or a compatible micro USB charger.
- For optimal battery life, avoid frequent full discharges and charges.

Long standby time



Image: The USHINING U181 mobile phone displaying a full battery icon, indicating long standby time.

6.2. Cleaning

Wipe the phone with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials.

7. TROUBLESHOOTING

If you encounter issues with your phone, refer to the following common solutions:

| Problem | Possible Solution |
|------------------------------|--|
| Phone does not power on | Ensure the battery is correctly inserted and charged. Connect the charger and try again. |
| Cannot make or receive calls | Check if the SIM card is properly inserted and activated. Ensure you have network signal. |
| Battery drains quickly | Reduce screen brightness, close unused applications, or consider replacing an old battery. |

| Problem | Possible Solution |
|------------------------------------|--|
| No sound from speaker | Check volume settings. Ensure no headphones are connected. |
| Cannot connect to Bluetooth device | Ensure Bluetooth is enabled on both devices and they are in pairing mode. Check device compatibility. |

8. SPECIFICATIONS

Key technical specifications for the USHINING U181 mobile phone:

- **Model:** U181
- **Screen Size:** 1.77 inches
- **Operating System:** Android (basic feature phone OS)
- **RAM:** 4 MB
- **ROM:** 4 MB
- **Expandable Memory:** Up to 32 GB (via microSD card)
- **SIM Card Slots:** Dual SIM
- **Cellular Technology:** GSM Quad Band (850/900/1800/1900 MHz)
- **Connectivity:** Bluetooth, Micro USB
- **Battery:** 800 mAh Lithium-ion
- **Talk Time:** Up to 240 minutes
- **Standby Time:** Up to 150 hours
- **Special Features:** MP3 Player, Camera, FM Radio, LED Flashlight, Alarm Clock, Calculator
- **Languages:** Spanish, English, French, Italian, German

9. WARRANTY AND SUPPORT

USHINING provides comprehensive support for your mobile phone:

- **Warranty:** Two years of technical and customer service support from the date of purchase.
- **Exclusions:** Artificial damages are not covered under warranty.
- For technical assistance or customer service inquiries, please refer to the contact information provided with your purchase documentation or visit the official USHINING website.