

[Manuals.plus](#) /

> [Bestier](#) /

> Bestier 70-inch Mid-Century TV Stand with Sliding Doors (Model: B08P8S12WJ) - Instruction Manual

Bestier B08P8S12WJ

Bestier 70-inch Mid-Century TV Stand with Sliding Doors (Model: B08P8S12WJ) - Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Bestier 70-inch Mid-Century TV Stand. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The Bestier TV Stand is designed to accommodate most flat-screen TVs up to 80 inches, offering both open and enclosed storage with sliding doors and integrated cord management.

SAFETY INFORMATION

Always follow assembly instructions. Keep electrical components away from children. Ensure the product is properly assembled and stable to prevent tip-over risks.

Do not exceed the maximum weight capacity of 150 lbs for the top surface and 42 lbs per shelf. Distribute weight evenly.

PRODUCT OVERVIEW

The Bestier 70-inch Mid-Century TV Stand features a spacious desktop, sliding doors for flexible storage, and robust construction for durability.



Image: The Bestier 70-inch Mid-Century TV Stand, showcasing its design and functionality in a typical living room environment.

- **Large Desktop:** Accommodates most flat-screen TVs up to 80 inches.
- **Sliding Doors:** Two easy-to-move black doors provide flexible open and enclosed storage.
- **Cord Management:** Four pre-drilled holes in the back panel for organized cable routing.
- **High-Quality Material:** Constructed from P2 Hollow-Core Panel and P2 Particle Board, certified by CARB, with a faux uneven wood grain melamine finish.
- **Sturdy Support:** Supported by four tapered solid wood legs and two powder-coated metal legs for stability.

COMPONENTS AND DIMENSIONS

Before assembly, ensure all components are present and undamaged. Refer to the included parts list in your packaging for a complete inventory.



Image: Detailed view of the TV stand's key features, including the sliding door mechanism, solid wood feet, rear media holes for cables, and metal support legs.




Image: Technical drawing illustrating the overall dimensions of the TV stand (70" L x 15.6" W x 16" H) and the weight capacity for the top surface (150 lbs) and each internal shelf (20 lbs).

ASSEMBLY INSTRUCTIONS

Assembly of this TV stand is designed to be straightforward. All necessary tools are typically included, and parts are labeled for easy identification. Please follow the step-by-step illustrated instructions provided in your product packaging.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all parts against the included parts list.
2. **Assemble Frame:** Attach the side panels to the top and bottom boards using the provided hardware. Ensure all connections are secure.
3. **Install Support Legs:** Secure the tapered solid wood legs and metal support legs to the bottom of the stand.
4. **Insert Shelves:** Place the internal shelves into their designated slots.
5. **Attach Sliding Doors:** Carefully install the sliding doors onto the rail system.
6. **Final Check:** Ensure all screws are tightened and the stand is stable before placing any items on it.

Note: For detailed visual guidance, refer to the specific assembly diagrams included with your product.

OPERATING INSTRUCTIONS

- **Sliding Doors:** The two black doors are designed to slide smoothly along the front track. Gently push or pull the doors to adjust the visibility of the storage compartments.
- **Cord Management:** Utilize the four circular cutouts on the back panel to route cables from your electronic devices (TV, media players, game consoles) to power outlets, keeping them organized and out of sight.
- **Storage:** The open and enclosed compartments are suitable for storing media devices, books, and decorative items. Ensure items are placed within the weight limits of each shelf.

MAINTENANCE

- **Cleaning:** Wipe the surfaces with a dry, soft cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the wood grain melamine.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight and the stand is stable. Retighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading or discoloration of the finish.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Stand is wobbly or unstable.	Loose screws or uneven floor.	Ensure all assembly screws are fully tightened. Adjust the footpads on the metal legs if the floor is uneven.
Sliding doors do not move smoothly.	Debris in the track or misaligned doors.	Clean the sliding tracks of any dust or debris. Check if the doors are properly seated in the tracks.
Missing parts during assembly.	Packaging error.	Contact Bestier customer service with your product model and a list of missing parts.

SPECIFICATIONS

Feature	Detail
Brand	Bestier
Model Number	B08P8S12WJ
Product Dimensions	70" L x 15.6" W x 16" H
Item Weight	55 pounds
Material	Engineered Wood, Metal, Wood (P2 Hollow-Core Panel, P2 Particle Board)
Color	Brown
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth
Max TV Size	Up to 80 inches

Feature	Detail
Weight Capacity (Top)	150 lbs
Weight Capacity (Shelf)	42 lbs per shelf

PRODUCT VIDEO



Video: An official Bestier video showcasing various products, including a TV stand with LED lighting, highlighting adaptability and home integration. This video provides a general overview of Bestier's product philosophy and design.

WARRANTY AND CUSTOMER SUPPORT

Bestier is committed to providing professional customer service. If you encounter any problems with your product, please do not hesitate to contact us. Our team aims to respond within 24 hours to assist with any issues or concerns.

For specific warranty details, please refer to the documentation included with your purchase or visit the official Bestier website.

Contact information for customer support can typically be found on the Bestier website or on your purchase receipt.

