



Manuals.plus /

› GABRYLLY /

› GABRYLLY Ergonomic High-Back Office Chair Instruction Manual, Model G01

GABRYLLY G01

GABRYLLY Ergonomic High-Back Office Chair Instruction Manual

Model: G01

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your GABRYLLY Ergonomic High-Back Office Chair, Model G01. Please read this manual thoroughly before assembly and use to ensure proper function and safety.



Image: GABRYLLY Ergonomic High-Back Office Chair, showcasing its design and adjustable components.

SAFETY WARNINGS

To ensure the longevity and safe use of your chair, please observe the following precautions:

- Do not expose the chair to excessive water or liquids.
- Exercise caution when adjusting the headrest, backrest, and armrests to prevent injury.
- Always follow the assembly instructions carefully to ensure the chair's stability and safety.
- Do not exceed the maximum weight limit of 127 kg (280 lbs).

PRODUCT FEATURES

The GABRYLLY Ergonomic High-Back Office Chair is designed for comfort and support during long hours of use. Key features include:

- **Ergonomic Design:** Provides 4 points of support (head, back, hips, hands) and lumbar support,

conforming to your body's curve.

- **Adjustable Flip-Up Armrests:** Armrests can be folded up by 45 degrees and adjusted 1.8 inches up/down, allowing the chair to be pushed under a desk for space-saving.
- **Breathable Mesh Seat and Backrest:** High-quality, tear-resistant mesh promotes airflow, keeping you cool and comfortable.
- **Adjustable Headrest:** Easy height and angle adjustment (6 inches lift/down, 45 degrees rotate, forward/backward movement) for optimal neck support.
- **Tilt Function:** Allows the backrest to recline between 90° (work), 105° (rest), and 120° (read) with a locking mechanism.
- **Silent PU Wheels:** Smooth and quiet rolling, suitable for protecting wooden floors.
- **Sturdy Construction:** Robust five-star base and frame for durability and stability, supporting up to 127 kg (280 lbs).



Image: Ergonomic design highlighting five key support points for optimal posture.



Image: Breathable mesh seat promoting comfort and airflow.

SPECIFICATIONS

Feature	Value
Brand	GABRYLLY
Model Number	G01
Color	Black
Material	Polyurethane, Mesh
Product Dimensions (L x W x H)	49.07 x 64.01 x 115.06 cm (19.3 x 25.2 x 45.3 inches)
Seat Dimensions (W x D x H)	50.8 x 48.3 x 47 - 56.9 cm (20 x 19 x 18.5 - 22.4 inches)
Backrest Dimensions (W x H)	47 x 48 cm (18.5 x 18.9 inches)
Armrest Dimensions (W x H)	7.1 x 18.3 - 23.1 cm (2.8 x 7.2 - 9.1 inches)
Item Weight	18.6 kg (41 lbs)
Weight Capacity	127 kg (280 lbs)
Recommended User Height	1.5 m to 1.8 m (4'11" to 5'11")

FLEXIBLE FLIP-UP ARMS

For both office & home relaxation



Image: Detailed dimension data for the GABRYLLY office chair.

PACKAGE CONTENTS

- 1 x GABRYLLY Ergonomic Office Chair (disassembled)
- 1 x User Manual
- 1 x Screw Set
- 1 x Allen Key

SETUP AND ASSEMBLY

Assembly is straightforward and typically takes 15-20 minutes. All necessary tools and hardware are included.

Before You Begin

- Unpack all components and verify against the package contents list.
- Place all parts on a clean, soft surface to prevent scratches.
- Keep children and pets away from the assembly area.

Assembly Steps

1. Attach the casters to the five-star base by pushing them firmly into the holes.
2. Insert the gas lift cylinder into the center hole of the five-star base.
3. Attach the mechanism to the underside of the seat cushion using the provided screws and Allen key. Ensure the 'FRONT' marking on the mechanism (if present) faces the front of the seat.
4. Secure the armrests to the seat cushion using the designated screws.
5. Attach the backrest to the seat cushion/mechanism assembly.
6. Mount the headrest to the top of the backrest.
7. Carefully place the assembled seat and backrest onto the gas lift cylinder.
8. Test all adjustments to ensure proper function.

OPERATING INSTRUCTIONS

Chair Height Adjustment

To adjust the seat height, pull the lever located under the right side of the seat upwards.

- **To raise the seat:** Lift the lever while taking your weight off the seat.
- **To lower the seat:** Lift the lever while remaining seated.

Release the lever to lock the seat at the desired height.

Backrest Tilt and Lock

The chair features a tilt function allowing the backrest to recline between 90° (work), 105° (rest), and 120° (read).

- **To recline:** Pull the lever located under the left side of the seat outwards. Lean back to the desired angle.
- **To lock the tilt:** Push the lever inwards at your preferred angle.
- **To return to upright:** Pull the lever outwards, lean forward slightly, and then push the lever inwards to lock.



Image: Three-gear tilt back function for various activities.

Flip-Up Armrests Adjustment

The armrests can be flipped up to allow the chair to be pushed closer to your desk or for more freedom of movement. They also offer 1.8 inches of vertical adjustment.

- **To flip up:** Press the black buttons on the side of each armrest and rotate them upwards. They will lock into the upright position.
- **To lower:** Press the black buttons again and rotate the armrests downwards until they lock into the horizontal position.



Image: Detailed view of the 45-degree flip-up armrest mechanism.

Headrest Adjustment

The headrest can be adjusted for height, angle, and depth to provide optimal neck and head support.

- **Height Adjustment:** Gently pull the headrest up or push it down to adjust its height (up to 6 inches).
- **Angle Adjustment:** Rotate the headrest to achieve your preferred angle (up to 45 degrees).
- **Depth Adjustment:** Press the two buttons on the sides of the headrest support to move it forward or backward.



Image: Customizable head support adjustments for height, angle, and depth.

MAINTENANCE

- **Cleaning:** Wipe the mesh and plastic parts with a damp cloth. For stubborn stains, use a mild soap solution and dry immediately. Avoid harsh chemicals.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary.
- **Casters:** Keep the casters clean from hair and debris to ensure smooth rolling.
- **Avoid Overloading:** Do not exceed the maximum weight capacity of 127 kg (280 lbs).

TROUBLESHOOTING

Chair Does Not Adjust Height

- Ensure the gas lift lever is fully engaged.
- Check if the gas lift cylinder is properly seated in the base and mechanism.
- If the gas lift is faulty, contact customer support for a replacement.

Chair Squeaks or Wobbles

- Tighten all assembly screws. Loose connections are a common cause of squeaking or wobbling.
- Apply a small amount of silicone lubricant to moving parts if squeaking persists.

Casters Not Rolling Smoothly

- Remove any hair, dust, or debris from the caster wheels.
- Ensure the casters are securely inserted into the chair base.

WARRANTY AND SUPPORT

GABRYLLY offers a **5-year warranty** for this mesh chair.

For any missing parts, functional issues, or warranty claims, please contact the GABRYLLY customer support team directly. Refer to the warranty card included in your package for contact details.

If you require a shorter gas lift cylinder for users under 1.5m (4'11"), please contact GABRYLLY customer support.