Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

E-YOOSO Z88

E-YOOSO Z88 81-Key Compact Mechanical Gaming Keyboard User Manual

Model: Z88

Product Overview

The E-YOOSO Z88 is an 81-key compact mechanical gaming keyboard designed for efficiency and performance. It features Outemu brown switches, customizable rainbow LED backlighting, and N-key rollover for an enhanced typing and gaming experience. Its durable construction and ergonomic design ensure comfort and longevity.



Figure 1: E-YOOSO Z88 Compact Gaming Keyboard, highlighting its small and portable 81-key layout and detachable Type-C data cable.

Package Contents

- E-YOOSO Z88 Mechanical Keyboard x 1
- USB Cable (detachable, 1.8m) x 1
- Keycap Puller x 1
- User Manual x 1

Setup Instructions

1. **Unpack the Keyboard:** Carefully remove the keyboard and its accessories from the packaging.
2. **Connect the USB Cable:** Insert the detachable USB cable into the Type-C port on the keyboard and the other end into an available USB port on your computer.
3. **Plug and Play:** The keyboard is plug-and-play. No additional drivers are required for basic functionality. Your

operating system should automatically detect and install the necessary drivers.

4. **Position the Keyboard:** Place the keyboard on a stable, flat surface. Adjust the kickstands on the back of the keyboard for your preferred typing angle, if available.

Operating Instructions

Key Features

- **Outemu Brown Switches:** These mechanical switches provide a tactile bump and audible click feedback, offering a responsive and satisfying typing experience. They are designed for durability with a lifespan of over 50 million keystrokes.
- **81-Key Anti-Ghosting:** Each key is independently controlled, ensuring that multiple simultaneous key presses are registered accurately without conflicts, which is crucial for gaming.
- **Compact Design:** The 81-key layout saves desk space while retaining essential functionality.



Figure 2: Close-up view of the E-YOOSO Z88 keyboard's Outemu Brown mechanical switches, known for their tactile feedback and

durability.



Figure 3: Illustration of the E-YOOSO Z88 keyboard's full anti-ghosting capability, ensuring all 81 keys register correctly during rapid input.



Figure 4: The compact 81-key layout of the E-YOOSO Z88, demonstrating its space-saving design and ergonomic keycap profile.

Backlight Control

The keyboard features a rainbow LED backlight with multiple modes and adjustable settings.

- **Change Backlight Mode:** Press **FN + PGDN** to cycle through 9 different backlight modes.
- **Adjust Brightness:** Use **FN +** ↑ (Up Arrow) to increase brightness and **FN +** ↓ (Down Arrow) to decrease brightness.
- **Adjust Breathing Speed:** Use **FN +** ← (Left Arrow) to decrease breathing speed and **FN +** → (Right Arrow) to increase breathing speed.



Figure 5: The E-YOOSO Z88 keyboard displaying its vibrant multi-mode rainbow LED backlighting.

Function Shortcut Keys (FN Combinations)

The keyboard utilizes the FN key to access various multimedia and system functions. Press and hold the **FN** key, then press the desired function key.

FN Key Combinations

Combination	Function
FN + F1	My Computer / Desktop
FN + F2	Web Browser
FN + F3	Email
FN + F4	Media Player

Combination	Function
FN + F5	Previous Track
FN + F6	Next Track
FN + F7	Play/Pause
FN + F8	Stop
FN + F9	Mute
FN + F10	Volume Down
FN + F11	Volume Up
FN + F12	Calculator
FN + Win	Lock/Unlock Windows Key (prevents accidental presses during gaming)

Maintenance

- **Cleaning Keycaps:** Use the included keycap puller to carefully remove keycaps. Clean them with a soft, damp cloth and mild soap if necessary. Ensure they are completely dry before reattaching.
- **Cleaning the Keyboard Base:** Use compressed air to remove dust and debris from between the switches. Wipe the surface with a soft, dry cloth.
- **Spill Resistance:** The keyboard features a splash-proof design. In case of accidental spills, immediately disconnect the keyboard from your computer, wipe off any liquid, and allow it to dry completely before reconnecting.
- **Cable Management:** The detachable USB cable can be replaced if damaged. Ensure the cable is not kinked or strained during use.

Troubleshooting

Common Issues and Solutions

Problem	Possible Cause	Solution
Keyboard not responding	Loose USB connection, faulty USB port, driver issue.	◦ Ensure the USB cable is securely connected to both the keyboard and the computer. ◦ Try a different USB port on your computer. ◦ Test the keyboard on another computer to rule out system-specific issues. ◦ Restart your computer.
Backlight not working or stuck	Backlight turned off, brightness set to minimum, software glitch.	◦ Press **FN + ↑** to increase brightness. ◦ Cycle through backlight modes using **FN + PGDN**. ◦ Disconnect and reconnect the keyboard.

Problem	Possible Cause	Solution
Keys not registering or ghosting	Dust/debris under keycap, switch malfunction, software conflict.	◦ Remove the keycap and clean the switch area with compressed air. ◦ Ensure N-key rollover is functioning (it's a hardware feature, but check for any software that might interfere). ◦ If a specific switch is faulty, it may require replacement (Outemu switches are hot-swappable).
FN shortcut keys not working	Incorrect key combination, software conflict.	◦ Ensure you are pressing and holding **FN** before pressing the function key. ◦ Check for any third-party software that might override keyboard functions.

If you encounter any quality or usage issues not covered here, please contact customer support.

Specifications

Feature	Detail
Brand	E-YOOSO (Gishine)
Model Name	Z88
Number of Keys	81
Switch Type	Outemu Brown Mechanical Switches (Tactile)
Key Durability	Up to 50 million clicks
Backlight	Rainbow LED (9 modes, adjustable brightness/speed)
Anti-Ghosting	N-Key Rollover
Connectivity	USB (Detachable 1.8m cable)
Material	ABS, Metal Base
Features	Ergonomic design, splash-proof, hot-swappable switches (Outemu 3-pin)
Compatibility	Windows 10/8/7/XP, Windows VISTA, Mac OS X
Weight	0.7 kg
UPC	723509313821
ASIN	B08PCVMHCS

Warranty and Support

This product comes with a standard manufacturer's warranty. For specific warranty terms and duration, please refer to the documentation included with your purchase or contact the seller directly.
Customer Support: If you experience any quality issues or require assistance with the product, please contact the seller via the messaging system on the platform where you made your purchase. Provide your order number and a detailed

description of the issue for prompt support.
For general inquiries or further information, you may also visit theproduct page.

© 2023 E-YOOSO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08PCVMHCS

More documents and user manuals: **https://manuals.plus/**