

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [RockJam](#) /

› [RockJam RJ10WAR2 Electric Guitar Amplifier User Manual](#)

RockJam RJ10WAR2

RockJam RJ10WAR2 Electric Guitar Amplifier User Manual

Model: RJ10WAR2 | Brand: RockJam

1. INTRODUCTION

Thank you for purchasing the RockJam RJ10WAR2 10 Watt Electric Guitar Amplifier. This compact and versatile amplifier is designed to provide excellent sound quality for practice sessions and small performances. Featuring a three-band equalizer, overdrive, and gain functions, it allows for extensive sound customization. The headphone output enables private practice, making it an ideal choice for musicians of all levels.

2. SAFETY INFORMATION

Please read and understand all safety instructions before operating this amplifier. Retain this manual for future reference.

- Do not expose the amplifier to rain or moisture.
- Do not block any ventilation openings.
- Ensure the power cord is not walked on or pinched.
- Unplug the amplifier during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.
- Do not attempt to modify or repair the unit yourself.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- RockJam RJ10WAR2 10 Watt Electric Guitar Amplifier
- Power Cable
- User Manual (this document)

4. PRODUCT OVERVIEW

Familiarize yourself with the various components and controls of your RockJam amplifier.

4.1 Front Panel Controls



Image: Amplifier Control Panel. This image displays a detailed view of the amplifier's top control panel, highlighting the power switch, guitar input jack, LED indicator, and the various control knobs for adjusting the sound: Gain, Boost, Volume, and Treble. The headphone output jack is also visible on the right.



Image: Front View. This image provides a clear front view of the RockJam RJ10WAR2 amplifier, showcasing its speaker grille, the prominent RockJam logo, and the top-mounted control panel.

- **POWER Switch:** Turns the amplifier on or off.
- **GUITAR Input:** 1/4-inch jack for connecting your electric guitar.
- **LED Indicator:** Illuminates when the amplifier is powered on.
- **GAIN Knob:** Controls the amount of pre-amplification and distortion. Higher settings produce more overdrive.
- **BOOST Switch:** Engages an additional gain stage for a more aggressive, distorted tone.

- **VOLUME Knob:** Adjusts the overall output level of the amplifier.
- **TREBLE Knob:** Controls the high-frequency response of the amplifier.
- **PHONES Output:** 3.5mm (1/8-inch) stereo jack for connecting headphones for silent practice. Connecting headphones mutes the main speaker.

4.2 Rear Panel



Image: Rear View. This image shows the back of the amplifier, clearly displaying the IEC power inlet where the detachable power cable

connects.

- **Power Inlet:** Connects the supplied power cable to the amplifier.

4.3 Overall Design



Image: Amplifier with Power Cable. This image provides an angled top-down view of the RockJam RJ10WAR2 amplifier, including its power cable. It highlights the amplifier's compact black design and the layout of its top-mounted controls.



Image: Side View with Carry Handle. This image shows a side profile of the RockJam RJ10WAR2 amplifier, emphasizing the convenient integrated carry handle designed for easy portability.



Image: RockJam Logo and Speaker Detail. This close-up image focuses on the RockJam logo and the texture of the speaker grille on the amplifier's front panel, showcasing the build quality.

5. SETUP

- Placement:** Place the amplifier on a stable, flat surface. Ensure there is adequate ventilation around the unit.
- Power Connection:** Connect the supplied power cable to the power inlet on the rear of the amplifier and then plug the other end into a suitable wall outlet.
- Guitar Connection:** Ensure the amplifier is turned OFF. Plug one end of a standard 1/4-inch instrument cable into your electric guitar and the other end into the "GUITAR" input jack on the amplifier's front panel.
- Headphone Connection (Optional):** If you wish to practice silently, plug your 3.5mm (1/8-inch) headphones into the "PHONES" output jack. This will automatically mute the main speaker.
- Initial Settings:** Before turning on, set the GAIN, BOOST, VOLUME, and TREBLE knobs to their minimum (counter-clockwise) positions.

6. OPERATING INSTRUCTIONS

- Power On:** Flip the "POWER" switch to the ON position. The LED indicator will illuminate.
- Adjust Volume:** Slowly turn the "VOLUME" knob clockwise to achieve your desired listening level.
- Adjust Gain:** The "GAIN" knob controls the amount of distortion. Turn it clockwise for more overdrive. For a clean tone, keep the GAIN low.
- Use Boost:** Engage the "BOOST" switch for an additional level of distortion and sustain, ideal for rock and metal tones. Disengage for a cleaner or less aggressive sound.
- Tone Shaping (Treble):** Use the "TREBLE" knob to adjust the brightness of your sound. Turn clockwise to increase high frequencies for a sharper tone, or counter-clockwise to reduce them for a warmer sound.
- Experimentation:** Experiment with different combinations of GAIN, BOOST, VOLUME, and TREBLE settings to find your preferred sound. Remember that your guitar's volume and tone controls also significantly impact the amplifier's output.
- Power Off:** When finished, turn the "VOLUME" knob to minimum, then flip the "POWER" switch to the OFF position.

7. MAINTENANCE

- Cleaning:** Wipe the amplifier's exterior with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Storage:** Store the amplifier in a cool, dry place away from direct sunlight and extreme temperatures.
- Ventilation:** Ensure the ventilation openings are clear of dust and debris to prevent overheating.
- Cable Care:** Always unplug cables by gripping the connector, not the cable itself, to prevent damage.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from amplifier.	Amplifier not powered on. Volume knob set too low. Headphones plugged in. Guitar cable faulty or not connected. Guitar volume knob set too low.	Ensure POWER switch is ON and LED is lit. Increase VOLUME knob. Unplug headphones. Check guitar cable connections; try a different cable. Increase guitar's volume knob.
Distorted or unclear sound.	GAIN knob set too high for desired tone. BOOST switch engaged for clean tone. Faulty guitar cable or guitar electronics.	Reduce GAIN knob. Disengage BOOST switch for cleaner sound. Test with a different cable or guitar.
Humming or buzzing noise.	Ground loop issue. Interference from other electronics. Faulty cable.	Try plugging into a different power outlet. Move amplifier away from other electronic devices. Try a different guitar cable.

9. SPECIFICATIONS

Feature	Detail
Model Number	RJ10WAR2
Output Wattage	10 Watts RMS
Colour	Black
Compatible Devices	Guitar, Drum (universal input)
Headphone Output	3.5mm Jack
Controls	Power, Guitar Input, LED, Gain, Boost, Volume, Treble, Phones
Power Source	Electric
Item Weight	2 kg
Package Dimensions	34.29 x 26.5 x 17.2 cm

10. WARRANTY AND SUPPORT

RockJam products are designed for reliability and performance. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official RockJam website. Please have your model number (RJ10WAR2) and purchase details ready when contacting support.



For additional resources and product information, you may visit the [RockJam Store on Amazon](#).

© 2025 RockJam. All rights reserved.

This manual is subject to change without notice.

Related Documents - RJ10WAR2

 <p>RockJam Guitar Beginner's Guide: Parts, Tuning, and First Chords</p>	<p>Learn to play your RockJam acoustic guitar with this comprehensive beginner's guide. Covers guitar parts, tuning methods, and how to play the essential E, A, and D chords.</p>
 <p>RockJam Electric Guitar Assembly & Tuning Guide</p>	<p>Comprehensive assembly, tuning, and maintenance instructions for the RockJam Electric Guitar. Learn how to set up your guitar, replace strings, adjust the neck, and care for your instrument. Includes FCC compliance information.</p>

	<p><u>RockJam Electric Guitar: Simple Assembly, Tuning, and Care Guide</u></p> <p>Comprehensive assembly instructions and care guide for the RockJam Electric Guitar. Learn how to set up, tune, and maintain your electric guitar, including details on components, string replacement, and important safety precautions. This guide also covers FCC compliance and product disposal information.</p>
	<p><u>RockJam Karaoke Super Kit RJKSK User Guide</u></p> <p>User guide for the RockJam Karaoke Super Kit (RJKSK), providing setup, operation, and troubleshooting instructions for the Bluetooth-enabled karaoke machine.</p>
 <p>61 Key Multi-function Keyboard User Guide</p>	<p><u>RockJam RJ6170 61 Key Multi-function Keyboard User Guide</u></p> <p>This user guide provides comprehensive instructions for the RockJam RJ6170 61 Key Multi-function Keyboard, covering setup, operation, features, and troubleshooting.</p>
 <p>RockJam RJ654 54 Key Keyboard Piano User Manual</p>	<p><u>RockJam RJ654 54 Key Keyboard Piano User Manual</u></p> <p>Comprehensive user guide for the RockJam RJ654 54-key keyboard piano, covering setup, operation, features, and maintenance.</p>