

One For All URC4913

One For All URC4913 Remote Control for Philips User Manual

INTRODUCTION

This manual provides comprehensive instructions for the One For All URC4913 Remote Control, specifically designed for Philips televisions. It covers initial setup, operational guidance, maintenance, and troubleshooting to ensure optimal performance and user experience.

SETUP

Battery Installation

To begin using your One For All URC4913 remote control, you must first install the batteries. This remote requires two AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards and remove it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.





Image: Back of the URC4913 remote control with the battery compartment open.

Initial Use

The One For All URC4913 remote control is pre-programmed for Philips TVs. In most cases, no setup is

required. Simply insert the batteries, and the remote should function immediately with your Philips television.

If the remote does not respond to your TV, please refer to the 'Troubleshooting' section or the 'Learning Feature' for advanced customization.

OPERATING INSTRUCTIONS

Basic Functions

The URC4913 remote control provides all standard functions of an original Philips TV remote. Familiarize yourself with the button layout:





Image: Front view of the URC4913 remote control.

- **Power Button:** Located at the top, turns the TV on or off.
- **Navigation Pad (OK, Up, Down, Left, Right):** Used for menu navigation and selection.
- **Volume Up/Down (+/-):** Adjusts the TV volume.
- **Channel Up/Down (P+/-):** Changes TV channels.
- **Mute Button:** Silences the TV audio.
- **Number Buttons (0-9):** For direct channel input.
- **Menu/Home Button:** Accesses the TV's main menu or home screen.
- **Exit Button:** Exits current menu or application.

Special Features

- **App Direct Keys:** Dedicated buttons for popular streaming services such as Prime Video, YouTube, and Netflix provide quick access.
- **Ambilight Button:** Activates or adjusts the Ambilight feature on compatible Philips TVs.
- **Learning Feature:** This remote can learn functions from your original remote control. This allows for full customization and ensures compatibility with any unique functions your original remote may have. Refer to the detailed instructions in the full product manual for specific steps on using the learning feature.

Product Usage Demonstration

Your browser does not support the video tag.

Video: A demonstration of the One For All URC4913 remote control's features and compatibility with Philips TVs, including quick access buttons and general operation.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Avoid using abrasive cleaners or solvents, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries or different types of batteries.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

TROUBLESHOOTING

- **Remote not working:**
 - Check if the batteries are inserted correctly with the correct polarity.
 - Replace old batteries with new ones.
 - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
 - Confirm the remote is pointed directly at the TV.
- **Certain buttons not working:**
 - If specific buttons do not function, try using the learning feature to copy the function from your original remote.
 - Ensure the button is not physically stuck or damaged.
- **Remote controls other devices:**
 - This remote is specifically for Philips TVs. If it is inadvertently controlling other devices, ensure no other universal remotes are active or interfering.

SPECIFICATIONS







Feature	Detail
Brand	One For All
Model	URC4913
Compatible Devices	Philips TVs (LCD, LED, Plasma)
Connectivity Technology	Infrared
Number of Buttons	47
Power Source	2 x AAA Batteries (not included)
Dimensions	19.5 x 4.4 x 2.5 cm
Weight	138 g
Special Features	Universal, Learning Function, App Direct Keys

WARRANTY AND SUPPORT

For warranty information, technical support, or further assistance, please refer to the official One For All

website or contact their customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

Related Documents - URC4913

	<p>One For All URC 1913 Universal Remote Control Setup and User Guide</p> <p>Detailed instructions for setting up and using the One For All URC 1913 universal remote control with Philips televisions. Covers direct setup, troubleshooting, and learning new functions.</p>
	<p>One For All URC 6810 Universal Remote Setup Guide Learn & Code Programming</p> <p>Comprehensive setup guide for the One For All URC 6810 universal remote. Learn how to program your remote using learning or code methods, control multiple devices, and utilize advanced features.</p>
	<p>One For All OARC04G 4-Device Universal Remote Control User Guide</p> <p>Comprehensive user guide for the One For All OARC04G 4-Device Universal Remote Control. Learn how to install batteries, set up the remote using direct code or search methods, understand keypad functions, use extra features like macros and volume punch through, troubleshoot common issues, and find warranty information.</p>
	<p>One For All URC 7880 Universal Remote Control Simple Setup Guide</p> <p>The One For All URC 7880 is a universal remote control designed to simplify home entertainment. This guide provides comprehensive instructions for setup, including SimpleSet and code-based programming, learning functions, configuring activities, programming macros, and utilizing app shortcuts. It supports a wide range of Audio/Video devices like TVs, Set Top Boxes, Blu-ray/DVD players, audio systems, game consoles, and sound bars from numerous brands, ensuring seamless control and customization.</p>
	<p>ONE FOR ALL URC1211 Essence TV Universal Remote Control User Manual</p> <p>User manual for the ONE FOR ALL URC1211 Essence TV Universal Remote Control. Learn how to set up, use, and program your remote for seamless control of your entertainment devices.</p>
	<p>One For All URC 9800 Home Producer User Guide</p> <p>Explore the features and setup instructions for the One For All URC 9800 Home Producer universal remote control. This user guide covers programming, macros, and optimizing your home entertainment system.</p>

