

[manuals.plus](#) /

› [Cellet](#) /

› [Cellet EB600 Wireless Bluetooth Earbuds User Manual](#)

Cellet EB600

Cellet EB600 Wireless Bluetooth Earbuds User Manual

Model: EB600

1. PRODUCT OVERVIEW

The Cellet EB600 Wireless Bluetooth Earbuds offer a high-quality audio experience with convenient wireless connectivity. Designed for comfort and portability, these earbuds feature Bluetooth V5.0 technology for stable connections, noise isolation, and built-in microphones for clear communication. The included charging case ensures your earbuds are always ready for use.



Image 1.1: Cellet EB600 Wireless Bluetooth Earbuds shown with their charging case.

2. PACKAGE CONTENTS

Please check the package for the following items:


- Cellet EB600 Wireless Bluetooth Earbuds (Left and Right)
- Portable Charging/Storage Case
- USB-C Charging Cable
- Earbud Tips (Small, Medium, Large sizes)
- User Manual



Charging case



Earbuds



User's guide



Type-C Charging cable



Large



Ear caps

Image 2.1: All items included in the Cellet EB600 package: charging case, earbuds, user guide, Type-C charging cable, and ear caps in various sizes.

3. SETUP AND INITIAL USE

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the USB-C charging cable to the charging case and a power source. The LED indicators on the case will show the charging status.

COMPATIBLE TO

IPHONE 11, 11 PRO, 11 PRO MAX XS MAX, XS, XR, 8/8 PLUS,
SAMSUNG GALAXY NOTE 9, NOTE 8, GALAXY S10/S10 PLUS/ S10E, LG V30S THIN Q, LG V30,
GOOGLE PIXEL 2, PIXEL 2 XL, IPODS, IPADS, TABLETS AND OTHER WIRELESS ENABLED DEVICES



Image 3.1: The charging case with earbuds inserted, illustrating the charging process.

The charging case has a battery capacity of 300mAh, providing multiple charges for the earbuds. Earbuds have 45mAh batteries each. Charging time for the case is approximately 1.5 hours.

3.2 Initial Pairing with a Device

1. Remove both earbuds from the charging case. They will automatically power on. A blue light will indicate they are active.
2. Wait for the voice prompt "Pairing, Left Channel, Right Channel." This confirms the earbuds are synced with each other.
3. On your device (smartphone, tablet, etc.), go to the Bluetooth settings menu.
4. Search for available devices and select "Cellet_EB600" from the list.
5. Once connected, both earbuds will flash blue approximately every 8 seconds, indicating a successful connection.



Image 3.2: Examples of earbud usage, including answering calls while driving, listening to music, and cycling.

4. OPERATING INSTRUCTIONS

4.1 Multifunctional Button Controls

Each earbud features a multifunctional button for easy control of music and calls.

- **Play/Pause Music:** Single press the button on either earbud.
- **Answer/End Call:** Single press the button on either earbud during an incoming call.
- **Reject Call:** Press and hold the button on either earbud during an incoming call.
- **Activate Voice Notifications:** (Specific action not detailed, typically a long press or double-tap depending on device/earbud model).

LED POWER INDICATORS ON CHARGING CASE AND EARBUDS



Image 4.1: Detailed view of the charging case and earbuds, highlighting the LED power indicators and the location of the multifunctional buttons on both the left and right earbuds.

4.2 Voice Notifications

The earbuds provide voice notifications for incoming calls, battery level, and pairing status, enhancing user convenience.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the earbuds and charging case. Do not use harsh chemicals or abrasive materials.
- **Ear Tips:** Regularly remove and clean the ear tips to prevent wax buildup, which can affect sound quality.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Water Resistance:** The earbuds have an IPX5 waterproof rating, meaning they are resistant to splashes and sweat. Do not submerge them in water.

6. TROUBLESHOOTING

- **Earbuds not pairing with each other:** Ensure both earbuds are removed from the case

simultaneously. If they don't sync, place them back in the case, then remove them again.

- **Earbuds not connecting to device:**

- Ensure Bluetooth is enabled on your device.
- Check if "Cellt_EB600" appears in your device's Bluetooth list.
- If previously paired, try "forgetting" the device in your Bluetooth settings and re-pairing.
- Ensure earbuds are charged.

- **No sound from one earbud:**

- Ensure both earbuds are charged and properly synced.
- Try resetting the earbuds by placing them back in the case and removing them.

- **Poor sound quality:**

- Ensure earbuds are clean and ear tips are correctly sized for a good seal.
- Check the distance between earbuds and your device; maintain within 10 meters (33 feet).

7. SPECIFICATIONS


Feature	Detail
Model Name	EB600 (also referred to as XG01 in some specifications)
Bluetooth Version	V5.0
Wireless Communication Technology	Bluetooth
Connectivity Technology	Wireless
Earbud Battery Capacity	45mAh * 2
Charging Case Battery Capacity	300mAh
Charging Time (Case)	Approx. 1.5 hours
Music Playback Time	3-4 hours
Talk Time	3-4 hours
Standby Time	150 hours
Wireless Range	10 meters (33 feet)
Waterproof Level	IPX5
Noise Control	Active Noise Cancellation (Noise-isolating earbuds)
Microphone	Built-in Dual Microphones
Control Method	Touch (Multifunctional Button)
Item Weight	4 ounces
Product Dimensions	1 x 1 x 1 inches (earbuds)

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact the manufacturer directly. Contact details can typically be found on the product packaging or the manufacturer's official website.

© 2025 Cellet. All rights reserved.

Related Documents - EB600

	<p>Champion EB600 Egg Cooker - Healthy Stainless Steel Cooking</p> <p>Discover the Champion EB600 Egg Cooker, a healthy and efficient way to cook eggs using stainless steel. Features a 400W power, 1-7 egg capacity, 30-minute timer, automatic shut-off, and included accessories. Learn more about its specifications and benefits.</p>
	<p>EcoFlow RIVER 3 Plus Portable Power Station User Manual & Specifications</p> <p>Detailed user manual and technical specifications for the EcoFlow RIVER 3 Plus portable power station, covering models EB300 (286Wh) and EB600 (572Wh). Includes features, port details, battery information, operating temperatures, and compliance statements (FCC, IC, CE, RoHS, WEEE).</p>
	<p>EcoFlow RIVER 3 Plus Smart Extra Battery User Manual</p> <p>Comprehensive user manual for the EcoFlow RIVER 3 Plus Smart Extra Battery, covering specifications, operation, safety, storage, maintenance, and regulatory compliance for models EB300 (286Wh) and EB600 (572Wh).</p>
	<p>SanMar Sports Fishing & Outdoor Apparel Catalog</p> <p>Discover a curated selection of fishing and outdoor apparel from top brands including Carhartt, Eddie Bauer, Port Authority, Sport-Tek, Cornerstone Workwear, and New Era, available through SanMar Sports.</p>
	<p>NUUO IP Camera Integration List</p> <p>A comprehensive compatibility list detailing NUUO's IP camera integration, including supported models and firmware versions from various manufacturers for NUUO's video management systems.</p>

