

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Cellet](#) /
- › [Cellet Wireless V5 Bluetooth Earbuds \(Model XG01\) User Manual](#)

Cellet XG01

Cellet Wireless V5 Bluetooth Earbuds (Model XG01) User Manual

Brand: Cellet | Model: XG01

INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your Cellet Wireless V5 Bluetooth Earbuds, Model XG01. Please read this guide thoroughly before using the product to ensure optimal performance and longevity.

**ULTRA-SMALL AND LIGHTWEIGHT
EARBUDS WITH HIGH QUALITY SOUNDS**



Figure 1: Earbud in Use. This image illustrates the compact design of the earbud when worn, highlighting its in-ear placement.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Wireless V5 Bluetooth Earbuds (Left and Right)
- Charging/Storage Case
- USB-C Charging Cable
- Earbud Tips (Small, Medium, Large)
- User Manual (this document)



Figure 2: Package Contents. The image displays the earbuds, charging case, USB-C charging cable, and various sizes of ear tips included in the package.

PRODUCT OVERVIEW

Familiarize yourself with the components of your earbuds and charging case.

LED POWER INDICATORS ON CHARGING CASE AND EARBUDS



Figure 3: Earbud and Case Features. This diagram highlights the LED power indicators on both the charging case and the earbuds, as well as the multi-function buttons on each earbud.

Key Features:

- **Multi-function Button:** Located on each earbud for controlling music, calls, and voice notifications.
- **LED Power Indicators:** On the charging case and earbuds to show power status.
- **Built-in Microphones:** For clear communication during calls.
- **Charging Contacts:** Inside the case for earbud charging.
- **USB-C Port:** On the charging case for recharging the case.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge both the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated, and the LED indicators on the earbuds light up, indicating charging.
2. Connect the USB-C charging cable to the charging port on the case and the other end to a USB power source (e.g., wall adapter, computer USB port).
3. The LED indicator on the charging case will show charging status. Once fully charged, the indicator may change color or turn off.

CONVENIENT CHARGING/STORAGE CASE

Bluetooth Version: V5.0
Bluetooth Distance: 10M
Earbuds Battery: 45mAh*2
Waterproof Level: IPX5

Charging Case Battery: 300mAh
Charging Time: About 1.5 hours
Music Playing Time: 3-4 hours
Calling Talk Time: 3-4 hours



Figure 4: Charging the Earbuds and Case. The earbuds are shown inside the charging case, which is being charged via a USB-C cable. The image also displays battery specifications and charging times.

Charging Time: Approximately 1.5 hours for the case. Earbuds charge when placed in the case.

2. Pairing with Your Device

Follow these steps to connect your earbuds to a Bluetooth-enabled device:

1. **Power On:** Remove both earbuds from the charging case. They will automatically power on, and a blue light will indicate this.
2. **Automatic Pairing:** The earbuds will automatically sync with each other. You will hear voice prompts such as "Pairing, Left Channel, Right Channel," confirming they are synced.
3. **Bluetooth Search:** On your device (smartphone, tablet, etc.), go to the Bluetooth settings and enable Bluetooth.
4. **Connect:** Search for "Cellet_EB600" in the list of available devices and select it to connect.
5. **Confirmation:** Once connected, both earbuds will flash blue approximately every 8 seconds, indicating a successful connection.

If pairing fails, place the earbuds back into the charging case, close the lid, and then repeat the steps.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Remove earbuds from the charging case. They will power on automatically.
- **Power Off:** Place earbuds back into the charging case. They will power off automatically and begin charging.

Music Playback

Use the multi-function button on either earbud:

- **Play/Pause:** Single press the multi-function button.
- **Next Track:** Double press the multi-function button on the right earbud.
- **Previous Track:** Double press the multi-function button on the left earbud.

Call Management

Use the multi-function button on either earbud:

- **Answer Call:** Single press the multi-function button when an incoming call rings.
- **End Call:** Single press the multi-function button during a call.
- **Reject Call:** Press and hold the multi-function button for 2 seconds when an incoming call rings.



Figure 5: Earbuds in Use. This image demonstrates the versatility of the earbuds for activities such as listening to music

while cycling or taking calls while driving.

Voice Notifications

The earbuds provide voice notifications for:

- Incoming calls
- Battery level status
- Successful pairing with your device

MAINTENANCE

To ensure the longevity and optimal performance of your earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Avoid Water:** While the earbuds have an IPX5 waterproof level, avoid submerging them in water. Clean any moisture immediately.
- **Temperature:** Do not expose the earbuds or charging case to extreme temperatures (hot or cold).
- **Charging:** Use only the provided USB-C cable for charging.

TROUBLESHOOTING

If you encounter issues with your earbuds, refer to the following common problems and solutions:

Problem	Solution
Earbuds do not power on.	Ensure the earbuds are charged. Place them in the charging case and connect the case to power.
Earbuds do not pair with each other.	Place both earbuds back into the charging case, close the lid, then remove them again to re-initiate automatic pairing.
Earbuds do not connect to my device.	<ul style="list-style-type: none">• Ensure Bluetooth is enabled on your device.• Forget "Cellet_EB600" from your device's Bluetooth list and try pairing again.• Ensure earbuds are fully charged.• Restart your device.
No sound or low volume.	<ul style="list-style-type: none">• Adjust the volume on your connected device.• Ensure earbuds are properly seated in your ears.• Check if the earbuds are connected to the correct device.
Charging case not charging.	Ensure the USB-C cable is securely connected to both the case and the power source. Try a different USB port or power adapter.

SPECIFICATIONS

Model Name	XG01
------------	------

Bluetooth Version	5.2
Wireless Communication Technology	Bluetooth
Connectivity Technology	Wireless
Ear Placement	In Ear
Form Factor	In Ear
Noise Control	Active Noise Cancellation
Control Type	Media Control
Control Method	Touch
Special Feature	Microphone Included
Material	Aluminum, Plastic, Stainless Steel
Item Weight	4 Ounces (113 grams)
Product Dimensions	1 x 1 x 1 inches (each earbud)
Charging Case Battery	300mAh
Earbuds Battery	45mAh * 2
Music Play Time	3-4 hours
Calling Talk Time	3-4 hours
Standby Time	150 hours
Bluetooth Distance	10M (33 feet)
Waterproof Level	IPX5

COMPATIBILITY

These earbuds are designed to be compatible with a wide range of Bluetooth-enabled devices, including but not limited to:

- Smartphones (e.g., iPhone, Samsung Galaxy, Google Pixel)
- Tablets (e.g., iPad, Android tablets)
- Laptops and Computers
- Other Bluetooth-enabled audio devices

COMPATIBLE TO

IPHONE 11, 11 PRO, 11 PRO MAX XS MAX, XS, XR, 8/8 PLUS,
SAMSUNG GALAXY NOTE 9, NOTE 8, GALAXY S10/S10 PLUS/ S10E, LG V30S THIN Q, LG V30,
GOOGLE PIXEL 2, PIXEL 2 XL, IPODS, IPADS, TABLETS AND OTHER WIRELESS ENABLED DEVICES



Figure 6: Device Compatibility. The earbuds are shown with icons representing compatibility with Apple, Android, and Windows devices, as well as specific examples like smartphones, tablets, and MP3 players.

WARRANTY INFORMATION

Cellet products are manufactured to high-quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included in your package or contact customer support for specific warranty terms and conditions.

CUSTOMER SUPPORT

For further assistance, technical support, or warranty claims, please contact Cellet customer service. Contact information can typically be found on the product packaging or the official Cellet website.

