

Cecotec GrandHeat 2350 (Model 01388)

Cecotec GrandHeat 2350 Digital Built-in Microwave Oven User Manual

Model: GrandHeat 2350 (01388) | Brand: Cecotec

Introduction	Safety Instructions	Product Overview	Setup	Operating Instructions	Maintenance
	Troubleshooting	Specifications		Warranty & Support	

1. INTRODUCTION

Thank you for choosing the Cecotec GrandHeat 2350 Digital Built-in Microwave Oven. This appliance is designed for convenient and efficient cooking, reheating, and defrosting. With a 23-liter capacity and 900 W microwave power, it offers versatile cooking options, including a 1000 W grill and 9 pre-configured functions. This manual provides essential information for safe operation, installation, maintenance, and troubleshooting to ensure optimal performance and longevity of your microwave oven.

2. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the appliance and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or injury.

- General Safety:** Ensure the microwave is properly grounded. Do not operate the appliance if it is damaged or malfunctioning.
- Placement:** Install the microwave in a location with adequate ventilation. Do not block ventilation openings.
- Materials:** Do not use metal containers or foil in the microwave, as this can cause arcing and damage the appliance.
- Supervision:** Close supervision is necessary when the appliance is used by or near children. This microwave includes a child safety lock feature to prevent unsupervised operation.
- Liquids:** Liquids heated in the microwave can boil over unexpectedly. Always stir liquids before and halfway through heating. Use caution when removing containers.
- Food Safety:** Do not overcook food. Do not heat sealed containers or whole eggs, as they may explode.
- Cleaning:** Always unplug the appliance before cleaning. Refer to the maintenance section for proper cleaning procedures.

3. PRODUCT OVERVIEW

The Cecotec GrandHeat 2350 is a sleek, built-in microwave oven designed to seamlessly integrate into your kitchen

cabinetry. It features a digital display and intuitive controls for ease of use.



Figure 3.1: Front view of the Cecotec GrandHeat 2350 Digital Built-in Microwave Oven.



Figure 3.2: The microwave oven seamlessly integrated into a modern kitchen cabinet.

3.1 Components

- **Control Panel:** Features digital display, buttons, and a rotary dial for setting time and power.
- **Oven Cavity:** Interior cooking space with ceramic coating.
- **Glass Turntable:** A 27 cm diameter rotating plate for even cooking.
- **Grill Rack:** Included for use with the grill function.
- **Door:** Opens easily by pressing a button.



Figure 3.3: Detail of the control panel with buttons and rotary dial, and the interior cavity.



Figure 3.4: Close-up view of the digital display, showing a time setting.

4. SETUP AND INSTALLATION

The Cecotec GrandHeat 2350 is designed for built-in installation. Proper installation is crucial for safety and optimal performance.

4.1 Unpacking

1. Carefully remove the microwave oven and all packing materials from the carton.
2. Check the appliance for any signs of damage. Do not operate if damaged.
3. Ensure all components are present: microwave oven, grill rack, turntable, and instruction manual.

4.2 Installation Requirements

- The microwave must be installed in a cabinet opening that meets the specified dimensions. Refer to the dimensions diagrams below.

- Ensure adequate ventilation space around the appliance as per installation guidelines provided in the full manual (not included here).
- The electrical outlet should be easily accessible and properly grounded.



Figure 4.1: External dimensions of the microwave oven (approx. 61.5 cm width, 45.5 cm depth, 41 cm height).




Figure 4.2: Schematic diagram illustrating the required cabinet opening dimensions for built-in installation.

4.3 Initial Cleaning

Before first use, wipe the interior and exterior of the microwave with a damp cloth. Ensure the turntable and turntable support are clean and correctly placed.

5. OPERATING INSTRUCTIONS

The GrandHeat 2350 offers various cooking modes and features for diverse culinary needs.

5.1 Basic Microwave Operation

1. Place food in a microwave-safe container on the turntable.
2. Close the door securely.
3. Select the desired microwave power level (6 levels available, up to 900 W).
4. Set the cooking time using the rotary dial or appropriate buttons.
5. Press the Start button to begin cooking.

5.2 Grill Function

Use the 1000 W grill function for browning and crisping food. Place food on the grill rack provided.

5.3 Combined Functions

The microwave allows combining microwave and grill functions for continuous operation, providing faster cooking with browning results.

5.4 Pre-configured Functions

The appliance features 9 pre-configured functions for common food types:

- Milk/Coffee
- Rice
- Pasta
- Meat
- Potatoes
- Fish
- Chicken
- Skewers
- Automatic Reheating

Select the desired function and the microwave will automatically set the optimal cooking time and power.

5.5 Defrost by Weight

This mode allows for quick and uniform defrosting of food while preserving its original texture and freshness. Simply input the weight of the food.

5.6 Quick Start

The Quick Start function allows the microwave to begin immediately at maximum power for a set duration, up to a maximum of 10 minutes. Ideal for quick reheating.

5.7 Automatic Start (Delayed Start)

You can program the microwave to start a cooking program at a specific time, offering convenience for meal preparation.

5.8 Timer Function

The built-in timer can be set for up to 95 minutes, providing flexibility for various cooking tasks.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and efficient operation of your microwave oven.

6.1 Cleaning the Interior

The interior of the GrandHeat 2350 features a ceramic coating for easy cleaning. Wipe the interior with a soft, damp cloth after each use. For stubborn stains, use a mild detergent solution. Do not use abrasive cleaners or scouring pads.

6.2 Cleaning the Exterior

Wipe the exterior surfaces with a soft, damp cloth. Avoid getting water into the ventilation openings. The control panel can be wiped with a slightly damp cloth, then dried immediately.

6.3 Turntable and Support

The glass turntable and its support can be removed for cleaning. Wash them in warm, soapy water or in a dishwasher. Ensure they are completely dry before placing them back in the microwave.

Important: Always unplug the microwave oven from the power outlet before cleaning.

7. TROUBLESHOOTING

If you encounter issues with your microwave oven, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Microwave does not start	Door not closed properly; Power cord unplugged; Fuse blown/circuit breaker tripped.	Ensure door is firmly closed; Check power connection; Check household fuse/circuit breaker.
Food not heating	Incorrect power level or time set; Door not closed properly.	Adjust power and time settings; Ensure door is firmly closed.
Turntable not rotating	Turntable not correctly placed; Debris under turntable.	Ensure turntable and support are correctly seated; Clean under the turntable.
Unusual noise during operation	Food container touching cavity walls; Turntable not properly seated.	Adjust food container position; Re-seat turntable correctly.
Child safety lock engaged	Child lock activated.	Refer to the control panel section for instructions on deactivating the child safety lock.

If the problem persists after trying these solutions, please contact Cecotec customer support.

8. SPECIFICATIONS

Technical specifications for the Cecotec GrandHeat 2350 Digital Built-in Microwave Oven:

Feature	Detail
Brand	Cecotec
Model Number	01388
Type	Built-in Digital Microwave Oven with Grill
Capacity	23 Liters
Microwave Power	900 Watts (6 power levels)
Grill Power	1000 Watts
Dimensions (L x W x H)	61.5 x 41 x 45.5 cm
Weight	14.9 Kilograms
Voltage	220 Volts
Noise Level	44 dB
Interior Material	Stainless Steel with Ceramic Coating
Special Features	Defrost, Timer, Turntable, Control Panel Safety Lock (Child Lock)
Included Components	1 Microwave Oven, 1 Grill Rack, 1 Rotary Turntable, 1 Instruction Manual

9. WARRANTY AND SUPPORT

Cecotec is committed to providing high-quality products and customer satisfaction.

9.1 Manufacturer's Warranty

This Cecotec GrandHeat 2350 Digital Built-in Microwave Oven comes with **three-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

9.2 Spare Parts Availability




Spare parts for this model are available for a period of **10 years** from the date of purchase, ensuring long-term usability and reparability of your appliance.


9.3 Customer Support

For technical assistance, warranty claims, or to inquire about spare parts, please contact Cecotec customer support through their official website or the contact information provided with your purchase documentation. When contacting support, please have your model number (01388) and purchase date ready.



Related Documents

	<p>Cecotec GrandHeat 2350 Built-In Microwave User Manual and Installation Guide</p> <p>Comprehensive guide for the Cecotec GrandHeat 2350 Built-In Microwave, covering safety instructions, operation, installation, cleaning, maintenance, and technical specifications. Learn how to use microwave, grill, and combi functions, preset programs, and auto defrost.</p>
	<p>Cecotec GrandHeat 2500 Flatbed Touch White Microwave Oven User Manual</p> <p>Comprehensive user manual for the Cecotec GrandHeat 2500 Flatbed Touch White microwave oven, covering installation, operation, features, maintenance, troubleshooting, and warranty.</p>
	<p>EU Declaration of Conformity - Cecotec ROCK'N GRILL Electric Grill</p> <p>Official EU Declaration of Conformity for the Cecotec ROCK'N GRILL electric grill, detailing compliance with relevant European directives and harmonized standards. Includes product identification and manufacturer information.</p>



[Cecotec GRANDHEAT 2110 Microondas: Manual de Usuario Completo](#)

Guía detallada para el Cecotec GRANDHEAT 2110 Microondas. Incluye instrucciones de seguridad, funcionamiento, consejos de uso, limpieza y especificaciones técnicas. Descubra todas las funciones de su microondas.