

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Cellet](#) /

› [Cellet Wireless V5.2 Bluetooth Earbuds \(Model XG01\) User Manual](#)

Cellet XG01

Cellet Wireless V5.2 Bluetooth Earbuds

Model: XG01

INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your Cellet Wireless V5.2 Bluetooth Earbuds, Model XG01. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- Wireless Bluetooth Earbuds (Left and Right)
- Portable Charging Case
- USB-C Charging Cable
- Earbud Tips (Small, Medium, Large)
- User Manual



Image: Package Contents. This image displays all items included in the product package: the charging case, the left and right earbuds, the user guide, a Type-C charging cable, and three pairs of ear caps in small, medium, and large sizes.

SETUP

1. Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging case and a compatible USB power source. The LED indicator on the case will show charging status.

CONVENIENT CHARGING/STORAGE CASE

Bluetooth Version: V5.0
Bluetooth Distance: 10M
Earbuds Battery: 45mAh*2
Waterproof Level: IPX5

Charging Case Battery: 300mAh
Charging Time: About 1.5 hours
Music Playing Time: 3-4 hours
Calling Talk Time: 3-4 hours



Image: Charging Case. This image shows the charging case with a lightning bolt graphic, indicating charging. It also lists specifications such as Bluetooth version, distance, battery capacities for earbuds and case, and estimated usage times.

2. Pairing with a Device

1. Remove both earbuds from the charging case. They will automatically power on, and a blue light will indicate their active status.
2. Wait for the voice prompt "Pairing, Left Channel, Right Channel." This confirms that the earbuds have successfully synced with each other.
3. On your device (smartphone, tablet, etc.), navigate to the Bluetooth settings.
4. Search for available devices and select "Cellet_EB600" from the list.
5. Once connected, both earbuds will flash blue approximately every 8 seconds, indicating a successful connection.

COMPATIBLE TO

IPHONE 11, 11 PRO, 11 PRO MAX XS MAX, XS, XR, 8/8 PLUS,
SAMSUNG GALAXY NOTE 9, NOTE 8, GALAXY S10/S10 PLUS/ S10E, LG V30S THIN Q, LG V30,
GOOGLE PIXEL 2, PIXEL 2 XL, IPODS, IPADS, TABLETS AND OTHER WIRELESS ENABLED DEVICES



Image: Device Compatibility. This illustration demonstrates the earbuds' broad compatibility with different operating systems and devices, including MP3 players, various smartphones (Android and iOS), and tablets.

OPERATING INSTRUCTIONS

Earbud Controls

Each earbud features a multi-function touch button for various operations:

- **Play/Pause Music:** Single tap on either earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud (if supported by your device).

LED POWER INDICATORS ON CHARGING CASE AND EARBUDS



Image: Earbud Controls. A detailed view of the earbuds within their charging case, highlighting the multi-function buttons on both the right and left earbuds, which are used for various controls and voice notifications.

Wearing the Earbuds

Select the earbud tips that provide the most comfortable and secure fit for optimal sound quality and noise isolation.

ULTRA-SMALL AND LIGHTWEIGHT EARBUDS WITH HIGH QUALITY SOUNDS



Image: Earbud Fit. An earbud is shown comfortably placed in a user's ear, illustrating its compact and ergonomic design for a secure fit.

MAINTENANCE

Cleaning

Regularly clean the earbuds and charging case to prevent dirt and earwax buildup, which can affect sound quality and charging. Use a soft, dry, lint-free cloth. Do not use abrasive cleaners or immerse the earbuds or case in water.

Storage

When not in use, store the earbuds in their charging case to protect them from damage and to keep them charged. Store the product in a cool, dry place away from extreme temperatures.

TROUBLESHOOTING

- **Earbuds not pairing with each other:** Place both earbuds back into the charging case, then remove them simultaneously. Wait for the "Pairing, Left Channel, Right Channel" voice prompt.
- **Earbuds not connecting to device:** Ensure Bluetooth is enabled on your device. Forget "Cellet_EB600" from your device's Bluetooth list and attempt to pair again. Ensure earbuds are

charged.

- **No sound from one earbud:** Check if both earbuds are charged. Try re-pairing them with each other and then with your device.
- **Poor sound quality:** Ensure earbuds are clean and properly seated in your ears. Check the audio source device for any issues.
- **Charging issues:** Ensure the USB-C cable is securely connected to both the case and the power source. Clean the charging contacts on the earbuds and inside the case.

SPECIFICATIONS

Model Name	XG01
Bluetooth Version	V5.2
Bluetooth Distance	Up to 10 meters (33 feet)
Frequency Response	48000 KHz
Earbud Battery Capacity	45mAh per earbud
Charging Case Battery Capacity	300mAh
Charging Time	Approximately 1.5 hours
Music Playback Time	3-4 hours
Talk Time	3-4 hours
Standby Time	Up to 150 hours
Waterproof Level	IPX5
Control Method	Touch
Noise Control	Active Noise Cancellation
Material	Aluminum, Plastic, Stainless Steel
Product Dimensions	1 x 1 x 1 inches
Item Weight	4 ounces

WARRANTY AND SUPPORT

Information regarding product warranty and customer support was not provided in the available product data. Please refer to the product packaging or the retailer's website for details on warranty coverage and how to contact customer support.