

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Cellet](#) /
- › [Cellet Wireless Bluetooth Earbuds XG01 User Manual](#)

Cellet XG01

Cellet Wireless Bluetooth Earbuds Model XG01 User Manual

Model: XG01 | Brand: Cellet

INTRODUCTION

This manual provides comprehensive instructions for the Cellet Wireless Bluetooth Earbuds Model XG01. Please read this manual carefully before using the product to ensure proper operation and to maximize your user experience. Keep this manual for future reference.

The Cellet Wireless Bluetooth Earbuds feature V5.0 Bluetooth technology for stable connections, noise-isolating design for high-quality sound, and built-in dual microphones for clear communication. They come with a convenient charging case and multiple ear tip sizes for comfort.



Image: Package contents including earbuds, charging case, USB-C cable, user guide, and ear caps.

PACKAGE CONTENTS

- Wireless Bluetooth Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- User Manual
- Ear Caps (Small, Medium, Large)

SETUP

1. Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging case and a power source. The LED indicators on the charging case will show the charging status.

CONVENIENT CHARGING/STORAGE CASE

Bluetooth Version: V5.0
Bluetooth Distance: 10M
Earbuds Battery: 45mAh*2
Waterproof Level: IPX5

Charging Case Battery: 300mAh
Charging Time: About 1.5 hours
Music Playing Time: 3-4 hours
Calling Talk Time: 3-4 hours



Image: The charging case with earbuds inside, illustrating the charging process and displaying key specifications like Bluetooth version, battery capacity, and talk/music time.

2. Pairing with Your Device

1. Remove both earbuds from the charging case. They will automatically power on, indicated by a blue light.
2. Wait for the voice prompt "Pairing, Left Channel, Right Channel." This confirms the earbuds are synced with each other.
3. On your device (smartphone, tablet, etc.), go to the Bluetooth settings.
4. Search for "Cellet_EB600" in the list of available Bluetooth devices.
5. Select "Cellet_EB600" to connect. Once connected, both earbuds will flash blue approximately every 8 seconds.

If pairing fails, place the earbuds back into the charging case, close the lid, and repeat the steps.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Remove earbuds from the charging case. They will power on automatically.

- **Power Off:** Place earbuds back into the charging case and close the lid. They will power off automatically and begin charging.

Multifunction Button Controls

Each earbud features a multifunction button for various controls. Refer to the image below for button location.



Image: The open charging case displaying the left and right earbuds, highlighting the multifunction buttons and LED power indicators on both the earbuds and the charging case.

- **Play/Pause Music:** Single press the multifunction button on either earbud.
- **Answer/End Call:** Single press the multifunction button on either earbud during an incoming call or active call.
- **Reject Call:** Press and hold the multifunction button on either earbud during an incoming call.
- **Activate Voice Assistant:** (Specific action not detailed in source, typically a long press or double tap) Refer to your device's manual for voice assistant activation with Bluetooth devices.

Voice Notifications

The earbuds provide voice notifications for incoming calls, battery level status, and when they are successfully paired with your device.



Image: Depicts individuals using the earbuds in different settings, including while driving, cycling, and relaxing, demonstrating their versatility for communication and entertainment.

MAINTENANCE

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- Ensure charging contacts on both earbuds and case are clean and free of debris.

Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place away from extreme temperatures and direct sunlight.

TROUBLESHOOTING

Common Issues and Solutions

- **Earbuds not powering on:**

Ensure the earbuds are fully charged. Place them in the charging case and check the charging indicators.

- **Earbuds not pairing with device:**

Make sure Bluetooth is enabled on your device. Forget "Cellet_EB600" from your device's Bluetooth list and attempt to pair again following the "Pairing with Your Device" steps.

Ensure earbuds are removed from the charging case and are in pairing mode (indicated by voice prompt).

- **Only one earbud working:**

Place both earbuds back into the charging case, close the lid, then remove them simultaneously to allow them to re-sync with each other.

Check battery level for both earbuds.

- **Poor sound quality or disconnections:**

Ensure your device is within the Bluetooth range (approximately 10 meters/33 feet) and there are no significant obstacles.

Check for interference from other wireless devices.

Clean the ear tips and earbud speakers to remove any debris.


SPECIFICATIONS

Feature	Detail
Model Name	XG01
Bluetooth Version	V5.0
Connectivity Technology	Wireless (Bluetooth)
Ear Placement	In Ear
Control Type	Media Control, Touch
Microphone	Included (Dual Microphones)
Noise Control	Noise Isolation
Frequency Response	48000 KHz
Earbuds Battery Life (Music)	3-4 hours
Earbuds Battery Life (Talk Time)	3-4 hours
Charging Case Battery	300mAh
Charging Time (Case)	About 1.5 hours
Standby Time	150 hours
Wireless Range	10M

Waterproof Level	IPX5
Material	Aluminum, Plastic, Stainless Steel
Product Dimensions	1 x 1 x 1 inches
Item Weight	4 ounces

COMPATIBLE TO

IPHONE 11, 11 PRO, 11 PRO MAX XS MAX, XS, XR, 8/8 PLUS,
SAMSUNG GALAXY NOTE 9, NOTE 8, GALAXY S10/S10 PLUS/ S10E, LG V30S THIN Q, LG V30,
GOOGLE PIXEL 2, PIXEL 2 XL, IPODS, IPADS, TABLETS AND OTHER WIRELESS ENABLED DEVICES



MP3



Smartphones



Tablets

Image: Illustrates the broad compatibility of the earbuds with various devices, including iPhones, Samsung Galaxy phones, LG phones, Google Pixel phones, iPods, iPads, and other tablets and smartphones.

WARRANTY AND SUPPORT

Cellet products are designed for reliability and performance. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. Please retain your proof of purchase for warranty claims.

For technical support, warranty inquiries, or further assistance, please contact Cellet customer service through their official website or the retailer where the product was purchased.

Note: Specific warranty terms and conditions may vary by region. Please refer to the warranty card included in your package or visit the official Cellet website for detailed information.

