

Manuals.plus /

- › Cellet /
- › Cellet Wireless Bluetooth Earbuds XG01 User Manual

Cellet XG01

Cellet Wireless Bluetooth Earbuds XG01 User Manual

Model: XG01

1. PRODUCT OVERVIEW

The Cellet Wireless Bluetooth Earbuds XG01 are designed to provide a high-quality audio experience with convenience and portability. These ultra-small and lightweight in-ear headphones feature advanced Bluetooth 5.2 technology for stable connectivity and efficient power consumption. Equipped with noise-isolating capabilities and built-in dual microphones, they ensure clear sound for both music and calls.

The earbuds come with a compact charging case that not only protects them but also recharges them on the go. A multifunctional button on each earbud allows for easy control of music playback, call management, and voice notifications.

**ULTRA-SMALL AND LIGHTWEIGHT
EARBUDS WITH HIGH QUALITY SOUNDS**



Image: Cellet XG01 Earbud shown in an ear, emphasizing its compact and lightweight design for comfortable wear.

COMPATIBLE TO

IPHONE 11, 11 PRO, 11 PRO MAX XS MAX, XS, XR, 8/8 PLUS,
SAMSUNG GALAXY NOTE 9, NOTE 8, GALAXY S10/S10 PLUS/ S10E, LG V30S THIN Q, LG V30,
GOOGLE PIXEL 2, PIXEL 2 XL, IPODS, IPADS, TABLETS AND OTHER WIRELESS ENABLED DEVICES



MP3



Smartphones



Tablets

Image: Illustration demonstrating the broad compatibility of Cellet XG01 Earbuds with various devices, including Apple and Android smartphones, tablets, and MP3 players.

2. PACKAGE CONTENTS

Please check the package for the following items:

- Cellet Wireless Bluetooth Earbuds (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- User Manual
- Ear Cushions (Small, Medium, Large sizes)



Image: All items included in the Cellet XG01 package: the charging case, left and right earbuds, user's guide, Type-C charging cable, and ear caps in various sizes.

3. SETUP GUIDE

3.1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the USB Type-C charging cable to the charging port on the case and the other end to a USB power source (e.g., wall adapter, computer USB port). The LED indicators on the case and earbuds will show charging status.

CONVENIENT CHARGING/STORAGE CASE

Bluetooth Version: V5.0
Bluetooth Distance: 10M
Earbuds Battery: 45mAh*2
Waterproof Level: IPX5

Charging Case Battery: 300mAh
Charging Time: About 1.5 hours
Music Playing Time: 3-4 hours
Calling Talk Time: 3-4 hours



Image: The Cellet XG01 charging case with earbuds, illustrating the charging process and displaying key battery specifications for the case and earbuds.

3.2. Bluetooth Pairing

1. **Power On:** Remove both earbuds from the charging case. They will automatically power on, and a blue light will indicate this.
2. **Automatic Sync:** Wait for the voice prompt "Pairing, Left Channel, Right Channel." This confirms that the earbuds have successfully synced with each other.
3. **Connect to Device:** On your device (smartphone, tablet, etc.), go to the Bluetooth settings menu.
4. **Select Device:** Search for "Cellet_EB600" in the list of available Bluetooth devices and select it to connect.
5. **Confirmation:** Once connected, both earbuds will flash blue approximately every 8 seconds, indicating a successful connection.

4. OPERATING INSTRUCTIONS

4.1. Multifunctional Button Controls

Each earbud is equipped with a multifunctional button for easy control:

- **Music Playback:**
 - Single press: Play/Pause music.
 - Double press (Right earbud): Next track.
 - Double press (Left earbud): Previous track.
- **Call Management:**
 - Single press during incoming call: Answer call.
 - Single press during a call: End call.
 - Press and hold during incoming call: Reject call.
- **Voice Assistant:** Triple press: Activate your device's voice assistant (e.g., Siri, Google Assistant).

LED POWER INDICATORS ON CHARGING CASE AND EARBUDS



Image: Detailed diagram showing the Cellet XG01 earbuds within their charging case, with labels pointing to the multi-function buttons on both the left and right earbuds.

4.2. Voice Notifications

The earbuds provide voice notifications for important status updates, including:

- Incoming call alerts.
- Battery level status.
- Pairing and connection status.



Image: Users engaging with Cellet XG01 earbuds in different daily activities, such as making calls while driving, listening to music while cycling, and relaxing, highlighting the versatility and hands-free communication feature.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Cellet Wireless Bluetooth Earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials. Gently remove any earwax or debris from the earbud tips and speaker grilles using a small, soft brush or cotton swab.
- **Storage:** Always store the earbuds in their charging case when not in use to protect them from dust, dirt, and physical damage.
- **Avoid Moisture:** While the earbuds are water-resistant, avoid prolonged exposure to water or extreme humidity. Do not submerge them in water. Ensure they are dry before placing them back in the charging case.
- **Temperature:** Store and operate the earbuds within recommended temperature ranges. Avoid extreme hot or cold environments.

6. TROUBLESHOOTING

If you encounter any issues with your Cellet Wireless Bluetooth Earbuds, please refer to the following common solutions:

Problem	Solution
Earbuds not pairing with each other.	Ensure both earbuds are removed from the charging case simultaneously. If they don't sync, place them back in the case, close it, wait a few seconds, then remove them again.
Earbuds not connecting to device.	<ul style="list-style-type: none">• Make sure Bluetooth is enabled on your device.• Ensure the earbuds are charged and powered on.• Forget "Cellet_EB600" from your device's Bluetooth list and try pairing again.• Restart your device and the earbuds.
No sound or low volume.	<ul style="list-style-type: none">• Check the volume level on both your device and the earbuds.• Ensure the earbuds are properly connected to your device.• Clean any debris from the earbud speaker grilles.
Charging case not charging.	<ul style="list-style-type: none">• Verify the USB Type-C cable is securely connected to both the case and the power source.• Try a different USB cable or power adapter.• Ensure the power source is active.

7. SPECIFICATIONS

Brand:	Cellet
Model Number:	XG01
Bluetooth Version:	5.2
Ear Placement:	In Ear
Noise Control:	Active Noise Cancellation
Battery Life (Music Playback):	Up to 6 Hours
Connectivity Technology:	Wireless (Bluetooth)
Control Method:	Touch
Water Resistance Level:	Water Resistant
Item Weight:	4 Ounces
Frequency Range:	20 Hz - 48000 Hz
Materials:	Aluminum, Plastic, Stainless Steel
UPC:	756449294110

8. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official Cellet website. If you require technical support or have questions not covered in this manual, please contact Cellet customer service through their official channels.

Contact Information: Please refer to the product packaging or the official Cellet website for the most up-to-date customer support contact details.