Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Enchanted Forest /
- > Enchanted Forest LED 50 Dome Light Set Instruction Manual

Enchanted Forest LED 50 Dome Light Set

Enchanted Forest LED 50 Dome Light Set Instruction Manual

Model: LED 50 Dome Light Set

Introduction

Thank you for choosing the Enchanted Forest LED 50 Dome Light Set. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new light set. Please read these instructions thoroughly before use and retain them for future reference.



Image 1: Packaging for the Enchanted Forest LED 50 Dome Light Set. The image displays the product box, highlighting key features such as 'LED', '50 Dome Light Set', 'Up to 88% More Energy Efficient', 'Connect up to 45 Light Sets', 'UL Certified', and 'Cool White' light color with green wire.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic precautions should always be followed, including the following:

- · Read all instructions.
- Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use. When products are used in outdoor applications, connect the product to a Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
- This seasonal product is not intended for permanent installation or use.

- Do not mount or place near gas or electric heaters, fireplaces, candles, or other similar sources of heat.
- Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
- Do not let lamps rest on the supply cord or on any wire.
- Unplug the product when leaving the house, when retiring for the night, or if left unattended.
- This is an electrical product, not a toy! To avoid risk of fire, burns, personal injury, and electric shock, it should not be played with or placed where small children can reach it.
- Do not use this product for anything other than its intended use.
- Do not hang ornaments or other objects from cord, wire, or light string.
- Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
- Do not cover the product with cloth, paper, or any material not part of the product when in use.
- This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit condition. If the fuse blows, unplug the product from the outlet. Also unplug any additional strings or products that may be attached to the product. Replace the fuse as per the user servicing instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit condition may be present and the product should be discarded.
- Read and follow all instructions that are on the product or provided with the product.

PACKAGE CONTENTS

Verify that all components are present and in good condition before proceeding with installation.

- 1 x Enchanted Forest LED 50 Dome Light Set
- 1 x Remote Control
- Instruction Manual (this document)

SETUP AND INSTALLATION

1. Unpacking

Carefully remove the light set and all components from the packaging. Untangle the string lights gently to avoid damage to the wiring or LED domes.

2. Placement

This LED light set is suitable for both indoor and outdoor use. When installing outdoors, ensure the power source is protected from direct water exposure, although the lights themselves are waterproof. Position the lights in your desired location, ensuring the total lighted length of 12.5 feet is sufficient for your display.

3. Connecting Multiple Sets

The Enchanted Forest LED 50 Dome Light Set is designed to be connectable. You can connect up to 45 light sets end-to-end. To connect, align the male plug of one set with the female receptacle of another and push firmly until secure. Ensure all connections are tight to prevent electrical hazards.



Image 2: A close-up view of the LED dome lights and the connection point. The image shows the green wire connecting several white LED dome bulbs, illustrating the design and how multiple sets can be linked together.

4. Power Connection

Plug the light set into a standard electrical outlet. For outdoor use, always use a GFCI-protected outlet.

OPERATING INSTRUCTIONS

1. Powering On/Off

Once plugged in, the lights should illuminate. To turn the lights on or off, use the provided remote control or unplug the unit from the power source.

2. Using the Remote Control

The included remote control allows for convenient operation of your light set. Point the remote directly at the receiver on the light string. Specific functions of the remote control may include:

- ON/OFF Button: To switch the lights on or off.
- Mode Selection: If applicable, cycle through different lighting modes (e.g., steady, flashing, fading).
- Brightness Adjustment: If applicable, increase or decrease the light intensity.

Note: Ensure the remote control has working batteries. Replace batteries if the remote does not respond.

MAINTENANCE

1. Cleaning

To clean the light set, ensure it is unplugged from the power source. Gently wipe the LED domes and wires with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.

2. Storage

When not in use, store the light set in a cool, dry place, away from direct sunlight and extreme temperatures. Carefully coil the string to prevent tangling and damage to the wires or bulbs.

3. Fuse Replacement

This product is equipped with a fuse for overload protection. If the lights do not illuminate, the fuse may need replacement. Refer to the fuse compartment on the plug for specific fuse rating and replacement instructions. Always unplug the light set before attempting to replace the fuse.

TROUBLESHOOTING

If you encounter issues with your light set, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Lights do not turn on.	No power, blown fuse, loose connection.	Check if the plug is fully inserted into a working outlet. Inspect the fuse in the plug and replace if blown. Ensure all connections between light sets are secure.
Remote control is not working.	Dead batteries, obstruction, out of range.	Replace batteries in the remote control. Ensure there are no obstructions between the remote and the light set's receiver. Operate the remote within close range.
Some lights are off.	Damaged LED bulb.	LEDs are generally durable. If a specific bulb is out, it may indicate a rare defect. The remaining lights should continue to function.

SPECIFICATIONS

Refer to the following technical specifications for your Enchanted Forest LED 50 Dome Light Set:

• Model: LED 50 Dome Light Set

Light Source Type: LEDNumber of Lights: 50

. Light Color: White

• Lighted Length: 12.5 feet (3.81 meters)

• Total Length: 13.8 feet (4.21 meters)

• Power Source: Corded Electric

• Wattage: 4.8 watts per set

• Energy Savings: Up to 88% over standard mini lights

• LED Life: Approximately 25,000 hours average

• Indoor/Outdoor Usage: Yes (Waterproof feature)

Connectability: Up to 45 light sets
Controller Type: Remote Control

Manufacturer: Menards
 UPC: 764878629168

WARRANTY AND SUPPORT

For warranty information or technical support regarding your Enchanted Forest LED 50 Dome Light Set, please refer to the contact details provided on the product packaging or visit the manufacturer's official website. Keep your proof of purchase for any warranty claims.

© 2023 Enchanted Forest. All rights reserved.

Related Documents - LED 50 Dome Light Set



Enchanted Forest 5' LED Smart Cone Tree - Assembly, Operation, and Safety Guide

Comprehensive guide for the Enchanted Forest 5' LED Smart Cone Tree (Model 23SYM-QY0818), including assembly instructions, safety warnings, remote control functions, and Magic Lantern app usage.



Anko LV 600 LED String Lights User Guide & Safety Information

Detailed user guide and safety warnings for the Anko LV 600 LED Multifunction Warm White String Lights (Model SL2810-C(WWW)). Includes adaptor manual, functions, and important usage instructions.



Feit Electric 72007 LED String Lights - Installation and Safety Guide

This guide provides essential safety instructions, installation methods, and maintenance tips for the Feit Electric 72007 LED String Lights. Learn how to safely connect, install, and replace bulbs for these durable indoor/outdoor lights.



Wiz String Lights Quick Setup and Safety Guide

Learn how to easily set up your Wiz String Lights with this comprehensive guide. Includes step-bystep instructions, app integration details, and essential safety information for indoor and outdoor use.



Feit Electric SL48/182/FIL Weatherproof String Lights Installation and Safety Guide

This guide provides essential safety instructions, installation methods, bulb replacement procedures, troubleshooting tips, and warranty information for the Feit Electric SL48/182/FIL weatherproof string lights.



Enbrighten 84313 Indoor Accent Spectrum String Wall Lights Installation Guide

Detailed installation and user guide for Enbrighten 84313 Indoor Accent Spectrum String Wall Lights. Covers setup, remote operation, battery replacement, warranty, and FCC compliance for these RGBWIC LED accent lights.