

[Manuals.plus](#) /

> [AULCMEET](#) /

> AULCMEET RC802V Voice Remote Control User Manual

AULCMEET RC802V

AULCMEET RC802V Voice Remote Control User Manual

Model: RC802V

1. INTRODUCTION

This user manual provides comprehensive instructions for the AULCMEET RC802V Replaced Voice Remote Control. Designed as a direct replacement for various TCL Android TV models, this remote offers seamless control and integrated voice search functionality. Please read this manual thoroughly to ensure proper setup and operation.






Figure 1: Front view of the RC802V Voice Remote Control, showcasing its sleek black design and button layout.

2. PRODUCT FEATURES

The RC802V remote control is engineered to provide a user-friendly experience with advanced features:

- **Direct Replacement:** Functions as a direct replacement for the original TCL Android TV remote, requiring no complex programming for basic functions.
- **Voice Control Functionality:** Integrated microphone for voice commands and search, enhancing navigation and content discovery.
- **Easy Connectivity:** Designed for easy pairing with compatible TCL Android TVs.
- **Dedicated App Buttons:** Quick access to popular streaming services like Netflix and YouTube.
- **Infrared (IR) and Radio Frequency (RF) Support:** Offers flexible control options, allowing operation without direct line-of-sight once paired via RF.



Figure 2: The remote control with an overlay indicating the voice search function, accessible via the dedicated microphone button.

3. SETUP

3.1 Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

3.2 Initial Pairing (for Voice Control and RF Functionality)

While basic functions may work immediately via infrared, to enable voice control and full RF functionality, pairing with your TCL Android TV is required:

1. Ensure your TCL Android TV is powered on.
2. Point the remote control towards the TV.
3. Simultaneously press and hold the **"Home"** button and the **"OK"** button on the remote control for a few seconds.
4. A pairing confirmation message should appear on your TV screen, indicating successful pairing.
5. If pairing is unsuccessful, ensure the remote is close to the TV and repeat the steps.

4. OPERATING INSTRUCTIONS

4.1 Basic Functions

- **Power Button** (): Turns the TV on or off.
- **Home Button** (△): Returns to the TV's home screen.
- **Navigation Buttons** (▲ ▼ ◀ ▶): Navigate through menus and options.
- **OK Button**: Confirms selections.
- **Back Button** (←): Returns to the previous screen.
- **Volume Up/Down** (+/-): Adjusts the TV volume.
- **Channel Up/Down** (CH+/-): Changes TV channels.
- **Netflix Button**: Launches the Netflix application directly.
- **YouTube Button**: Launches the YouTube application directly.

4.2 Using Voice Control

After successful pairing, you can use the voice control feature:

1. Press the **Voice Search Button** (often indicated by a microphone icon or Google Assistant logo).
2. Hold the remote control close to your mouth and speak your command clearly.
3. Release the button when you are finished speaking.

Examples of voice commands include: "Open Netflix," "Search for action movies," "What's the weather like?," "Play music by [artist name]".



Figure 3: Illustrative image of a user operating the remote control while watching television.

5. MAINTENANCE

5.1 Cleaning the Remote

To maintain the remote's appearance and functionality:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals or abrasive cleaning agents.

5.2 Battery Care

- Replace batteries when the remote's response becomes sluggish or inconsistent.
- Remove batteries if the remote will not be used for an extended period to prevent leakage.
- Dispose of used batteries according to local regulations.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote not responding.	Low or dead batteries. Incorrect battery insertion. Remote not paired (for RF/voice). Obstruction between remote and TV (for IR).	Replace batteries. Ensure batteries are inserted correctly. Re-pair the remote as per Section 3.2. Remove any obstructions.
Voice control not working.	Remote not paired for voice functionality. TV does not support voice control. Microphone obstructed.	Ensure the remote is paired (Section 3.2). Verify your TV model supports voice control. Ensure the microphone on the remote is clear.
Buttons are sticky or unresponsive.	Dirt or debris under the buttons.	Clean the remote surface (Section 5.1).

7. SPECIFICATIONS

Feature	Detail
Model Number	RC802V
Brand	AULCMEET
Product Dimensions	5 x 1 x 0.5 inches (12.7 x 2.54 x 1.27 cm)
Item Weight	0.705 ounces (20 grams)
Batteries Required	2 AAA batteries
Special Feature	Voice Search
Color	Black
Max Number of Supported Devices	1 (Television)



Figure 4: Dimensional diagram of the RC802V remote control, indicating its length of 6.1 inches and width of 1.57 inches.

8. COMPATIBLE TCL ANDROID TV MODELS

The AULCMEET RC802V remote control is compatible with a wide range of TCL Android TV models, including but not limited to:

- 40S330, 32S330, 65Q637, 55Q637, 55S430, 43S430, 43S434, 50S434, 55S434, 65S434, 75S434, 70S430
- 32P30S, 49P30FS, 43P30FS, 32S6500A, 55EP680, 32A325, 32A323, 40A325, 40A323
- 40S334, 32S334, 40S6510FS, 43S6500, 43P8M, 43P8, 43P717, 43P715, 43P65US

- 32S6800S, 32S65A, 32S6510S, 32S6500S, 32S6500, 32S615, 32S60A, 32S5200
- 85P8M, 85P715, 75P8MR, 75P8M, 75P715, 75C815, 65T8S, 65P8S, 65P8M, 65P8, 65P717, 65P715, 65C815, 65C8, 65C717, 65C716, 65C715
- 55T8S, 55P8S, 55P8M, 55P8, 55P717, 55P715, 55C815, 55C8, 55C717, 55C716, 55C715
- 50T8S, 50P8S, 50P8M, 50P8, 50P717, 50P715, 50P65US, 50C717, 50C716, 50C715
- 49S6510FS, 49S6500FS, 49S6500, 43S6800FS, 49S6800, 43S65A/F8F, 43S6510FS, 43S6500FS

For a complete list of compatible models, please refer to the product listing or contact AULCMEET customer support.

9. SAFETY INFORMATION

- Do not expose the remote control to direct sunlight, heat sources, or extreme temperatures.
- Avoid dropping the remote or subjecting it to strong impacts.
- Do not disassemble the remote control. This will void any potential warranty.
- Keep batteries out of reach of children and pets. If swallowed, seek immediate medical attention.
- Do not mix old and new batteries, or different types of batteries.

10. WARRANTY AND SUPPORT

Specific warranty details for the AULCMEET RC802V remote control are not provided within the product specifications. For information regarding warranty coverage, technical support, or customer service, please refer to the original product packaging, the seller's website, or contact AULCMEET customer support directly.

Contact information for AULCMEET can typically be found on their official website or through the retailer where the product was purchased.