

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Vikefon](#) /

> [Vikefon Type-C Data Charging Cable User Manual](#)

Vikefon Type C 0126

Vikefon Type-C Data Charging Cable User Manual

Model: Type C 0126

INTRODUCTION

This manual provides essential information for the proper use and care of your Vikefon Type-C Data Charging Cable. Please read these instructions carefully to ensure optimal performance and longevity of your cable.

The Vikefon Type-C Data Charging Cable is designed for reliable charging and high-speed data transfer for a wide range of compatible devices, including smartphones, tablets, and other USB Type-C enabled electronics.

PRODUCT FEATURES

- **Universal Compatibility:** Compatible with all Type-C mobile devices.
- **Fast Charging:** Supports power output up to 5V, 3 Amp for rapid charging.
- **High-Speed Data Transfer:** Data transfer rates up to 480 Mbps.
- **Durable Design:** Features intricate nylon braiding for enhanced durability and longevity, tested for over 5000 bends.
- **Reversible Type-C Connector:** Allows for quick and easy connections in any orientation.



Figure 1: Cable durability features, highlighting enhanced insulation, thickness, and bend testing.

SETUP

Connecting the Vikefon Type-C Data Charging Cable is a straightforward process. Ensure both your device and power source are compatible with USB Type-C.

1. Identify the USB Type-A end of the cable. This end typically connects to a power adapter, computer USB port, or power bank. Gently insert the USB Type-A connector into the appropriate port on your power source or computer. Ensure correct orientation as USB Type-A is not reversible.
2. Identify the USB Type-C end of the cable. This end connects to your compatible smartphone, tablet, or other Type-C enabled device. Gently insert the USB Type-C connector into the Type-C port on your device. The USB Type-C connector is reversible, allowing for easy connection in any orientation.



Figure 2: USB Type-A and Type-C connectors.



Figure 3: Detailed view of the USB Type-C connector.

OPERATING INSTRUCTIONS

Charging Your Device

Connect the cable as described in the 'Setup' section. Once connected to a compatible power source (such as a wall adapter, power bank, or computer USB port), your device will begin charging. This cable supports up to 5V, 3 Amp output for rapid charging, provided your power source and device also support these specifications.

Transferring Data

To transfer data, connect the USB Type-A end of the cable to a computer's USB port and the USB Type-C end to your device. Your computer should recognize the device, allowing you to access and transfer files. Data transfer rates can reach up to 480 Mbps, enabling quick synchronization of photos, videos, and documents.

MAINTENANCE

Proper care will extend the life of your Vikefon Type-C Data Charging Cable and ensure consistent performance.

- **Avoid Extreme Bending:** Do not bend the cable sharply, especially near the connectors. Excessive bending can damage the internal wires and insulation.
- **Handle by Connectors:** Always grasp the connector housing when plugging or unplugging the cable. Avoid pulling directly on the cable wire.
- **Keep Clean:** Keep the cable and its connectors free from dust, dirt, and debris. Use a soft, dry cloth for cleaning.
- **Proper Storage:** Store the cable in a loose coil rather than tightly wrapped to prevent stress on the internal wires and outer jacket.
- **Environmental Conditions:** Avoid exposing the cable to extreme temperatures, direct sunlight, or moisture for prolonged periods.

**2X MORE INSULATION
MORE THICKNESS
THAN REGULAR CABLES**




Figure 4: Vikefon Type-C cable in a coiled state.

TROUBLESHOOTING

If you encounter issues with your Vikefon Type-C Data Charging Cable, refer to the following common problems and solutions:

- **Device Not Charging:**
 - Ensure both ends of the cable are securely connected to the device and power source.
 - Verify that the power adapter or USB port you are using is functional.
 - Check your device's charging port for any debris or obstructions.
 - Try using a different power adapter or USB port.
- **Slow Charging:**
 - Confirm that your power adapter supports fast charging and provides sufficient output (e.g., 5V, 3A).
 - Ensure your device is not running power-intensive applications during charging.
- **Data Transfer Issues:**

- Ensure the cable is properly connected to both the device and the computer.
- Check your device's settings to ensure data transfer mode is enabled (e.g., 'File Transfer' or 'MTP').
- Try connecting to a different USB port on your computer.
- Restart both your device and computer.

- **Cable Damage:**

- If the cable shows signs of physical damage (fraying, exposed wires, bent connectors), discontinue use immediately to prevent electrical hazards.

SPECIFICATIONS

Feature	Detail
Brand	Vikefon
Model Name	Type C 0126
Connector Type	USB Type-C (Device), USB Type-A (Host)
Cable Type	USB
Compatible Devices	Smartphones, Tablets, Laptops, Charging Adapters with Type-C port
Power Output	Up to 5V, 3 Amp
Data Transfer Rate	Up to 0.48 Gigabits Per Second (480 Mbps)
Length	1 Meter (100 cm)
Outer Material	Nylon Braided (as per product features)
Connector Gender	Male-to-Male
Net Quantity	1 Count
Specification Met	ISO

WARRANTY AND SUPPORT

For product support or inquiries, please refer to the retailer or manufacturer's official contact channels. While specific warranty details are not provided in this manual, proper care and adherence to these instructions will help ensure the longevity and reliable performance of your Vikefon Type-C Data Charging Cable.