



Manuals.plus /

› seenda /

› seenda 2.4GHz Ultra-Thin Wireless Rechargeable Silent Keyboard (Japanese Layout) - Model IWG-7302C User Manual

**seenda IWG-7302C**

# seenda 2.4GHz Ultra-Thin Wireless Rechargeable Silent Keyboard

MODEL: IWG-7302C USER MANUAL

## 1. Introduction

Thank you for purchasing the seenda 2.4GHz Ultra-Thin Wireless Rechargeable Silent Keyboard. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your new keyboard. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

## 2. Product Overview

The seenda IWG-7302C is a full-size, ultra-thin wireless keyboard designed for efficiency and comfort. It features a Japanese layout, a numeric keypad, and a silent pantograph key structure. Its ergonomic design helps reduce wrist fatigue during long typing sessions.



Image: The seenda wireless keyboard, showcasing its sleek design and full-size layout on a modern desk setup.

### 3. Setup

- 1. Charge the Keyboard:** Before initial use, fully charge the keyboard using the included USB-C cable. Connect the USB-C end to the keyboard's charging port and the USB-A end to a power source (e.g., computer USB port, USB wall adapter). The charging indicator LED will illuminate during charging and turn off when fully charged.
- 2. Locate the USB Receiver:** The 2.4GHz USB receiver is typically stored in a compartment on the underside of the keyboard or included separately in the packaging.
- 3. Connect the Receiver:** Insert the USB receiver into an available USB-A port on your computer.



Image: A close-up view of the USB receiver being inserted into a laptop's USB port, illustrating the wireless connection method.

- 4. Power On the Keyboard:** Locate the power switch on the underside of the keyboard and slide it to the 'ON' position.



Image: The bottom of the keyboard, highlighting the power switch and anti-slip pads for stable placement.

5. **Automatic Connection:** The keyboard should automatically connect to your computer. No additional drivers are typically required for Windows operating systems.

## 4. Operating Instructions

### 4.1 Key Features

- **Full-Size Layout:** Includes a dedicated numeric keypad for convenient data entry, ideal for spreadsheets and financial applications.
- **Ultra-Thin Design:** The keyboard features a slim profile, with key height approximately half of traditional keyboards. An ergonomic tilt angle at the base helps prevent wrist fatigue during extended use.



Image: Diagram showing the keyboard's dimensions and its ultra-thin profile, emphasizing its compact and ergonomic design.

- **Silent Pantograph Keys:** The pantograph-style key structure provides a fast rebound and high sensitivity, making it suitable for high-speed typing while minimizing click noise. This low-noise design allows for focused work in quiet environments.



Image: A magnified view illustrating the pantograph key mechanism and an icon indicating silent operation, highlighting the keyboard's quiet typing experience.

- **Rechargeable & Energy Saving:** The keyboard is powered by a built-in rechargeable battery, eliminating the need for disposable batteries. A full charge provides approximately 180 hours of continuous operation and over 900 hours of standby time. To conserve energy, the keyboard automatically enters sleep mode after 5 minutes of inactivity.



Image: A close-up of the USB-C charging port on the keyboard, indicating its rechargeable nature and ease of power replenishment.

## 4.2 LED Indicators

The keyboard features several LED indicators to provide status information:

- **Caps Lock Indicator:** Illuminates red when Caps Lock is active.
- **Num Lock Indicator:** Illuminates red when Num Lock is active.
- **Low Battery Indicator:** A small LED near the volume keys will light up when the battery is low, signaling that charging is required.
- **Charging Indicator:** Illuminates blue during charging and turns off when the battery is full.



Image: A detailed view of the keyboard's upper right section, pointing out the Caps Lock, Num Lock, and battery status indicators, along with the charging port.

## 5. Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe the keyboard surface. For stubborn dirt, a slightly damp cloth can be used, ensuring no liquid enters the keycaps or internal components. Avoid harsh chemicals or abrasive materials.
- **Charging:** Recharge the keyboard when the low battery indicator lights up. Use only the provided USB-C cable or a certified equivalent. Avoid overcharging for extended periods.
- **Storage:** When not in use for a long time, turn off the keyboard using the power switch to conserve battery life. Store in a cool, dry place away from direct sunlight and extreme temperatures.

## 6. Troubleshooting

- **Keyboard not responding:**
  - Ensure the keyboard is powered on.
  - Check if the USB receiver is securely plugged into your computer's USB port.
  - Verify the keyboard battery is charged. Recharge if necessary.
  - Try plugging the USB receiver into a different USB port on your computer.
  - Restart your computer.
- **Keys not registering or intermittent input:**
  - Ensure the keyboard is within the effective range of the USB receiver (typically up to 10 meters).
  - Avoid placing the receiver near strong interference sources (e.g., other wireless devices, large metal objects).
  - Clean any debris from under the affected keys.
- **Charging issues:**
  - Ensure the USB-C cable is properly connected to both the keyboard and the power source.
  - Try using a different USB-C cable or power source to rule out cable/adaptor issues.
  - If the charging port feels loose, ensure the cable is inserted firmly and correctly.
- **Some function keys not working on Mac OS:**
  - This keyboard is primarily designed for Windows. Some function keys may have limited or no

functionality on Mac OS. This is expected behavior.

## 7. Specifications

Feature	Specification
Brand	seenda
Model Number	IWG-7302C
Connectivity Technology	2.4GHz Wireless (USB Receiver)
Keyboard Description	Pantograph
Number of Keys	108
Power Source	Rechargeable Battery (USB-C)
Compatible Devices	PC (Windows 10, 8, 7, Vista, XP, 2000)
Hand Orientation	Ambidextrous
Dimensions (Approx.)	43.5 cm (17.1 in) Length, 12.5 mm (4.9 in) Width, 0.5 cm (0.2 in) to 2 cm (0.8 in) Thickness
Weight (Approx.)	466 g (16.4 oz)

## 8. Warranty and Support

**Warranty:** This product comes with a 1-year warranty against manufacturer defects. Please retain your proof of purchase for warranty claims.

**Support:** If you encounter any issues or have questions regarding the use of your seenda keyboard, please do not hesitate to contact our customer support team via email. Refer to your product packaging or the retailer's website for contact information.