

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [LG](#) /

> [LG LRGL5825F 5.8 Cu. Ft. Stainless Steel Gas Range with Air Fry User Manual](#)

LG LRGL5825F

LG LRGL5825F 5.8 Cu. Ft. Stainless Steel Gas Range with Air Fry User Manual

Model: LRGL5825F

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient use, installation, maintenance, and troubleshooting of your LG LRGL5825F 5.8 Cu. Ft. Stainless Steel Gas Range with Air Fry. Please read all instructions carefully before using the appliance to ensure proper operation and to prevent potential hazards.

2. IMPORTANT SAFETY INFORMATION

WARNING: If the information in this manual is not followed exactly, a fire or explosion may result causing property damage, personal injury, or death.

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- WHAT TO DO IF YOU SMELL GAS:
 - a. Do not try to light any appliance.
 - b. Do not touch any electrical switch; do not use any phone in your building.
 - c. Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
 - d. If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency, or the gas supplier.
- Always ensure proper ventilation when operating the gas range.
- Keep children away from the appliance during operation.

3. PRODUCT OVERVIEW

The LG LRGL5825F is a 5.8 cubic feet capacity gas range featuring a stainless steel finish, multiple burners, and an integrated Air Fry function. It is designed for freestanding installation.



Figure 3.1: Front view of the LG LRGL5825F 5.8 Cu. Ft. Stainless Steel Gas Range. This image displays the full front of the appliance, including the control panel, cooktop with grates, oven door with handle, and storage drawer.



Figure 3.2: Top-down view of the cooktop area. This image highlights the five sealed burners, heavy-duty grates, and the central removable griddle accessory.



Figure 3.3: Close-up of the control panel and burner knobs. The digital display shows the time and oven settings, while the five front-mounted knobs control the individual gas burners.

Key Features:

- **Capacity:** 5.8 Cu. Ft. oven capacity.
- **Burners:** Five sealed gas burners, including an UltraHeat 20,000 BTU burner for rapid boiling and a simmer burner.
- **Air Fry:** Integrated Air Fry function for healthier cooking options.
- **Control Console:** Knob controls for burners and digital touch controls for oven functions.
- **Material:** Stainless Steel construction.

4. SETUP AND INSTALLATION

The LG LRGL5825F is a freestanding gas range. Proper installation is crucial for safety and optimal performance. It is highly recommended that installation be performed by a qualified installer or service technician.

Installation Steps (Summary):

1. **Location:** Ensure the range is placed on a level surface and away from combustible materials.
2. **Gas Connection:** Connect the range to a natural gas or LP gas supply using an approved gas connector. Ensure all connections are leak-tested.
3. **Electrical Connection:** Plug the range into a properly grounded electrical outlet (120 Volts).
4. **Anti-Tip Bracket:** Secure the anti-tip bracket to the wall or floor as per instructions to prevent accidental tipping.
5. **Leveling:** Adjust the leveling legs to ensure the range is stable and level.

Refer to the detailed installation guide provided with your appliance for complete instructions and safety warnings.

5. OPERATING INSTRUCTIONS

5.1 Cooktop Operation

- **Igniting Burners:** Push in and turn the desired burner knob counter-clockwise to the "LITE" position. You will hear a clicking sound as the igniter sparks. Once the burner ignites, continue to hold the knob in for a few seconds, then adjust to the desired flame size.
- **Flame Adjustment:** Turn the knob to adjust the flame from high to simmer. A proper flame should be blue and stable.
- **Griddle Use:** Place the griddle over the center burners. Preheat the griddle before placing food on it.

5.2 Oven Operation

- **Setting Bake Temperature:** Press the "BAKE" button on the control panel. Use the number pad to enter the desired temperature, then press "START". The oven will preheat to the set temperature.
- **Convection Baking:** Press the "CONV. BAKE" button, enter the temperature, and press "START". Convection uses a fan to circulate hot air for more even cooking.
- **Broiling:** Press the "BROIL" button, select the broil level (High/Low), and press "START". Keep the oven door slightly ajar for optimal broiling.
- **Oven Racks:** The oven includes 7 rack positions. Adjust racks before preheating for best results.

5.3 Air Fry Function

The Air Fry function utilizes the convection fan and a specific heating element to circulate hot air around food, providing a crispy texture similar to deep-frying with less oil.

- **Using Air Fry:** Press the "AIR FRY" button on the control panel. Enter the desired temperature and cooking time, then press "START".
- **Recommended Accessories:** For best results, use a dark, non-stick baking sheet with low sides or an air fry basket to allow for proper air circulation around the food.
- **Preheating:** Preheating is generally recommended for air frying to achieve optimal crispiness.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your LG gas range.

6.1 Cooktop Cleaning

- **Grates and Burner Caps:** Remove grates and burner caps. Wash with warm, soapy water. For stubborn stains, use a non-abrasive cleaner. Ensure they are completely dry before reassembling.
- **Cooktop Surface:** Wipe the stainless steel surface with a damp cloth and mild detergent. For best results, use a stainless steel cleaner and polish.

6.2 Oven Cleaning

- **Self-Clean Cycle:** The oven features a self-clean function. Remove all racks and accessories before

starting a self-clean cycle. Follow the instructions on the control panel for initiating and completing the cycle.

- **Manual Cleaning:** For light spills, wipe the interior with a damp cloth and mild soap once the oven has cooled.
- **Oven Racks:** Clean oven racks with warm, soapy water.

6.3 Exterior Cleaning

- Wipe the exterior stainless steel surfaces with a soft cloth and a stainless steel cleaner. Avoid abrasive cleaners or scouring pads.
- Clean the control panel with a damp cloth. Do not spray cleaners directly onto the panel.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your LG LRGL5825F gas range. For more complex problems, contact qualified service personnel.

Problem	Possible Cause	Solution
Burner does not ignite.	Gas supply off, burner ports clogged, igniter wet or dirty.	Check gas supply valve. Clean burner ports and igniter. Ensure burner caps are correctly seated.
Oven not heating.	Power supply issue, oven controls not set correctly.	Check circuit breaker. Ensure oven settings are correctly entered and "START" is pressed.
Uneven cooking in oven.	Improper rack placement, overcrowded oven, dirty oven.	Adjust rack position. Avoid overcrowding. Clean oven interior.
Gas odor.	Gas leak.	Immediately follow safety instructions in Section 2. Do not operate the appliance.

8. SPECIFICATIONS

Feature	Detail
Brand	LG
Model Name	LRGL5825F
Item Weight	169 pounds
Product Dimensions (H x W x D)	47 x 30 x 29 inches
Capacity	5.8 Cubic Feet
Installation Type	Freestanding
Burner Type	Sealed
Drawer Type	Storage, Warming
Heating Elements	5 (Cooktop Burners)

Feature	Detail
Color	Stainless Steel
Control Console	Knob and Digital Touch
Voltage	120 Volts
Racks	7 (Oven Rack Positions)
Fuel Type	Gas
Material Type	Stainless Steel

9. WARRANTY AND SUPPORT

Your LG LRGL5825F Gas Range is covered by a limited warranty. Please refer to the warranty card included with your product for specific terms, conditions, and duration of coverage.

For technical assistance, service, or to order replacement parts, please contact LG Customer Service:

- **Website:** Visit the official LG website for support resources and contact information.
- **Phone:** Refer to your product documentation for the customer service phone number in your region.

When contacting support, please have your model number (LRGL5825F) and serial number readily available.